



LENOXX KB922 61 Key Electronic Keyboard Instruction Manual

[Home](#) » [lenoxx](#) » LENOXX KB922 61 Key Electronic Keyboard Instruction Manual 

Contents

- [1 LENOXX KB922 61 Key Electronic Keyboard](#)
- [2 Product features,](#)
- [3 CONNECTION DESCRIPTION](#)
- [4 FN combination function key](#)
- [5 Troubleshooting](#)
- [6 FCC Caution](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)



LENOXX KB922 61 Key Electronic Keyboard



Product features,

1. Support switching back and forth across devices
2. Three-system mod@ switching: the mainstream equipment of the general market
3. Bluetooth S.O is b@tter compatible with new and old devices
4. Connect vel\$!On S.O to hibernate and wake up faSter
5. W,the high-frequency equipment switching, the keyboard works smoothly

CONNECTION DESCRIPTION

1. Turn the power switch to ON to turn on the keyboard
2. 4G mode; (system default)
Take out the USB receiver and plug it into the computer
3. Bluetooth mode:
Press and hold FN. then press 1. and then press and hold for 3 seconds, the blue light flashes.and Bluetooth device 1 enters the searched state on the device side-open the turn ;ettmgi-tum on 81uetootll-\$earch end

Multi-device connection

1. FN + 1: connect Bluetooth device
2. FN +2: connect Bluetooth device 2
3. FN +3: connect Bluetooth device 3
4. FN + -connect USB,2.4G wireless ,_1v1n9
5. FN + L2.3, – combination single press; you can switch the paired devices
6. FN +L2.3combined long press for 3 seconds: flashing light, C<In start ifie searched state (connect new equipment)

Connection supplement

1. The initial connection keyboard needs 10 switch the devices to the corresponding system
2. the system is not switched, the function key may work normally'
3. The new distance of keyboard, 5-10m. and the distance is related to different equipment and environmental factors

FN combination function key

Connection switching		Multimedia buttons	
FN+1	Combined long press for 3seconds, flashing light can search to add new device	FN+F1	Brightness+
FN+2		FN+F2	Brightness-
		FN+F3	Show desktop
FN+3	Switch to USB wireless	FN+F4	screen capture
FN+E	Apple IOS mode	FN+F5	Lock screen
FN+Q	Android mode	FN+F6	Search
FN+W	Windows mode	FN+F7	In a song
FN+F	Windows, F1-F12	FN+F8	The last song
		FN+F9	Play/Pause
FN+1	Combined single press can switch paired devices	FN+F10	The next song
FN+2		FN+F11	Mute
FN+3		FN+F12	Turn down the volume
		FN+Del	Turn up the volume

Troubleshooting

1. When the keyboard can't be searched, try Bluetooth on the switch device to search again
2. When the keyboard is turned on and there is no indicator light, try to charge the keyboard
3. After connecting other devices, you used to delete the old records before connecting back to the original devices
4. When the pairing fails, the failed pairing record needs to be deleted and the second pairing is performed

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Documents / Resources



[LENOXX KB922 61 Key Electronic Keyboard](#) [pdf] Instruction Manual
KB922, 2A3TZ-KB922, 2A3TZKB922, KB922 61 Key Electronic Keyboard, 61 Key Electronic Keyboard