



levoit LV110WP-RF Water Pitcher Replacement Filter User Guide

[Home](#) » [Levoit](#) » levoit LV110WP-RF Water Pitcher Replacement Filter User Guide

Contents [[hide](#)]

- [1 levoit LV110WP-RF Water Pitcher Replacement Filter](#)
- [2 ABOUT YOUR FILTER](#)
- [3 TROUBLESHOOTING](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)

levoit[™]

levoit LV110WP-RF Water Pitcher Replacement Filter



SAFETY INFORMATION

Follow all safety guidelines. Read all instructions before using.

- Only filter tap water. This filter cartridge is not designed to filter water from other sources (such as river water).
- The filter cartridge may become clogged and may not work correctly if filtering liquids other than tap water.
- Do not filter hot water (over 35°C / 95°F). This may damage the filter and may release contaminants.

ABOUT YOUR FILTER

A. Upper Micro Net

Removes particles suspended in the water, such as sand, rust, sludge, and organic matter.

B. Activated Carbon

- Uses high-quality activated carbon for excellent filtration.
- Removes chlorine taste and odor effectively.
- Removes pesticides (including Endrin) and residual pollutants.
- Improves taste of water.


C. Ion-Exchange Resin

- Reduces heavy metals (such as lead, cadmium, mercury, copper, and aluminum).
- Reduces minerals in water to soften it, leaving a percentage of beneficial minerals behind (such as calcium

and magnesium).

D. Lower Micro Net

Final filtration removes remaining unwanted particles in the water.



BEFORE USING

1. Remove all packaging from the filter cartridge.
2. Remove the restrictor caps from the bottom of the filter. [Figure 1.1]
3. Soak the filter cartridge in clean tap water (submerged completely) for 15 minutes.

NOTE: There may be carbon dust in the water while rinsing or soaking the filter. This is normal.




Figure 1.1

4. Rinse the filter cartridge thoroughly for 10 seconds under running water.
5. Replace the restrictor caps on the bottom of the filter.




Figure 1.2



Figure 1.3

Restrictor Cap Settings

- Place the restrictor cap in the “+” position if you want water to filter faster, or in the “-” position if you want water to filter more thoroughly. [Figure 1.2]
- You can remove the caps completely if you want water to filter as fast as possible.

Rubber Gasket

- Place the restrictor cap in the “+” position if you want water to filter faster, or in the “-” position if you want water to filter more thoroughly. [Figure 1.2]
- You can remove the caps completely if you want water to filter as fast as possible.
- Make sure the rubber gasket is correctly in place on the filter cartridge. If the rubber gasket has come loose, press into place, making sure the ridge is facing up. [Figure 1.3]

6. Place the filter cartridge into the filter chamber. Press the cartridge into place as firmly as possible to prevent leaks. [Figure 1.4]

7. Fill the pitcher with cold tap water. Discard the filtered water. Refill and discard the water 2 more times.

8. Reset the filter timer by pressing firmly for 8 seconds. Your filter is ready to use. [Figure 1.5]



Figure 1.4




Figure 1.5

NOTE: If water filtration becomes slow, repeat these steps again. Shake the filter before replacing it into the pitcher.

TROUBLESHOOTING

Problem	Possible Solution
Water filtration is too slow.	Place the restrictor cap in the “+” position if you want water to filter faster, or remove the caps completely if you want water to filter as fast as possible (see Restrictor Cap Settings).
	Follow the steps in Before Using to soak the filter. Shake the filter before replacing it into the pitcher. Press the cartridge into place as firmly as possible to prevent leaks.

TERMS & POLICY

Arovast Corporation warrants all products to be of the highest quality in material, craftsmanship, and service, effective from the date of purchase to the end of the warranty period.

Arovast Corporation will replace any product found to be defective due to manufacturer flaws based on eligibility. Refunds are available within the first 30 days of purchase. Refunds are only available to the original purchaser of the product. This warranty extends only to personal use and does not extend to any product that has been used for commercial, rental, or any other use for which the product is not intended. There are no warranties other than the warranties expressly set forth with each product. This warranty is non-transferrable. Arovast Corporation is not responsible in any way for any damages, losses, or inconveniences caused by equipment failure or by user negligence, abuse, or use noncompliant with the user manual or any additional safety or use warnings included in the product packaging and manual.

This warranty does not apply to the following:

- Damage due to abuse, accident, alteration, misuse, tampering, or vandalism.
- Improper or inadequate maintenance.

- Damage in return transit.
- Unsupervised use by children under 18 years of age.

Arovast Corporation and its subsidiaries assume no liability for damage caused by the use of the product other than for its intended use or as instructed in the user manual. Some states do not allow this exclusion or limitation of incidental or consequential losses so the foregoing disclaimer may not apply to you. This warranty gives you specific legal rights and you may also have other rights which may vary from state to state.

ALL EXPRESSED AND IMPLIED WARRANTIES, INCLUDING THE WARRANTY OF MERCHANTABILITY, ARE LIMITED TO THE PERIOD OF THE LIMITED WARRANTY.

Extend Your Warranty by 1 Year

Register your product at www.levoit.com/warranty to extend your 1-year warranty by an additional year. Please fill out all required fields and include your order ID, place of purchase, and purchase date, if applicable.

Defective Products & Returns

If you discover your product is defective within the specified warranty period, please contact Customer Support via support@levoit.com with a copy of your invoice and order ID. DO NOT dispose of your product before contacting us. Once Customer Support has approved your request, please return the product with a copy of the invoice or order ID.

WARRANTY

Product Name	Pitcher Replacement Filter
Model	LV110WP-RF
Default Warranty Period	1 year
For your own reference, we strongly recommend that you record your order ID and date of purchase.	
Date of Purchase	
Order ID	

CUSTOMER SUPPORT

If you have any questions or concerns about your new product, please contact our helpful Customer Support Team.

Arovast Corporation

1202 N. Miller St., Suite A

Anaheim, CA 92806

Email: support@levoit.com

Toll-Free: (888) 726-8520

Support Hours

Mon–Fri, 9:00 am–5:00 pm PST/PDT

Please have your order invoice and order ID ready before contacting Customer Support.

Questions or Concerns?

Please contact us Mon–Fri, 9:00 am–5:00 pm PST/ PDT at support@levoit.com or at (888) 726-8620.



Documents / Resources

	levoit LV110WP-RF Water Pitcher Replacement Filter [pdf] User Guide LV110WP-RF, Water Pitcher Replacement Filter
---	---

References

-  [Vesync-Warranty Registration](#)