





# Link tech LBS-Q218 LED Flashing Portable Wireless Speaker **User Manual**

Home » LINK TECH » Link tech LBS-Q218 LED Flashing Portable Wireless Speaker User Manual



#### **Contents**

- 1 Link tech LBS-Q218 LED Flashing Portable Wireless **Speaker**
- 2 Specifications
- **3 Product Feature**
- **4 Key And Slot Function**
- 6 Documents / Resources
  - **6.1 References**
- **7 Related Posts**



Link tech LBS-Q218 LED Flashing Portable Wireless Speaker



## **Specifications**

Wireless	V5.3
	L2CAP/A2DP/AVCTP, can receive AUDIO signal and control the AUDIO device.
Support	Support HSP/HFP(Handsfree profile), with
	HANDS-FREE functions.
Working distance	10M
SNR	≥90db
Battery	3.7V about 1500mAh
Normal volume playing time	about 3 hours with LED light off
Speaker driver	¢52mm*2
Power	40/5W *2
Frequency response	120Hz-20KHz
Unit size	185.5*82*82.5mm
Unit weight	about 587g (not include accessories)
Charging	5V/500mA
charging time	about 4h

### **Product Feature**

- 1. International advanced wireless chip and circuit design techniques, support all wireless devices.
- 2. With FM function, can search radio station broadcast automatically.
- 3. With Hi-Fi speaker, to make sure the clear and bright sound.
- 4. Supports micro SD card and USB card, play MP3 format audio.
- 5. The wireless working distance is 10 meters.
- 6. With AUX line in, can directly connect the outside devices, for example, tablet PC/TV/cell phones.
- 7. It will close automatically after 30 mins.
- 8. A variety of flashing LED lights with different colors, color lights flash follows the melody.


- 9. With mobile holder
- 10. Support TWS.

#### **Key And Slot Function**

- 1. DC 5V slot: Use the standard Micro USB VB charging cable for power charging.
- 2. TF slot: It can decode and play MP3 format audio when put TF card into the slot
- 3. USB slot: It can decode and play MP3 format audio when put the USB card into the slot
- 4. AUX line in slot: Use the Mini 3.5 head input through outside devices.
- 5. Power switch: Press long for power on /power off. When play music, (USB card/TF card/Wireless/line in), short press for "play/pause". In FM mode, press short to search station automatically, press again to stop searching. Under wireless mode with mobile paired, when call coming, press short to answer a call hands-free, press again to hand up, press twice to ring up a call.
- 6. When play music, press short for last song, long press to turn down the volume.
- 7. When play music, press short for next song, long press to turn up the volume.
- 8. LED switch: press short for option of the LED flashing light, press long to close/open the LED light
- 9. Short press to switch model

(USB card/TF card/Wireless/line in/FM). TWS: Keep the two speakers under Wireless mode without pairing, press the "M" key for 2-3 seconds either of the speaker until hear a hint and mean-time the button light stop flashing, now it is TWS mode, then can pair the mobile.

**NOTE:** In the FM mode, put in micro charging cable or AUX cable to increase the FM radio signal. If this speaker crashes during use, you can press and hold the power button for 8 seconds to reset and shut down.



USB/TF card pls use FAT32 format

## • Q: How do I reset the speaker if it crashes during use?

A: Press and hold the power button for 8 seconds to reset and shut down the speaker.

#### **Documents / Resources**

LIOK
LES-0218
LED FLASHING PORTABLE
WIRELESS SPEAKER
USER MANUAL
Hello!

<u>Link tech LBS-Q218 LED Flashing Portable Wireless Speaker</u> [pdf] User Manual LBS-Q218 LED Flashing Portable Wireless Speaker, LBS-Q218, LED Flashing Portable Wireless Speaker, Portable Wireless Speaker, Wireless Speaker, Wireless Speaker, Wireless Speaker

No biasulishnooning his Proba to decouples broased action has being schooner.

#### References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.