

**Linocell®
65441
Wireless
Keyboard
for Tablets**



Linocell 65441 Wireless Keyboard for Tablets Instruction Manual

[Home](#) » [Linocell](#) » Linocell 65441 Wireless Keyboard for Tablets Instruction Manual 

Contents

- [1 Linocell 65441 Wireless Keyboard for Tablets](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Overview](#)
- [5 Specifications](#)
- [6 Use](#)
- [7 Troubleshooting](#)
- [8 Safety information](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)

Linocell®

Linocell 65441 Wireless Keyboard for Tablets



Product Information

Specifications:

- **Connection:** Bluetooth ver. 5.1 (10m)
- **Size:** 285x117x21 mm
- **Weight:** 344 g
- **Input power, charging:** USB-C
- **Battery time:** Up to 4 hours
- **Compatibility:** Tablets
- **In the box:** Wireless keyboard, USB-C charging cable

Product Usage Instructions

- **Before First Use:**

Charge the keyboard fully before using it for the first time.

- **Charging:**

Connect the included USB-C charging cable between the USB-C charging port and a USB power adapter. The battery indicator lights up red during charging and turns green when fully charged. A full charge takes up to 4 hours.

- **Power On/Off:**

To turn on the keyboard, slide the Power on/off switch to On. The battery indicator lights up green for 3 seconds and then turns off, indicating the keyboard is on. To turn it off, slide the switch to Off.

- **Note:** The keyboard enters sleep mode after 30 minutes of inactivity. Press any key to wake it up.

- **Bluetooth Pairing:**

The keyboard can be connected to up to 3 different Bluetooth devices. To pair, hold Fn and number 1 key for 3 seconds. Open Bluetooth settings on your device, and connect to “Linocell BTK17”. The Bluetooth indicator turns solid green when connected.

- **Multimedia Keys:**

Function keys may differ based on operating systems. Use the Fn key to activate functions like PgUp/Dn/Home/End.

Troubleshooting:

- If the keyboard won't turn on or the battery indicator flashes red, charge the keyboard.
- If the device shows a connection but the keys don't work, press a key to wake up from sleep mode.
- If issues persist, remove and reconnect the keyboard in the device's Bluetooth settings.

FAQ:


- **Q: How do I change the focus between different paired devices?**

A: Hold down the Fn key and tap the number on the keyboard corresponding to the device you want to use.

- **Q: How many Bluetooth devices can be connected to the keyboard?**

A: The keyboard can be connected to up to 3 different Bluetooth devices.

Overview



Specifications

- **Connection:** Bluetooth ver. 5.1 (10 m)
- **Size:** 285x117x21 mm
- **Weight:** 344 g
- **Input power, charging:** 5 V/500 mA (charger sold separately)
- **Battery time:** Up to 66 h
- **Compatibility:** iOS, AndroidOS, Windows, Mac OS
- **Wireless frequency:** 2402–2480 MHz
- **Max. radiated power:** 20 mW (Max.)
- **In the box:** Bluetooth keyboard, USB-C to USB-A charging cable (80 cm), manual

Before first use

Charge the keyboard fully before using it for the first time.

Use

Charging

- Connect the included USB-C charging cable between the USB-C charging port and a USB power adapter (sold separately). The battery indicator lights up red during charging and turns green when the keyboard is fully charged. A full charge takes up to 4 hours.
- The battery indicator flashes red when the battery power is low.

Power on/off


- Slide the Power on/off switch on the back of the keyboard to “On” to turn the keyboard.
- The battery indicator lights up green for 3 seconds and turns off, but the keyboard is still on.
- Slide the Power on/off switch to “Off” to turn off the keyboard.

Note!

The keyboard automatically enters sleep mode after 30 minutes of inactivity to save battery power. Press any key and wait a couple of seconds to wake it.

Bluetooth pairing

- The keyboard can be connected to up to 3 different Bluetooth devices, and focus is easily shifted between the devices as long as a Bluetooth connection has been made first.
- Activate the Bluetooth pairing by holding the Fn and number 1 keys on the keyboard for 3 seconds. The Bluetooth indicator lights up and flashes green. Open the Bluetooth settings on your device and look for “Linocell BTK17” and connect. The Bluetooth indicator turns to a solid green light when the connection is successful.
- To add more devices, follow the same procedure as above, but change which number key is pressed to 2 or 3. The Bluetooth indicator lights up in different colors during use and pairing depending on what Bluetooth device/channel is selected or currently being paired:
 - Bluetooth 1: green light
 - Bluetooth 2: blue light
 - Bluetooth 3: red light













- To change the keyboard focus between different devices, hold down the Fn key and tap the number on the keyboard that the device is paired to.
- To disconnect a Bluetooth device from the keyboard, hold down the Fn key and the number key to which your device is connected for 3 seconds.

Multimedia keys

The keys in the top row (F1–F10) have functions or shortcuts assigned to them which are outlined in blue.

Note!

The function key commands may differ between different operating systems. The functions PgUp/Dn/Home/End are activated when the Fn key is held down.

Key	Windows/AndroidOS	iOS/iPadOS	Mac OS
 / 	Screen brightness -/+	Screen brightness -/+	Screen brightness -/+
	Mute	Mute	Mute
 / 	Volume -/+	Volume -/+	Volume -/+
	Previous track	Previous track	Previous track
	Play/pause	Play/pause	Play/pause
	Next track	Next track	Next track
	Open browser	Display desktop	Mission Control
	Search	Search	Search

Troubleshooting

- **The keyboard won't turn on, or the battery indicator flashes red during use.**

If the battery is low or depleted – charge the keyboard.

- **My device states that the keyboard is connected, but nothing is happening when I press the keys.**

- The keyboard may have been put in sleep mode, press a key and wait a few seconds for it to wake up.
- Try removing the keyboard from your device's Bluetooth settings. Go to the Bluetooth settings for your

device. Find "My devices"/"Paired devices", locate "Linocell BTK17" in the list, and tap the "i" icon. Select the option "Forget This Device". Pair the keyboard to your device again.

- **Not all keystrokes are registered when I press them down on the keyboard.**

Make sure that the distance between your keyboard and device is not more than 10 meters. Make sure there are no objects between the keyboard and your device, or that a radio transmitter or wifi signal is interfering.

Safety information


- The product contains a rechargeable Li-ion battery and the battery can not be replaced. Do not store the product with the battery completely discharged for extended periods. Charge the juicer once every 3 months during extended periods of storage.
- Never attempt to disassemble the product. Repairs should only be performed by a qualified technician.
- We recommend turning off the keyboard when it's not in use to extend the longevity of the built-in battery.

Simplified EU Declaration of Conformity

Kjell & Company hereby declares that this device complies with the essential requirements and other relevant provisions of Directive 2014/53/EU. The full text of the EU Declaration of Conformity is available at www.kjell.com/65441.

- Box 50435 Malmö Sweden 2024-05-30
- www.linocell.com.

Documents / Resources

	<p>Linocell 65441 Wireless Keyboard for Tablets [pdf] Instruction Manual 65441, 65441 Wireless Keyboard for Tablets, Wireless Keyboard for Tablets, Keyboard for Tablets, Tablets</p>
---	---

References

- [Linocell Bluetooth-tangentbord - Bluetooth-tangentbord | Kjell.com](#)
- [Linocell | Kjell.com](#)
- [User Manual](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.