Manuals+ — User Manuals Simplified.

LITETRONICS SFSAS01 Extender for VTCS Series Pluggable Sensor

# LITETRONICS SFSAS01 Extender for VTCS Series Pluggable Sensor User Guide

Contents

LITETRONICS®

LITETRONICS SFSAS01 Extender for VTCS Series Pluggable Sensor

Product Specifications

- **Product Name:** Extender for VTCS Series Pluggable Sensor (EJ50)
- **Dimensions:** 29.2mm / 1.15 inches
- **Size:** 71.5mm / 2.81 inches

Product Usage Instructions

1. Before installation, always turn off the power supply from the main circuit breaker first!
2. Open the fixture and remove the knockout.
3. Remove the lock nut from the 3-wire elbow (SFSAS01 – Sold Separately) and add it to the extender.
4. Attach the extender to the knockout and tighten it to the fixture.
5. Follow the wiring diagram for connections (refer to Figure 1).
6. Close the fixture.
7. Turn on the power.

FAQ

- **Q: Can the extender be used with other sensor models?**
  - **A**: The extender is specifically designed for use with the VTCS Series Pluggable Sensor (EJ50) and may

not be compatible with other models.

- **Q: What should I do if I encounter difficulties during installation?**
    - **A**: If you face any challenges during installation, please contact our customer service at 1-800-860-3392 or email us at CustomerService@Litetronics.com for assistance.
- **Q: Is it necessary to follow the wiring instructions exactly as stated?**
    - **A**: Yes, to ensure proper installation and functionality, it is crucial to adhere to the provided wiring instructions.

WHAT COMES IN THE BOX

Extender

SAFETY INSTRUCTIONS AND WARNINGS

- When using electrical equipment, basic safety precautions should always be observed
- This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved
- Installation should only be conducted by a qualified electrician in accordance with NEC and any relevant local building codes.
- Be certain electrical power is OFF before and during installation and maintenance.
- To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or sharp objects.

WIRING INSTRUCTIONS

Figure 1

Yellow: 12-24Vdc
Pink: DIM-
Purple: DIM +

1. Before installation, always turn off the power supply from the main circuit breaker first!
2. Open the fixture, and remove the knockout.
3. Remove lock nut from 3-wire elbow (SFSAS01 – Sold Separately) and add to the extender. Attach extender to knockout and tighten to the fixture.
4. Follow the wiring diagram for connections (Figure 1).
5. Close the fixture.
6. Turn on the power.

DIMENSIONS/SIZE

71.5mm / 2.81"

Ø29.2mm / 1.15"

Unit: mm / Inches

Thank you for choosing

- 6969 W. 73rd Street Bedford Park, IL 60638
- **WWW.LITETRONICS.COM**
- **CustomerService@Litetronics.com** or 1-800-860-3392

The information and product specifications contained in these instructions are based upon data believed to be accurate at the time of printing. This information is subject to change without notice and without incurring liability. If you have questions regarding specific product details, please contact us at 800-860-3392 or via email at **customerservice@litetronics.com**. To check for an updated version of these instructions, please visit **www.litetronics.com**.

Documents / Resources

 LITETRONICS SFSAS01 Extender for VTCS Series Pluggable Sensor [pdf] User Guide
SFSAS01 Extender for VTCS Series Pluggable Sensor, SFSAS01, Extender for VTCS Series Pluggable Sensor, VTCS Series Pluggable Sensor, Pluggable Sensor, Sensor

References

- **Commercial Lighting Company | LED Lighting Solutions**

- **User Manual**