



Lofree OE903 TOUCH Connection Mechanical Keyboard User Guide

[Home](#) » [Lofree](#) » Lofree OE903 TOUCH Connection Mechanical Keyboard User Guide 

Contents

- [1 Lofree OE903 TOUCH Connection Mechanical Keyboard](#)
- [2 SPECIFICATIONS](#)
- [3 FEATURE DESCRIPTION](#)
- [4 Battery Indicator](#)
- [5 Detailed user guide](#)
- [6 Multimedia keys](#)
- [7 FCC Statement](#)
- [8 Documents / Resources](#)
- [9 Related Posts](#)

Lofree


Lofree OE903 TOUCH Connection Mechanical Keyboard



SPECIFICATIONS

- Number of keys: 100 (hot-swappable Mechanical Switch)
- Number of Multimedia Keys: 12
- Materials: ABS Body, PBT Keycaps
- Interface: Type-C
- Max 2.4G & Bluetooth & Wired
- Device Name: TouchID@Lofree
- Dimensions 367mm*129mm .. 54.5mm

FEATURE DESCRIPTION



Battery Indicator

Wired Mode

- the indicator light is steady white.
- Bluetooth Mode/2.4G Wireless USB mode.
- When the power is lower than 20%, the indicator light flashes slowly in red;
- When the power is lower than 3%, the indicator light flashes quickly then automatically turn off;

Status indicator (white light)

- Caps Lock Indicator

- Solid LED light =The uppercase mode is turned on;
- LED light off= The uppercase mode is turned off;

Bluetooth Pairing indicator(white light)

- Flashing LED light= The device is in Bluetooth pairing mode;
- When successfully paired, the Pairing Indicator turns on for 3 seconds, and then turns off again;
- During each switch to a new device, the Pairing Indicator flashes quickly for 3 seconds and then turns off again

2.4G Wireless USB Pairing Indicator

- When the 2.4G receiver is started for pairing, the Pairing indicator flashes quickly for 3 seconds
- When successfully paired, the Pairing I indicator turns on for 3 seconds and then turns off again

Status switch

- 2.4G/BT:
- 2.4G / Bluetooth mode/ ON: Wired mode/ OFF: Off

Type-C interface

- Wired mode interface.


Battery cover




Detailed user guide

2.4G Wireless USB mode


1. Swipe to the right to remove the battery cover



2. Take out the 2.4G receiver



3. Install the battery cover




4. Insert the 2.4G receiver into the USB port of the computer




Note: **MAC/IOS** system devices do not support multimedia functions under 2.4G USB connection


- Switch the status to 2.4G/BT gear




- Press and hold Fn+4to start 2.4G connection mode




- The status indicator flashes quickly for 3 seconds then paired successfully




- This light turns on for 3 seconds then turns off again



1. Switch the status to 2.4G/BT gear




2. Long press Fn+ 1/ Fn+2/ Fn+3 until the status indicator flashes slowly




3. Turn on the Bluetooth function of your device, search for “Touch100@Lofree” and connect



4. When successfully paired, the Pairing Indicator turns on for 3 seconds and then turns off again




5. Short press Fn+ 1/ Fn+2/ Fn+3 to switch Bluetooth connected devices




Wired mode

1. Switch the status to the ON



2. Connect the keyboard to a computer with a Type-C cable to complete the wired connection



System Switch



Fn+N in the lower right corner is the key to trigger the corresponding system function of windows
 Fn+M in the lower right corner is the key to trigger the corresponding system function of Mac

Multimedia keys



Fn+I_in th_e upper left corner ... = the mult1med1a keys

Multimedia sign Mac Windows

FN+F1		Reduce brightness	Reduce brightness
FN+F2		increase Brightness	increase Brightness
FN+F3		Multi Screen	Multi Screen



Fn+I in the upper left corner ... = the multimedia keys

Multimedia sign		Mac	Windows
FN+F4		Search	Search
FN+F5		/	ON/Cortana
FN+F6		/	Sleep Mode/ON
FN+F7		Previous Track	Previous Track
FN+F8		Play/Pause	Play/Pause
FN+F9		Next Track	Next Track
FN+10		Mute	Mute
FN+11		Volume Down	Volume Down
FN+12		Volume Up	Volume Up
FN+Opt/Ctrl		Menu Button	Menu Button

Note: Multimedia key FN+5%/FN+6': Some models of Mac system devices may not support the triggering of this multimedia key due to the problem of matching the connected device model and system version.

Numeric keypad

- In Windows system
- The numeric keypad function is enabled when NUM light is always on
- The numeric keypad function is disabled when NUM light is off

In MAC system

The numeric keypad function is enabled by default, and the NUM key function and indicator light are invalid.

NAME AND CONTENT OF HAZARDOUS SUBSTANCES IN PRODUCT

Harmful Elements	Hazardous substances					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr, VI)	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
Plastic Components	O	O	O	O	O	O
Circuit Board Assembly	O	O	O	O	O	O
Silicone Components	O	O	O	O	O	O
Spare Partss	O	O	O	O	O	O

- This table is prepared in accordance with the provisions of SJ/T 11364.
- The classification and marking of this product were performed in accordance with the EU directive 2011/65/EU and the revised directive 2015/863/EU.
- O: indicates that the said hazardous substance contained in all the homogeneous materials' forth is component is below the limit requirement in GB/T 26572.
- X: indicates Lhal This hazardous substance contained in al least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.

ENVIRONMENTAL PROTECTION INSTRUCTIONS

The hazardous substances contained in the electronic parts of this product will not leak or change under normal use conditions for a period of ten years. During the same period, the electronic components of these products will not cause serious environmen-, tal pollution or serious. damage to human health or property while the products are being used by the consumer. According to the Chinese electronic industry standard SJ/T 11364-2014 and related Chinese government regulations, this product and some of its internal or external components may have an environmentally friendly use period mark, depending on the component and component manufacturer, the mark lifespan on the product and its components may vary. The expiration date on the component takes precedence over any conflicted or different UFUP [abelson the product.

Warning

- If the battery is not replaced properly, there may be leakage or explosion and personal injury hazards. • Do not use the battery when there is leakage, discoloration, deformation, or any other abnormality.
- Do not leave the battery in a discharged or unused state for a long time
- Do not short-circuit the product
- Battery life varies with usage. Used batteries should be disposed of in accordance with local laws or thrown away in trash cans for recycling electronic devices.
- If any liquid accidentally enters the product, please immediately disconnect the power supply and remove the product. Continuing to use the product may cause fire or electric shock. Please contact the agent or the nearest customer service center for inspection and maintenance.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the Instructions, may cause harmful interference to radio communications. However,

there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

FCC Radiation Exposure Statement

- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.
- This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Shenzhen Lofree Culture Co., Ltd.
202-F8, F518 Idea Land, 1065 Bao Yuan Road, Shenzhen
Service Hotline: 4006002083
www.lofree.com.cn www.lofree.co

Documents / Resources

	<p>Lofree OE903 TOUCH Connection Mechanical Keyboard [pdf] User Guide OE913, OE903, OE903 TOUCH Connection Mechanical Keyboard, TOUCH Connection Mechanical Keyboard, Connection Mechanical Keyboard, Mechanical Keyboard, Keyboard</p>
---	---