



## LOGIC SP9 BT SPEAKER QUICK GUIDE




### Contents [ [hide](#) ]

- [1 LOGIC SP9 BT Speaker](#)
- [2 Button Description:](#)
- [3 Instructions for Use:](#)
- [4 Warranty Certificate](#)
- [5 FCC Statement](#)
- [6 Documents / Resources](#)
  - [6.1 References](#)


## LOGIC SP9 BT Speaker

Thank you for purchasing this innovative LOGIC device. The specifications in this document are subject to change without prior notice.

LOGIC and the LOGIC logo are registered trademarks of Swagtek, Inc. Other trademarks are the property of their respective owners.



### Button Description:



1. Press to switch between modes (Bluetooth / Radio).
2. Short press to previous song / Long press to volume down.
3. Long press to Power On / Off.
4. Press to switch between lights mode / pattern.
5. Short press for next song / Long press to volume up.
6. Press for Play / Pause.

**Note:** the Speaker is compatible for most mobile devices and adapters enabled with Bluetooth technology.

### Instructions for Use:

## 1. Device connection

1.1 Once the device is ON, the speaker will be in Bluetooth Mode by default.

1.2 Look in the device for the speaker “Logic SP9mini”,

## 2. Sound notifications

2.1 There will be a sound notification when speaker is turned ON or OFF.

2.2 Before running out of battery charge, a notification will sound 3 times, then after 15 seconds the speaker will turn OFF.

## 3. Mode change

3.1 Speaker default mode is Bluetooth.

3.2 SD card and USB mode has priority once inserted.

Model: Logic SP9 mini

Function: BT, FM, TF, USB, AUX

Bluetooth: v5.3

Speaker: 57mm 508W 2

Connection Distance: 10M

Operation Mode: Button

Play Time: 3-4H

Battery Capacity: 1800mAh

Charging Voltage: DC-5V

Battery Voltage: 3.7V

## Warranty Certificate

### Terms and Conditions

LOGIC warrants that their Products will be free from defects in material and workmanship. The warranty period is one (1) year for the products and three (3) months for the accessories which are part of the original package including the battery. The warranty period begins the date of purchase by the End-User who shall present an invoice or a purchase receipt when requiring warranty service otherwise the warranty period will begin from the date of manufacture of the product. LOGIC will repair a product without cost to the customer if it presents a manufacturing defect or defect in workmanship during the warranty period and if the defect occurred under normal conditions of use in accordance with the instructions and specifications stated in the

user's manual.

For additional information about the terms and conditions of LOGIC's Limited Warranty or to obtain warranty service information, please visit the support section at: [logicmobility.com](http://logicmobility.com)

## **FCC Statement**

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
  - (1) This device may not cause harmful interference.
  - (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **NOTE:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### **FCC Radiation Exposure Statement:**

The device has been evaluated to meet general RF exposure requirement. The device

can be used in portable exposure condition without restriction.




[logicmobility.com](http://logicmobility.com)

Made in China



Copyright Swagtek, Inc. 2025

## Documents / Resources

	<p><a href="#">Logic Mobility LOGIC SP9 BT Speaker [pdf]</a> User Manual</p> <p>O55SP95024, O55SP95024, sp95024, LOGIC SP9 BT Speaker, LOGIC SP9, BT Speaker, Speaker</p>
-----------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------

## References

- [User Manual](#)

LOGIC Mobility

BT Speaker, LOGIC Mobility, LOGIC SP9, LOGIC SP9 BT Speaker, O55SP95024, sp95024, speaker

—Previous Post

[LOGIC Mobility TW7 Galaxy Buds TWS User Guide](#)

Next Post—

[Logic Mobility SP9 mini BT Speaker User Manual](#)



## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.