



**Contents** [ [hide](#) ]

- [1 LOGIC L65E 4G Smart Phone](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 INTRODUCTION](#)
- [5 Safety](#)
- [6 Understanding your Phone](#)
- [7 Using your Phone](#)
- [8 Inputting Text](#)
- [9 Maintenance](#)
- [10 Taking Care of Your Device](#)
- [11 FCC STATEMENT](#)
- [12 FAQ](#)
- [13 Documents / Resources](#)
  - [13.1 References](#)

# LOGIC

## LOGIC L65E 4G Smart Phone



## Specifications

- Model: LOGIC L65E
- Operating System: Android™
- Processor: 1.28GHz Quad Core
- SIM: Dual SIM

## Product Usage Instructions

- Make sure to follow these safety precautions to prevent any danger or violation of laws:
- Keep SAR value in mind and use the cell phone when the signal strength is good.
- Avoid long calls, especially for children, adolescents, and pregnant women.
- Use a headset or send a text message instead.
- If using a Bluetooth headset, ensure it has a low-power emitter.


## INTRODUCTION

- Thanks for choosing LOGIC L65E, double SIM, powered by Android 14 smart phone based on 1.28GHz Quad Core Processor.
- If you'd like your phone to live a long and fruitful life, please read this guide carefully and keep it for future reference. You never know when you might need it.

- And don't worry if the pictures we use to demonstrate your phone's functions look a little different from what you see on its screen. It's the functions that matter.

## Safety

### Safety Precautions

-  Please read through the following briefings carefully and act in accordance with these rules, so as to prevent causing any danger or violating any law.

### SAR Value

- XXXXW/kg@1g(Head) XXXXW/kg@1g(Body)
- Use cell phone when the signal strength is good. Keep your calls short or instead use a headset or send a text message. This advice applies especially to children, adolescents and pregnant women.
- If you are using a Bluetooth headset device, please make sure it has a low-power emitter.

### Using your phone safely



#### On The Road

- Using a phone while driving is illegal in many countries. Please follow local laws and drive safely at all times.



#### Near Sensitive Electronics

- Don't use your phone near sensitive electronic equipment, particularly medical devices such as pacemakers, as it could cause them to malfunction. It can also interfere with the operation of fire detectors and other automatic-control equipment.
- For more information about how your phone affects pacemakers or other electronic equipment, please contact the manufacturer or your local distributor.

- Your phone may cause interference when used near TVs, radios or automated office equipment.



### **While Flying**

- Your phone can cause interference with aircraft equipment. So it's essential you follow airline regulations. And if airline personnel ask you to switch off your phone, or disable its wireless functions, please do as they say.



### **In Hospital**

- Your phone may interfere with the normal operation of medical equipment. Follow all hospital regulations and turn it off when you're asked to by posted warnings or medical staff.



### **At a Petrol Station**

- Don't use your phone at petrol stations. In fact, it's always best to switch off whenever you're near fuels, chemicals or explosives.



### **Around Water**

- Keep your phone away from water (or any other liquid). It's not a waterproof model.



### **Making Repairs**

- Never take your phone apart. Please leave that to the professionals. Unauthorized repairs could break the terms of your warranty.



### **Broken Antenna**

- Don't use your phone if the antenna is damaged, as it could cause injury.



### **Around Children**

- Keep your mobile out of children's reach. It should never be used as a toy and it might not be good for their health.



### **Original Accessories**

- Only use the original accessories supplied with your phone or those approved by the manufacturer. Using unapproved accessories may affect performance, make the warranty void, break national regulations on the use of mobile phones, or even cause injury.



### **Near Explosives**

- Turn off your phone in or near areas where explosive materials are used. Always obey local laws and turn off your phone when requested.



### **Emergency Calls**

- To make an emergency call your phone must be turned on and in an area where there's network coverage. Dial the national emergency number and press 'send'. Explain exactly where you are and don't hang up until help has arrived.



### **Working Temperature**

- The working temperature for the phone is between 0 Degree and 40 Degree Celsius. Please don't use the phone outside the range. Using the phone under too high or too low temperature might cause problems.



- At very high volume, prolonged listening to a mobile phone can damage your

hearing.

## Understanding your Phone

### Your Phone



### Description Icons

Keys	Functions
------	-----------

Home	●Press this button to return home from any application or interface.
Menu	●Press it to open recently opened application window
Back	●Press it to return to the previous interface , or to close dialog box ,options, menu notification panel or the keypad.
Power	●Press it to open the phone's menu , then you could choose to restartphone or turn off the phone
Up	●Press it to increase the volume
Down	●Press it to decrease the volume.

## Charging the battery

The rechargeable Li-ion battery that comes with your phone is ready to be used, but is not fully charged full. It is easy to do & can be done in 3 simple steps below:

1. Connect the charger to your phone, and plug it into a socket.
2. The battery indicator in the corner of the screen will scroll to show you it's charging.
3. When fully charged, the battery indicator will stop scrolling.
4. Disconnect the charger from your mobile and unplug.

## Power ON/OFF

Press the power key to power-ON/OFF the phone.

When you turn your phone on, it'll automatically check the SIM and show the following

information on the screen:

- Input SIM PIN: If you've set a PIN for your SIM.

**Note:**

The PIN is supplied with your SIM. Please replace it with your own PIN code as soon as possible.

Enter the wrong PIN three times, and your SIM will be locked. Then you'll need to contact your network service provider to ask for a PUK code to unlock it.

**Enter Main Menu**

- In Idle mode, press the Menu key to enter the main menu on the desktop and click the Home key/Back key to return.

**Enter Sub Menu**

- Once at the main menu, click the icon to select the sub menu, press Back Key to return to the previous menu, and press the Home Screen to return to the home screen.

**Use Notification Panel**

- As a new notification appears in the notification area, slide down in the area to view the contents of the notification.
- And slide down again, there is a shortcut of some functions, about brightness level Bluetooth Airplane mode Auto-rotate Flashlight Location Do not disturb Wi-Fi and many more

**Move icons on the main interface**

1. Long-press the icon on the main interface until it's enlarged and the mobile.
2. Drag the icon to the desired position and then release it.

**Delete icons on the main interface**



1. Long-press the icon on the main interface until it's enlarged and the mobile.
2. Drag the icon to "Remove" to delete it.

## **Change wallpapers**

1. Long-press the desktop pop-up menu.
2. Choose WALLPAPERS to change wallpapers

## **Recent tasks**

- On any interface, press [menu]to access to the recent tasks interface, view all the recent tasks &touch one of them to enter this App.

## **Install APK through File Manager**

APK is a supported file format for the Android mobile operating system.

- Please copy the downloaded APK file into the SD card, and then insert the SD card into the phone.
- In Idle mode, click Main Menu to enter the main menu.  
Click "File Manager" to enter the directory of SD card.
- Click the APK file you wish to install, and follow the installation wizard.

## **Using your Phone**

### **Main Menu & Its Functions**

- Scroll up the screen to enter the main menu.
- Allows you to view a list of features available in your phone.

### **Chrome browse**

- Browse the internet. The search engine default set as Google.

### **Calculator**

- This function can turn your phone into a calculator; it can do some simple calculations.

## **Calendar**

- View the calendar & add events.

## **Camera**

- Allows you to click pictures& video anytime you want. The camera opens in capture mode. Frame your picture within the screen and hold the phone steady. Touch Camera button to capture. Continue to hold the camera steady for a second after you hear the shutter sound.
- Click the preview box to browse the picture, share (via a compatible application), edit a picture, or delete a picture

## **clock**

- After entering Clock, move right to set the Alarm.

## **Contacts**

- To see your list of Contacts.Access Contacts through this function.


## **Email**

- Set up a common email and manage your email

## **File Manager**

- You could install the files in APK format & also view your files.

## **FM Radio**

- In main menu, touch  to enter FM Radio interface, Through this program, you may listen to FM radio on the device, FM radio use the wired headset as an antenna to receive signals, before opening this program ,you can install the original equipment-headphones, when listening, you can switch it manually to speakers or the mode with wired headphones.

## Photos

- Allows you to view photos & videos in folders.

## Gmail

- Gmail is an easy-to-use email app that saves you time and keeps your messages safe. Get your messages instantly via push notifications, read and respond online & offline, find any message quickly and lots more.

## Messages

- Allow you to view messages sent & received as a thread.

## Music

- View the list of songs available in your phone. Your music files are classified according to the following four categories Artists, albums, songs and play lists. Touch one of these categories; you can view the list inside.


## Phone

- Allow you to make quick outgoing calls.

## Google Play

- Google Play is your entertainment unbound. It brings together all of the entertainment you love and helps you explore it in new ways, anytime, anywhere.

## Google

- In main menu, touch  to access Google Search, Enter keywords, you can search a target in All or Web or Apps or Contacts, the matched result will display below. You also can do voice search here.

## **Settings**

Modify settings under the following:

- Screen lock
- Add another email account
- Wi-Fi
- Bluetooth
- SIM cards
- Data Usage
- More
- Display
- Notifications
- Sound
- Apps
- Storage
- Battery
- Memory
- Users
- Location
- Security
- Accounts
- Google
- Language & input
- Backup&reset
- Date &time
- Accessibilty
- Printing
- Schedule power on/off
- About phone

## **SIM Toolkit**

- This service is provided by the operator. It provides many types of personalized message services.

## Sound Recorder

- Allows you to record sounds.


## Wi-Fi

- LOGIC L65E supports Wi-Fi which allows you to connect with a Wireless connection. This is useful for surfing the internet on phone.
- Enter the “Settings” interface & search WIRELESS & NETWORKS. Select the network you want to connect.

## Inputting Text

### Google Keyboard

- LOGIC L65E use Google Keyboard by default.



## Cut, Copy and Paste

- Touch and hold text content to bring up the magnifying glass, and then slide your

finger to move the insertion points. Then choose to cut, copy, or paste. It is very easy to copy text from web pages, email, or text messages.

## **Maintenance**

- Use a dry soft cloth to wipe general dirt.
- Do not use a hard cloth, benzene or thinner to wipe the phone, otherwise, the surface of the phone will be scratched or could even result in the fading of colour.

## **Taking Care of Your Device**

Your device is a product of superior design and craftsmanship and should be handled with care:

The following suggestions will help you protect your phone:

- Always keep the small parts of the phone away from children.
- Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that will rust electronic circuits. If your device does get wet, remove the battery and allow the device to dry completely before replacing it.
- Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.
- Do not store the device in high or cold temperatures. High temperatures can shorten the life of electronic devices and damage batteries.
- Do not attempt to open the device other than as instructed in this guide.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device.
- Only use a soft, clean, dry cloth to clean the surface of the device.
- Do not paint the device. Paint can clog the moving parts and prevent proper operation.
- Use indoor chargers.
- Google, Android, Google Play and other marks are trademarks of Google LLC.

## **FCC STATEMENT**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Relocate or reorient the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
  - Consult your local RadioShack store or an experienced radio/TV technician for help.
- Changes or modifications not expressly approved by RadioShack may cause interference and void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**SAR Information Statement**

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radiofrequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. \* Tests for SAR are conducted with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the



lower the power output. Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government-adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. The highest SAR value for this model phone when tested for use at the ear is 1.150W/Kg, and when worn on the body, as described in this user guide, is 0.478W/Kg(Body-worn measurements differ among phone models, depending upon available accessories and FCC requirements). The maximum scaled SAR in hotspot mode is 0.478 W/Kg. While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure. The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/fccid> after searching on FCC ID: O55651125. Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications Industry Association (CTIA) website at <http://www.wow-com>. \* In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

## **Body-worn Operation**

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 10mm must be maintained between the user's body and the handset, including the antenna. Third-party belt clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.

## **FAQ**


- **Q: Can I use two SIM cards in the LOGIC L65E?**

- **A:** Yes, the LOGIC L65E is a dual SIM phone, allowing you to use two SIM cards simultaneously.

- **Q: Is the LOGIC L65E waterproof?**

- **A:** No, the LOGIC L65E is not a waterproof model. Keep it away from water and liquids to prevent damage.

## Documents / Resources

	<a href="#">LOGIC L65E 4G Smart Phone [pdf]</a> User Guide L65E, L65E 4G Smart Phone, 4G Smart Phone, Smart Phone
---	--

## References

- [User Manual](#)

 4G Smart Phone, L65E, L65E 4G Smart Phone, Logic, Smart

 Logic Phone

---

## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

**Post Comment**

**Search:**

**Search**

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.