



logitech TP01 Wireless Mouse User Guide

[Home](#) » [Logitech](#) » logitech TP01 Wireless Mouse User Guide 

Contents

- [1 logitech TP01 Wireless Mouse](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 WHAT IN THE BOX](#)
- [5 USING INSTRUCTION](#)
- [6 CONNECTION](#)
- [7 Features](#)
- [8 FCC](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)



logitech TP01 Wireless Mouse



Specifications

- Left and right mouse buttons
- Scroll wheel Press the wheel down for middle button (function can vary by software application)
- On/Off slider switch
- Battery door release
- USB Nano-receiver storage

Product Usage Instructions

Setup

- **Step 1:** Make sure the mouse is powered on.
- **Step 2:** Securely plug the Nano receiver into a USB port on your computer. If the mouse is not working, try changing USB ports.
- **Step 3:** If the Nano receiver is plugged into a USB hub, try plugging it directly into a USB port on your computer.
- **Step 4:** Check the orientation of the battery inside the mouse.
- **Step 5:** If the mouse is still not working, try using it on a different surface. Remove any metallic objects between the mouse and the Nano receiver.
- **Step 6:** If you are using a tower PC, consider using a USB extender. Visit www.logitech.com/usbextender for more information.



Important Notes: Do not immerse the product in any liquid or expose it to heat or moisture. There are no serviceable parts.

Additional Compliance Information: To obtain additional information about other compliance-related matters, visit www.logitech.com/compliance.

WHAT IN THE BOX




USING INSTRUCTION




CONNECTION

3



Features


1. Left and right mouse buttons
2. Scroll wheel
3. Press the wheel down for middle button (function can vary by software application)
4. On/Off slider switch
5. Battery door release
6. USB Nano-receiver storage



Help with setup: Mouse is not working

1. Is the mouse powered on?
2. Is the Nano receiver securely plugged into a USB port? Try changing USB ports.
3. If the Nano receiver is plugged into a USB hub, try plugging it directly into a USB port on your computer.
4. Check the orientation of the battery inside the mouse.
5. Try a different surface. Remove metallic objects between the mouse and the Nano receiver.

6. Try moving the Nano receiver to a USB port closer to the mouse. If you are using a tower PC, go to www.logitech.com/usbextender for a USB extender.
7. For Windows® operating systems, reconnect the mouse with the Nano receiver by launching the Connect utility from www.logitech.com/connect_utility



Important ergonomic information. Long periods of repetitive motion using an improper set-up workspace, incorrect body position, and poor work habits may be associated with physical discomfort and injury to nerves, tendons, and muscles. If you feel pain, numbness, weakness, swelling, burning, cramping, or stiffness in your hands, wrists, arms, shoulders, neck, or back, see a qualified health professional. For more information, please read the Comfort Guidelines located on the Logitech® website at <http://www.logitech.com/comfort>, or on the Logitech® Software CD.

- Do not immerse the product in any liquid or expose it to heat or moisture. There are no serviceable parts.
- Class 1 LED products. The product contains Class 1 LED. Operating temperature between 5° C (41° F) to 40° C (104° F).

Additional compliance information. To obtain additional information about other compliance-related matters, go to <http://www.logitech.com/compliance>.

Battery warning! Risk of explosion or personal injury if batteries are replaced by incorrect type, mutilated, or exposed to conducting materials, liquid, fire, or heat (above 54° C or 130° F). Do not use or recharge damaged rechargeable batteries. Do not mix battery types. Dispose of spent or damaged batteries according to manufacturer instructions and local laws. UL statement. Your product is UL-approved. Use only with UL listed ITE computers.

FCC

FCC – United States and Canada

This hardware device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation. Compliance Information Statements:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

Modifications to this product not authorized by Logitech could void your right to use or operate this product by the FCC.

Where shielded interface cables or accessories have been provided with the product or specified additional components or accessories elsewhere defined to be used with the installation of the product, they must be used in order to ensure compliance with FCC regulations.

Canada (IC) Statements: Corded products: This Class B digital apparatus complies with Canadian ICES-003. Cordless (Radio Transmitter) products: Section A. RSS-310 (27 MHz transmitters and receivers): This Category II radio communication device complies with Industry Canada Standard RSS-310. Section B. RSS-210 (2.4 GHz transmitters or transceivers): This Category I radio communication device complies with RSS-210 of Industry Canada.

Logitech hardware product limited warranty

Logitech warrants to the original purchaser that your Logitech hardware product shall be free from defects in material and workmanship for the period of time, identified on your product package and/or contained in the user documentation, from the date of purchase. You may also find this information by selecting your product in the Online Support section of our website at www.logitech.com/support. Except where prohibited by applicable law, this warranty is nontransferable and is limited to the original purchaser. This warranty gives you specific legal rights, and you may also have other rights that vary under local laws.

Remedies. Logitech's entire liability and your exclusive remedy for any breach of warranty shall be, at Logitech's option, (1) to repair or replace the hardware, or (2) to refund the price paid, provided that the hardware is returned to the point of purchase or such other place as Logitech may direct with a copy of the sales receipt or dated itemized receipt. Shipping and handling charges may apply, except where prohibited by applicable law. Logitech may, at its option, use new or refurbished or used parts in good working condition to repair or replace any hardware product. Any replacement hardware product will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer or for any additional period of time that may be applicable in your jurisdiction.

This warranty does not cover problems or damage resulting from (1) accident, abuse, misapplication, or any unauthorized repair, modification or disassembly; (2) improper operation or maintenance, usage not under product instructions or connection to improper voltage supply; or (3) use of consumables, such as replacement batteries, not supplied by Logitech except where such restriction is prohibited by applicable law.

How to obtain warranty support. Before submitting a warranty claim, we recommend you visit the support section at www.logitech.com/support for technical assistance. Valid warranty claims are generally processed through the point of purchase during the first thirty (30) days after purchase; however, this time may vary depending on where you purchased your product – please check with Logitech or the retailer where you purchased your product for details.

Warranty claims that cannot be processed through the point of purchase and any other product-related questions should be addressed directly to Logitech. The addresses and customer service contact information for Logitech can be found in the documentation accompanying your product and on the web at www.logitech.com/support.

Limitation of liability. LOGITECH SHALL NOT BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES WHATSOEVER, INCLUDING BUT NOT LIMITED TO LOSS OF PROFITS, REVENUE OR DATA (WHETHER DIRECT OR INDIRECT) OR COMMERCIAL LOSS FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON YOUR PRODUCT EVEN IF LOGITECH HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Duration of implied warranties. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THIS HARDWARE PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THE APPLICABLE LIMITED WARRANTY PERIOD FOR YOUR PRODUCT. Additional Rights. Some states do not allow limitations on how long an implied warranty lasts, or allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from State to State or by country or other jurisdiction.

- **National Statutory Rights.** Consumers have legal rights under applicable national legislation governing the sale of consumer goods. Such rights are not affected by the warranties in this Limited Warranty.
- **No Other Warranties.** No Logitech dealer, agent, or employee is authorized to make any modification, extension, or addition to this warranty.
- **Warranty Periods.** Please note that in the European Union, any warranty period less than two years shall be increased to two years.
- **Logitech address.** Logitech, Inc. 6505 Kaiser Drive, Fremont, California 94555

MORE INFORMATION

What do you think?

Please take a minute to tell us. Thank you for purchasing our product.

- **United States** +1 646-454-3200
- **Argentina** +00800-555-3284
- **Canada** +1 866-934-5644
- **Brazil** +0 800-891-4173
- **Chile** 1230 020 5484
- **Latin America** +1 800-578-9619
- **Mexico** 001 800 578 9619
- **FMIN:** C-U0007
- **Rating:** 5V 100mA
- **FCC D:** JNZCU0007
- **IC:** 4418A-CU0007


MADE IN CHINA

© 2011 Logitech. All rights reserved. Logitech, the Logitech logo, and other Logitech marks are owned by Logitech and may be registered. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.





www.logitech.com

www.logitech.com/ithink

Documents / Resources

	<p>logitech TP01 Wireless Mouse [pdf] User Guide TP01, TP01 Wireless Mouse, Wireless Mouse, Mouse</p>
---	---

References

-  [Logitech | Official Online Store](#)
-  [Logitech | Official Online Store](#)
-  [Compliance Certification Search | Logitech](#)
-  [Logitech Customer Support & Business Support](#)
- [User Manual](#)