


logitech VR0032 Video Conferencing Camera and Remote Control User Manual

[Home](#) » [Logitech](#) » logitech VR0032 Video Conferencing Camera and Remote Control User Manual 




logitech VR0032 Video Conferencing Camera and Remote Control



Contents


- [1 In The Box](#)
- [2 PRODUCT OVERVIEW](#)
- [3 GETTING STARTED](#)
- [4 USE WITH THE MEVO APP](#)
- [5 USE AS WIRED CONNECTION](#)
- [6 FCC statement](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)
- [8 Related Posts](#)

In The Box



PRODUCT OVERVIEW

1. Built in Microphones | Built in Microphones
2. Tally Lights (x2) | Tally Lights (x2)
3. Micro Four Thirds Lens Mount | Micro Four Thirds Lens Mount
4. Body Cap | Body Cap
5. Lens Release Button | Lens Release Button
6. 1/4"-20 Mounting Points (x4) | 1/4"-20 Mounting Points (x4)



7. Power Button with 4 LEDs for Battery Status Power Button with 4 LEDs for Battery Status

8. USB-C Ports

Charging Ports (up to 20W) Power Out (5V/500mA) USB Audio In Ethernet In (requires adapter sold separately)

USB-C Ports

Charging Ports (up to 20W) Power Out (5V/500mA) USB Audio In Ethernet In (requires adapter sold separately)

9. USB-C Ports

Wired Webcam (up to 4k 30fps)

USB-C Ports

Wired Webcam (up to 4k 30fps)

10. 3.5mm Audio In TRS

3.5mm Audio In TRS

11. Reset Button


Reset Button

12. MicroSD Card Slot

MicroSD Card Slot

13. HDMI Output


HDMI Output




More info here:
More info here:

GETTING STARTED


Remove the attached body cap.
Remove the attached body cap.



Align the dot on your lens with the alignment dot on Stratos.
Align the dot on your lens with the alignment dot on Stratos.



Push gently the lens against the camera body and turn it clockwise until the lens locks into place.
Push gently the lens against the camera body and turn it clockwise until the lens locks into place.



Don't have a lens yet?

Learn about which lens we recommend for different use cases here:

logitech.com/supported-lenses

Don't have a lens yet?


Learn about which lens we recommend for different use cases here:

logitech.com/supported-lenses




USE WITH THE MEVO APP

Connect Stratos to power, using the provided cable and plugging it in one of the two USB-ports.
Connect Stratos to power, using the provided cable and plugging it in one of the two USB-ports.




Turn on Stratos, by holding down the power button for 3 seconds.
Turn on Stratos, by holding down the power button for 3 seconds.




Download the Mevo Multicam app on your tablet or smartphone.
Download the Mevo Multicam app on your tablet or smartphone.



www.logitech.com/get-mevo-app




Open the Memo Multicar app and follow the instructions on your screen.
Open the Memo Multicar app and follow the instructions on your screen




USE AS WIRED CONNECTION


Turn on Stratos, by holding down the power button for 3 seconds.
Turn on Stratos, by holding down the power button for 3 seconds.



Do a quick double press on the power button. A chime will inform you Stratos is now in wired webcam mode.
Do a quick double press on the power button. A chime will inform you Stratos is now in wired webcam mode.



Connect Stratos to your computer with the provided cable, using the USB-C port with the monitor icon.
Connect Stratos to your computer with the provided cable, using the USB-C port with the monitor icon.



To control your camera from your computer, download the Logitech desktop app: www.logitech.com/download
To control your camera from your computer, download the Logitech desktop app:
www.logitech.com/download





Looking for a tutorial, need additional product information, or more? Visit:

logitech.com/stratos/howtos

Looking for a tutorial, need additional product information, or more? Visit:

logitech.com/stratos/howtos

©2023 Logitech. Logitech, Logitech G, Logi and their respective logos are trademarks or registered trademarks of Logitech Europe S.A. and/or its affiliates in the U.S. and other countries. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

©2023 Logitech. Logitech, Logitech G, Logi and their respective logos are trademarks or registered trademarks of Logitech Europe S.A. and/or its affiliates in the U.S. and other countries. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

620-012123 00B

Important Safety, Compliance and Warranty Information

Read Manual Before Product Use.



This product is intended to be supplied by a Listed/Certified power supply, rated 5-9V d.c. , 2A max , Tma (maximum ambient temperature) 35 degree C and altitude 2000 m. If needed, please contact the Manufacturer for further information.

BATTERY WARNING! Improperly replaced batteries may present a risk of leak or explosion and personal injury. Risk of fire or explosion if the battery is replaced by an incorrect type. Ensure batteries are installed correctly by following the instructions provided. Mistreated rechargeable batteries may present a risk of fire or chemical burn. Do not disassemble or expose to conducting materials, moisture, liquid, or heat above 54° C (130° F). A battery subjected to extremely low air pressure may result in an explosion or the leakage of flammable liquid or gas. Do not use or charge the battery if it appears to be leaking, discolored, deformed, or in any way abnormal. Do not leave your battery discharged or unused for extended periods. Do not short circuit. Your device may contain an internal, rechargeable battery that is not replaceable. Battery life varies with usage. Non-operational batteries should be discarded according to local laws. If no laws or regulations govern, dispose of your device in a waste bin for electronics. Keep batteries away from children.

Safe Usage Guidelines for Products

- Do not open or modify the product except for battery removal and replacement.
- Do not disassemble or attempt to service this product.
- Use the product with listed/certified ITE computers and accessories.
- Connect power supply or power cord to a properly wired and grounded electrical outlet.
- This product is safe under normal and reasonably foreseeable operating conditions.
- If product is operating improperly, please contact Logitech support.
- Product must be returned to the manufacturer for any service or repair.
- This is not a Children's Product and is not intended for use by children under 14 years old.

Logitech Compliance. The product complies with all applicable requirements for Restriction of Hazardous Substances (RoHS) and Waste Electronic and Electrical Equipment (WEEE). For Product Safety, EMC, RF, Energy, RoHS and WEEE information, go to www.logitech.com/compliance. Maintenance is not required for product compliance.



Packaging, batteries, electronic and electrical equipment and their accessories should not be disposed of with household waste.

Wherever possible, they should be segregated and brought to an appropriate collection point to enable recycling and avoid potential impacts on the environment and human health. For more information, contact your local authorities or place of purchase, or visit www.logitech.com/recycling.

FCC statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy. And, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Where shielded interface cables or accessories have been provided with the product or specified additional components or accessories elsewhere defined to be used with the installation of the product, they must be used in order to ensure compliance with FCC. Changes or modifications to product not expressly approved by Logitech, Inc could void your right to use or operate your product by the FCC.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. Operation of transmitters in the 5.925-7.125 GHz band is prohibited for control of or communications with unmanned aircraft systems.

Radiation Exposure Statement:

This equipment complies with FCC and IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

IC statement : CAN ICES3(B)/NMB3(B)

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Caution: (i) the device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems; (ii) high-power radars are allocated as primary users (i.e. priority users) of the bands 5250-5350 MHz and 5650-5850 MHz and that these radars could cause interference and/or damage to LE-LAN devices.

Logitech Limited Hardware Product Warranty – A Summary

Logitech warrants that its hardware product shall be free from defects in materials and workmanship for the length of time identified on your product package beginning from the date of the original retail purchase. See support.logitech.com for specific warranty information about your product and procedures to act on a warranty claim.


Logitech’s entire liability and your exclusive remedy for any breach of warranty shall be, at Logitech’s option, to repair or replace a functional equivalent of the product, or to refund the price paid, if the hardware is returned to the point of purchase or such other place as Logitech may direct along with a receipt. Warranty protections are in addition to rights provided under local consumer laws and may vary among countries. See full warranty information to know your consumer rights and the additional protections provided by this product warranty. Logitech Address: Logitech, Inc., 3930 North First Street, San Jose, California 95134.

Full Warranty Information: support.logitech.com

© 2023 Logitech. Logitech, Logitech G, Logi and their respective logos are trademarks or registered trademarks of Logitech Europe S.A. and/or its affiliates in the U.S. and other countries. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.



Documents / Resources

	Logitech VR0032 Video Conferencing Camera and Remote Control [pdf] User Manual VR0032 Video Conferencing Camera and Remote Control, VR0032, Video Conferencing Camera and Remote Control, Conferencing Camera and Remote Control, Camera and Remote Control, Remote Control
---	---

References

- [Logitech Support + Download](#)
- [Logitech Suporte + Download](#)
- [Logitech Support + Download](#)
- [Product Compliance Certification Search | Logitech](#)
- [Logi Options+ \(Plus\): Customization App for Logitech Devices](#)
- [Get Mevo Apps | Wireless Live Streaming for iOS and Android](#)
- [Global Recycling Program for Ewaste and Batteries - Logitech](#)
- [User Manual](#)

Manuals+. Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.