

looirobot 2BLAY-01 Smartphone into a Desktop Robot User Manual

Home » looirobot » looirobot 2BLAY-01 Smartphone into a Desktop Robot User Manual



Contents

- 1 looirobot 2BLAY-01 Smartphone into a Desktop Robot
- 2 Quick Start Guide
- 3 Include in the box
- 4 Fun to play LOOI
- **5 CAUTION**
- 6 Specification
- **7 Warranty Policy**
- 8 FCC Warning
- 9 Specifications
- 10 FAQ
 - 10.1 Q: What should I do if my LOOI Robot is not
 - responding?
 - 10.2 Q: How do I charge my LOOI Robot?
 - 10.3 Q: Is the LOOI Robot covered under warranty?
- 11 Documents / Resources
 - 11.1 References
- **12 Related Posts**

looirobot 2BLAY-01 Smartphone into a Desktop Robot




USER MANUAL

The LOOI Robot is a fun and interactive device that can be controlled using the LOOI App on your mobile device. It features a USB C port for charging and a 15W Wireless Charger for convenient charging.

Quick Start Guide

1. Download LOOI App on your mobile device and register an App account.

You need to install the LOOI APP and register a LOOI APP account to experience the endless fun brought by LOOI products.




2. Tap the front button to activate the device (as shown).




3. Attach your phone to the device to officially activate your LOOI Robot.



Include in the box



- LOOI x1
- USB C Cable x1
- LOOI x1
- USB C Cable x1
- Decking Ring x1
- User Manual x1
- LOOI Card x1 Fun



CAUTION

Please follow the cautions below as there may be a risk of overheat, fire or explosion.

- Lithium ion battery is built into the product.
- · Avoid dropping.
- Charge the product with a 5V/2A adapter;
- Do not place the product in or near fire, such as near a fireplace, or put the product in a microwave. / Keep your device away from radiators and heat sources.
- Do not leave the product in hot weather.
- Do not use your equipment in a wet environment, for example, near a bath tub, sink, or swimming pool or in a wet basement.
- Do not disassemble, crush or pierce the product.

- The maximum ambient temperature during use of this product must not Exceed 40°C.
- · Keep the product dry. Do not spill food or liquids on your equipment
- Dispose of the product appropriately.

Specification



• Weight: 0.85lbs (384g)

• Sensors: 3D ToF(Time of Flight) Sensor; Touch Sensors; Obstacle Sensor; Cliff Sensors.

Battery: 6000 mAh rechargeable battery

• Charging: USB C port

15W Wireless Charger

Charging Input: 5V2A 9V2A Wireless Output: 15W Max

Warranty Policy

We offer a comprehensive one year warranty that begins on the date of purchase.

Our warranty covers any non human induced repairs and includes expert guidance and assistance for any inquiries you may have during the warranty period. Please be aware that the warranty duration compl ies with the consumer laws applicable in the country where the product is purchased.

To learn more visit looirobot.com

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy

and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Specifications

- · USB C port
- 15W Wireless Charger Charging Input Wireless Output
- 5V2A 9V2A 15W Max

FAQ

Q: What should I do if my LOOI Robot is not responding?

A: If your LOOI Robot is not responding, try resetting the device by turning it off and on again. Make sure the device is charged and properly connected to your phone.

Q: How do I charge my LOOI Robot?

A: Use the provided USB C cable to connect the robot to a power source or use the 15W Wireless Charger for wireless charging.

Q: Is the LOOI Robot covered under warranty?

A: Yes, the LOOI Robot comes with a one-year warranty that covers non-human-induced repairs. For more information on the warranty policy, visit looirobot.com.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

— Reorient or relocate the receiving antenna. — Increase the separation between the equipment and receiver. — Connect the equipment into an outlet on a circuit

different from that to which the receiver is connected. — Consult the dealer or an experienced radio/TV technician for help. To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.

Documents / Resources



<u>looirobot 2BLAY-01 Smartphone into a Desktop Robot</u> [pdf] User Manual 2BLAY-01, 2BLAY-01 Smartphone into a Desktop Robot, 2BLAY-01, Smartphone into a Desktop Robot, into a Desktop Robot, Robot

References

- LOOI Robot: Turn Your Smartphone into a Desktop Robot!
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.