Manuals+ — User Manuals Simplified.

LUTRON Dimmer and Switch App User Guide

Contents

LUTRON Dimmer and Switch App

USER GUIDE

Firmware updates are important to ensure you have access to the latest features of the Caséta system. To use the Pico paddle remote in a Caséta system with basic on/off control, a firmware update is not required; however an update may be necessary to unlock the exclusive 3-way control when paired with a Diva smart dimmer.
Learn more about the firmware update requirements and process below.

## Do You Need to Update Your Existing Caséta Device(s)?

A firmware update is not required when initially pairing a Pico paddle remote with:

- A Diva smart dimmer that came in the same package
- Any other Caséta device

In other cases, a firmware update may be required.

Caséta Firmware Update Process

1. Open the Lutron App and select Settings (gear icon)

2. Select Firmware Update (If an update is available, a red dot will be present)

3. Select the devices to be updated and click on the Update button

4. A prompt will appear when upgrade is complete – you are now able to access your system

What to Know During the Update

1. The app can be closed
2. System performance may be impacted (including existing schedules, scenes, and Pico remotes)
3. No additional devices can be added to your system
4. Updates typically take 10-15 minutes per device

If you have additional questions about the firmware process, visit **Lutron.com/firmware**.

Specifications:

- Product Name: Pico Paddle Remote
- Manufacturer: Lutron
- Compatibility: Works with Lutron systems

Product Usage Instructions

Initial Pairing:

1. Ensure a firmware update is not required for initial pairing.
2. Open the Lutron App and select Settings (gear icon).
3. Select the Pico Paddle Remote to pair.
4. Follow on-screen instructions to complete the pairing process.

Firmware Update:

1. If a firmware update is required, follow these steps:

2. Open the Lutron App and select Settings (gear icon).

3. Select Firmware Update (If an update is available, a red dot will be present).

4. Select the devices to be updated and click on the Update button.

During the Update:

- The app can be closed during the update process.
- System performance may be impacted, including existing
  schedules, scenes, and Pico remotes.
- No additional devices can be added to your system during the update.
- Updates typically take 10-15 minutes per device.

If you have additional questions about the firmware process, visit **Lutron.com/firmware**.

FAQ

Q: Do I need to update the firmware every time I pair a new Pico Paddle Remote?

A: A firmware update is not required when initially pairing a Pico paddle remote. However, in some cases, a firmware update may be necessary. Follow the provided instructions if an update is needed.

Documents / Resources

LUTRON Dimmer and Switch App [pdf] User Guide
PJ2P2BGWH, PJ2-P2B-GWH, Dimmer and Switch App, App, Dimmer and Switch, Switch, Dimmer

References

- **How to update Caséta Hub (formerly known as Bridge) or RA2 Select Firmware | Lutron**
- **User Manual**