


Manual

Find My device



Quick instructions

1. Turn on the device
Press and hold the button for 5 seconds, the device will beep and turn on.
2. Pair the device
·Open the Find My app.
·Hold the device close to your iPhone, tap the Items tab, tap + and then Add Other Item.
·Tap Connect.
·Type a name for your device, select an emoji.
·Tap Agree to acknowledge that this item will be linked to your Apple ID.
·Tap Finish.

3. Enable Lost Mode
·Open the Find My app, tap the Items tab, then tap your item.
·Under Lost Mode, tap Enable.
·Read the instructions, tap Continue and enter a phone number or email address.
·Confirm the information, customize the lost message, and tap Activate to complete the setup.

4. Remove the device
·Open the Find My app, tap the Items tab, then tap your item.
·Tap Remove Item and then tap Remove to complete the operation.

Note: After removing the device in the app, the device will beep

and the light will flash six times, it will not shut down and will be in the pairing mode. If there is no re-pairing within 10 minutes, the device will leave the pairing state, and the device and app cannot be paired at this time. If you need to pair the device, you need to click the device button once, the device will ring and the light will flash once. At this point, the device enters the pairing state and can be re-paired with the app.

Main Functions

1. Locate your item
If your missing item isn't nearby, the Find My app can still help you track it down using the Find My network-hundreds of millions of iPhone, iPad, and Mac devices around the world. Nearby devices securely send the location of your missing device to iCloud, then you can see where it is in the Find My app. It's all anonymous and encrypted to protect everyone's privacy.

2. Play Sound
·Open the Find My app, tap the Items tab, then tap your item.
·Click Play Sound, and the device will beep, so you can find the item easily.

Instructions for device button

1. Power on
After installing the battery, long press the button for five

seconds, the device will beep, the light will flash three times, and the device will be turned on.

2. Device status confirmation
Double-click the device button, the device will beep, and the light will flash three times, indicating that the device is working. If the device does not ring, the device is off. Long press the button for five seconds to turn it on.

3. The device enters the pairing state again
After removing the device in the app, the device will beep and the light will flash six times, it will not shut down and will be in the pairing mode. If there is no re-pairing within 10 minutes, the device will leave the pairing state. If you want to pair a device at this time, you need to click the device button once, the device will beep, and the light will flash once. At this time, the device enters the pairing state and can be paired with the app again.

4. Factory Reset
First, remove the item from Find My app then, after the device is powered on, double-click the device button. The device will beep. Long press the device button for eight seconds until the device beeps and the light flashes three times. Release the button to complete factory reset. The device can now be paired.

5. Power off
When the device is on, press the device button 5 times in 2 seconds. The device will beep, the light will flash three times, the device will be powered off.

FAQ:

1. When can the device be located?
When an item is separated from its owner for a period of time, it can be found by other Apple devices that are part of the Find My network, and the owner can start to get the location of the device.
2. How to confirm whether the device has been turned on?
Double-click the device button, the device will beep, and the light will flash three times, indicating that the device is working. If the device does not ring, the device is off. Long press the button for five seconds to turn it on.
3. How is the device designed to discourage unwanted tracking?
if any Find My network accessory separated from its owner is seen moving with you over time, you'll be notified in one of two ways:

- a. if you have an iPhone, iPad, or iPod touch, Find My will send a notification to your Apple device. This feature is available on iOS or iPadOS 14.5 or later.
- b. if you don't have an iOS device or a smartphone, a Find My network accessory that isn't with its owner for a period of time will emit a sound when it's moved. These features were created specically to discourage people from trying to track you without your knowledge

4. How is my privacy protected?
Only you can see where your item is. Your location data and history are never stored on the item itself. Devices that relay the location of your item also stay anonymous, and that location data is encrypted every step of the way. So not even Apple or Findale knows the location of your device or the identity of the device that helps find it.

5. Battery Specifications
Replaceable battery capacity: 3.7V-130mAh

6. Wireless charging instructions:
 - a. There is a wireless charging location sign on the front of the device, which corresponds to the center of the wireless charger.
 - b. The LED light will come on when the device is charging and the device will beep once.
 - c. In general, when there is no electricity, it can be fully charged within 45 minutes.

7. What is the Find My network? And how does it work?
The Apple Find My network provides an easy, secure way to locate compatible personal items on a map using the Find My app on your iPhone, iPad, ipod touch, Mac, or the Find Items app on Apple Watch. Simply pair your compatible product with the Apple Find My app to view it right alongside your Apple devices. If your item ever goes missing, you can put it in Lost Mode to display a message and contact information to anyone who might find it. The Find My



network is encrypted and anonymous, so no one else, not even Apple, can view its location.

European Union-Disposal Information

The symbol above means that according to local laws and regulations your product and/or its battery shall be disposed of separately from household waste. When this product reaches its end of life, take it to a collection point designated by local authorities. The separate collection and recycling of your product and/or its battery at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.



Regulatory Safety Information

WARNING:

KEEP BATTERIES OUT OF REACH OF CHILDREN
Swallowing may lead to serious injury in as little as 2 hours or death, due to chemical burns and potential perforation of the oesophagus.
If you suspect your child has swallowed or inserted a button battery immediately call the 24-hour Poison Information Centre for fast expert advice.

Legal Notice:

The Apple Find My device provides an easy, secure way to locate Find My device using the Find My app on your iPhone, iPad, Mac, or the Find Items app on Apple Watch.

To use the Apple Find My app to locate Find My device, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOS.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are the trademarks of Apple Inc. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

Introduction

Simple Description of Button Operation

Turn on:
press and hold the button for five seconds.

Turn off:
press the device button 5 times in 2 seconds,

Device status confirmation:
Double-click the device button.

Factory Reset: double-click the button, then press and hold the device button for 8 seconds.

For detailed operation, please refer to Instructions for device operation in the manual.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

