




# Vanity Table Manual 85023







Ax1




Bx1




Cx1




Dx1




Ex1




Fx1




Gx2




Hx2




Ix2




Jx1




Kx3




Lx3




Mx3




Nx3




Ox2




Px1





















Qx1




Rx3



1


①		Two In One Screw (6x28mm)	60pcs +2pcs
②		Two In One Nut (10x12mm)	60pcs +2pcs
③		Wood Chipping (6x30mm)	8pcs +2pcs
④		Guide & Screw (3x12mm)	24pcs +6pcs 6pcs
⑤		Small Non-slip pads	6pcs +2pcs
⑥		Backboard Card Strip (774mm)	1pcs
⑦		Fixing Clip & Screw (3x16mm)	8pcs +1pcs
⑧		Screw (6x28mm)	7pcs
⑨		Corner Code & Screw (3.5x12mm)	8pcs +1pcs 2pcs
⑩		Big Non-slip pads	1pcs
Anti tipping hardware			
⑪	 x1  (3.5x12mm) x1  x2  (4x45mm) x1  x1		
	AC/DC Adapter (12V=3.0A)	1pcs	
	1pcs	 Double-head screwdriver, use as required	
			2

# Product structure decomposition






1		36pcs	2		36pcs
4		6pcs 12pcs			




# Use parts ① and ②



Step1




Step2



Step3





Use a screwdriver to lock in the direction of the "+" sign




Disassemble along the direction of "-" sign

Step 1




①  x6



## Step 2





## Step 3




## Step 4



## Step 5




# Drawer rail breakdown diagram




Step 1 : Pull the rails apart

Step 2 : Push the nylon buckle outward (a)



(b)

(c)




(a)


(b)

(c)

## Step 6




④





x4

(a)



x2




8

## Step 7

1

x6




## Step 8


2





x6



## Step 9



## Step 10





## Step 11

②



x6




## Step 12

⑤






x4

a








x2



11












- |   |   |     |
|---|---|-----|
| ① |  | x24 |
| ② |  | x24 |
| a |  | x4  |
| ④ |  | x8  |





**x2**

Repeat the drawer installation steps


1		24pcs	2		24pcs
3		8pcs	4	 	6pcs 18pcs
5		6pcs	6		1pcs
7		8pcs			






## Step 13





## Step 14



## Step 15




## Step 16




This hole is a reinforced fixing hole which can be installed as required

## Step 17





## Step 18




This hole is a reinforced fixing hole which can be installed as required


## Step 19




①  x8

③  x2

## Step 20



②  x3





## Step 21

2



x5





## Step 22



3





x2



## Step 23



## Step 24







## Step 25

⑤




x6




⑤

Tear off release paper and stick the black foot pad on the board




## Step 26






Place the "O" board, Backboard card strip, and "O" board in order



## Step 27



## Step 28




## Step 29


2



x6








## Step 30



As shown, When installing the drawer, pull the guide rail out first, Slide beads are also pulled out.


## Step 31





If a large gap is found after installing the drawer the slide rail can be moved up and down to adjust the gap









## Step 32


7



x8



8		7pcs	9		2pcs 8pcs
10		1pcs	11		1pcs 1pcs
		1pcs			2pcs
					1pcs
					1pcs





## Step 33



Choose Plan "A" or Plan "B" as needed

8





x4


Plan "A"



Plan "B"







## Step 34




Height can be adjusted under the hardware foot to avoid imbalance


## Step 35



## Step 36





Choose installation as needed





Install anti rewind tape at the edge of the board to prevent insufficient length when connecting to the wall

## Step 37

Choose installation as needed




# wall




Step 38

8



x3





## Step 39

10




x1



10


Tear off release paper and stick the black foot pad on the board

## Step 40







## Step 41



x1





## User's Guide

Thank you for purchasing this product.

To use this product, please plug it into a 12V DC power supply.

Please use if the product works normally after connecting to power.

## Introduction

The box is an intelligent controller. It has 1 USB port and 1 type-C port and can distribute the current output up to 5V DC-2A. With 2 touch buttons, it can turn ON/OFF the light, change light colors, and adjust the light luminance.

## Operation




This touch button is used to turn on/off, change colors, and adjust brightness.

- A. Short touch -> lighting on -> short touch -> change light color -> short touch -> change light color -> short touch -> lighting off.
- B. Long touch -> adjust the luminance.



This touch button is used to turn on/off the induction function.

- A. Short touch to turn on the induction function. It can auto-turn on the light when people are close to the controller in 1 meters. It can auto power off the light when the body is far away from the controller after 30 seconds.
- B. Long touch to turn off the induction function.
- C. Note: When you touch the light button to change the light modes, the induction function will automatically turn off. It is best to turn on this function after selecting the light color and adjusting the brightness you want.



This range is a wireless charging area, and only mobile phones with wireless charging function can be charged.

Consumer Reminder: Important Notice for Wireless Charging Use

1, Phone-Only Wireless Charging: This device supports wireless charging for mobile phones only. Attempting to charge other electronic devices may result in danger.

2, Metal Warning: Ensure that no metal objects are placed between your phone and the wireless charger (this includes magnetic or metal phone cases).

If there are metal objects can interfere with charging or cause hazardous conditions.



## ATTENTION PLEASE

1. If there is no touch response suddenly, Re-plug the power to reset the touch static electricity.
2. If bubbles appear on the panel, remove the protective film.
3. If you have any questions when installing, please feel free to contact us. Thank you.