

VEVOR[®]

TOUGH TOOLS, HALF PRICE


Support and E-Warranty Certificate

<https://www.vevor.com/support>

ICE MAKER INSTRUCTION MANUAL

We continue to be committed to offering tools at competitive prices. "Save Half", "Half Price", or any other similar expressions used by us only represent an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and do not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when placing an order with us if you are saving half in comparison with the top major brands.

SKF-S25J



NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us:



CustomerService@vevor.com

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

READ ALL INSTRUCTIONS BEFORE USING

IMPORTANT SAFETY INFORMATION:



WARNING: Read all safety warnings, instructions, illustrations and specifications provided with this electric appliance. Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury.

Save all warnings and instructions for future reference.

SAFETY INFORMATION



This is the safety alert symbol. This symbol alerts you to potential hazards that can kill or hurt you and others. All safety messages will follow the safety alert symbol and the word “WARNING” or “CAUTION”. **These words are defined as:**



WARNING

Indicates a hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION

Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.



CAUTION

ICE CAN'T BE STORED IN THE ICE BIN DURING NIGHT TIME, IT'S NOT FRIDGE, ICE WILL BE MELTED INTO WATER AND FLOW OUT OF THE MACHINE.



WARNING

To reduce the risk of fire, explosion, electric shock, exposure to UV radiation, or injury when using your ice maker, follow these basic safety precautions:

- This product must be properly installed and located in accordance with the installation instructions before it is used.

- When using electrical appliances, basic safety precautions should be followed to reduce the risk of fire, electric shock and injury to persons or property. Read all instructions before using any appliance.
- High humidity environment will increase the risk of short circuit or electric shock. If in doubt, please cut off the power supply of the ice maker.
- Do not exceed power outlet ratings. It is recommended that the ice maker is connected to its own circuit. Use only standard electrical supply that is properly grounded in accordance with the National Electric Code and local codes and ordinances.
- If the ice maker is brought indoors from outdoors during the wintertime, give it a few hours to warm up to room temperature before plugging to power source.
- Do not store explosives, such as combustion-supporting sprays in the appliance.
- The machine is intended to be used in household and similar applications such as:
 - kitchen areas in shops,offices and other working environments;
 - farm houses;
 - by clients in hotels,motels and other residential type environments;
 - Catering industry and similar non-retail industry.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Avoid direct sunlight and make sure that the machine should be used in the household and without obstacles surrounded, good ventilation place. There is must be 50cm at least between the four sides of the machine with the wall.
- Do not tip the machine over.
- We do not recommend the use of an extension cord, as it may overheat and become a risk of fire.
- Don't use any liquid other than water in the unit to make the ice.
- Do not store or use flammable vapors or liquids near this product.
- Do not allow children to climb, stand or hang on the ice maker. They could seriously injure themselves.
- Do not use with water that is microbiologically unsafe or of unknown quality.
- To avoid risk of injury, place power cord in such a way it cannot be pulled on by children or cause a tripping hazard.


- Place power cord in such a way that it is not in contact with hot surfaces.
- Do not operate if any component, including the cord or plug, is damaged.
- Unplug the product before cleaning or repairing, and when not in use. (Note: If the machine needs repair, it is strongly recommended that it be operated by professionals. Type Y attachment: If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.)
- Do not immerse any part of the product in water.
- Do not plug or unplug product with wet hands.
- Do not place the power cord on carpet or other heat sources.
- Do not attempt to disassemble, repair, modify, or replace any part of your product.
- Use this product only for its intended purpose as described in this user manual.
- If the power cord is damaged, it must be replaced by the manufacturer or similar professionals in order to avoid danger.
- Do not use any accessories not recommended by the manufacturer.
- The foaming materials inside is combustible which must be kept away from fire.
- It's forbidden to pull the cable to unplug the plug, pull the plug is a must.
- Except for the method recommended by the manufacturer, no mechanical tools or other methods shall be used to accelerate the defrosting process. Do not damage the refrigeration circuit.
- There are high-pressure, flammable and explosive refrigerants in the compressor. Do not damage the refrigeration system. Care or repair should be carried out by professionals. Be especially careful when installing and transporting.
- There are heat insulation materials in the ice maker, which are combustible materials, and must be kept away from fire sources. Repairs must be carried out by the manufacturer or professionals. Scrap must be disposed of by the designated recycling department.


Product specifications:

Model No	SKF-S25J
Rated Voltage	AC120V 60Hz
Input Power	350W
Rated Current	3A

Ice Production	62lbs/day
Ice Basket Capacity	5lbs
Refrigerating	R290/24g
Shock Protection Type	I
Foam Material	Cyclopentane


Quick introduction:





Installation and setup

Caution: Installation must be installed by professionals.



Warning:

The drain of inner tank must be always connected to a floor drain.

The drain of internal water tank (Only connect to a floor drain after cleaning, or it must be plugged).


Installation requirements




Lifting Hazard: It is recommended to have two people move and install the ice maker in order to prevent injury.

Product is designed to be installed indoors. Do not use your ice maker outdoors.

- Product must be installed upright on a flat, level surface that is able to support the total weight when full of water.
- Ensure a minimum of 50cm clearance around the side and back walls of the ice maker for proper air circulation.
- Install the product in a well-ventilated area with an ambient temperature between 3°C and 40°C.
- Do not place the product near heat sources such as ovens or cook tops.
- Do not place the product in direct sunlight or rain.
- Do not place any stuff on the top of the machine.





Prepare for use

1. Carefully remove packing material. Do not use sharp tools that can damage the ice maker.
2. Ensure all components are present.
(An assembled filter, 1 drainage pipe and 2 silica plug, drip tray and drip tray cover are a standard on the machine.)
3. Place the ice maker upright on a flat, level surface and plug it in.
4. Clean the ice maker before first use.

Connect to water and drain pipe

It must be connected to tap water. If there is a problem caused by the tap water without a filter, our company will not bear the cost of repairing.



The water supply pressure should be 0.1-0.4MPa; if the pressure is greater than 0.4MPa, a pressure reducing valve is required.

(1) Use tap water as water source

The filter you received is assembled, plug the water intake pipe firmly into the connector at the back of the machine until you can't insert it anymore, and the other side connects to the water tap.

(2) Drain



The drain of the inner tank must be always hooked it up to a floor drain or a container, or the water will leak to floor !


The drain of internal water tank only connect to a floor drain after cleaning, or it must be plugged.

Understanding the display

A.Please make sure:

- 1.The tap is on or there is water in the bottle.
- 2.The drain pipe was inserted into sink or bucket.
- 3.The machine is power on.

B.Touch screen:



Control board

(1) Standby: Plug the power cord into the socket will make the machine enter standby mode.

(2) Touch “making ice”, “dispense ice”, “clean” icon under standby mode, the selected indicator will blink.

(3) Making ice: Touch “Making ice” icon under standby mode or “clean” mode to make the machine start to make ice; Long touch this icon for 2 seconds during “Making ice” mode to make the machine enter standby mode.

(4) Dispense ice: Touch this icon under standby or “making ice” mode will make the machine to dispense ice, touch again to stop dispensing. If no ice is dispensed within 30s, it will stop dispensing automatically. If the outlet is jammed, long press this icon for 5s, ice cubes will be dispensed automatically after 2-5s.

(5) Large / Clean: Touch this icon during “making ice” mode will make the machine to dispense ice continuously for 5min, touch again will make the machine stop dispensing ahead of time.

Long touch the icon for 3s under standby mode to start the self-cleaning progress, touch again to stop the self-cleaning progress. After cleaning, unplug the outlet to drain. Make sure the drain pipe is connected before starting the machine.

NOTE:

1. Clean mode and ice making mode can't be operated at the same time.


2. The two outlets of the machine must be hook up to a floor drain after cleaning. Observe the water flow to avoid overflow.

3. After that, the outlet of the internal water tank must be plugged.

(1)Ice full: As infrared rays detected no ice fall over 2 min, the machine will stop and the “ice full” indicator will be on, the machine will restart to work as you take some ice out or after the ice melt.

(2)Fault: If no ice fall over 15min for the first cycle, the machine will stop and FAULT indicator will be on. After that, if there is no ice fall over 3min, the machine will stop working and the FAULT indicator will be on.

Warning: The ice machine is used to make and store ice, wash your hands before taking ice.



Clean and care

1. For long time storage

- Power off the machine and pull the plug.
- Turn off the faucet and remove the inlet pipe.
- Take out all the ice, drain the water inside.
- Dry the ice bin and interior.

2. Daily cleaning

During the working time, more and more scales will precipitate in the water tank. If it is not cleaned in time, it will cause malfunctions. Generally, it needs to be cleaned once a week. Take all nugget ice out, add 10% edible citric acid to the water tank during cleaning, touch the clean icon, it will take about 5min to finish the clean procedure, and then repeatedly rinse with fresh water before using. Observe the water flow at any time during the cleaning mode to avoid overflow, if the water is too swift which lead to overflow, turn down the tap.

3.Clean interior

NOTE: Pull the plug before cleaning or maintaining.

To make the machine work normally, check and clean condenser annually.

Don't use alcohol to clean the in-wall of the machine, it will break the plastic materials.

4.Clean exterior

Clean the exterior with detergent weekly.

Common malfunction analysis

Issues	Check items	Possible causes	Solutions
The machine doesn't work	Power cord	The plug didn't plug into socket	Plug into socket
	The fuse of PCB	The fuse is broken	Replace the fuse
	PCB	Broken	Replace the PCB
	Ice full	Ice full	Take out some ice
	Proximity switch	Proximity switch is broken	Replace the proximity switch
	Power supply	No power or lower voltage	Contact power supply bureau
	Water supply	No water or water pressure is low	Check water source and its pressure
	Inlet valve	Inlet valve is broken	Replace the inlet valve
Compressor didn't work or stop working suddenly	Power supply	No power or lower voltage	Contact power supply bureau
	Air inlet is congested	Ensure that the machine's surrounding space of at least 50 cm of clear of any objects	Air inlet is congested
	Condenser	Too much dust covered	Clean the condenser
	Refrigerant	Refrigerant leaked	Contact after sales service
	compressor	Connection wire is broken off	Contact after sales service
No water in the water tank	Water supply	No water or water pressure is low	Check water source and its pressure
	Inlet valve	Inlet valve is broken	Replace the inlet valve

Water leakage	Water inlet	Water inlet is loosened	Re-tightened the water pipe
	Drain pipe	Didn't connect to drain pipe or sewer	Connect to drain pipe or sewer
	Float	Jammed or broken	Adjust or replace
Stoppage indicator is on	No ice during 15min	Refrigeration system	Contact after sales service
	There are ice fall into the ice basket	Infrared ray is broken	Contact after sales service

Take too long to make ice	Water pressure	Lower water pressure	Check the water source
	Water temperature	Water temperature is high	Change to a water source of lower temperature
	Ambient temperature	Ambient temperature is too high or too low	Change to a place of lower temperature
	Refrigerant	Refrigerant leakage	Contact the after sales
Productions of ice cubes is low and the cube ice is too thin	Condenser	Too much dust covered causes bad ventilation, will take too long to make ice	Clean the condenser
	Water pump	Water pump broken	Replace a water pump
	Ambient temperature	Ambient temperature is relative high	Change to a place of lower temperature
	Air inlet	Air inlet is congested	Ensure that the machine's surrounding space of at least 50cm is clear of any objects

Add water indicator is on	Water tank	No water inside	Check the water supply
		Water in the tank	Check the float
Noise	Condenser	The sound of the fan scrapes against condenser	Contact the after sales
	Valve	It worked too long for single time	Restart the machine after the solenoid valve cool off
	Evaporator	In the beginning of making ice	Normal

RoHS

Nugget ice maker							
Category	Accessories	Harmful substance					
		Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Hardware	Refrigeration Component	○	○	○	○	○	○
	Screws	○	○	○	○	○	○
	Sheet metal	○	○	○	○	○	○
Electricity Component	Fan component	○	○	○	○	○	○
	Power cord	○	○	○	○	○	○
	PCB	×	×	×	○	○	○
	Compressor component	○	○	○	○	○	○

Plastic injection	Plastic panels	○	○	○	○	×	×
	Water tank	○	○	○	○	○	○
	Inner shaft	○	○	○	○	○	○
	Feet	○	○	○	○	○	○
	Ties	○	○	○	○	○	○
	Silicon gel plugs	○	○	○	○	○	○
Wrapping	Carton	○	○	○	○	○	○
	Foam	○	○	○	○	○	○
	PE bag	○	○	○	○	○	○
	Labels	○	○	○	○	○	○
	Manual	○	○	○	○	○	○

Manufacturer: Cixi Jirui Electric Appliance Co.,Ltd

Add: 118# Nanxin Road,Zonghan Street,Cixi City,Zhejiang Province

MADE IN CHINA

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Support and E-Warranty Certificate

<https://www.vevor.com/support>