



Govee Home App

For FAQs and more information,
please visit: www.govee.com

Warning

- 1 Do not press the On-Off button quickly and frequently.
- 2 Do not plug in the appliance whose power is higher than 1800W.

11

Specifications

Rated Voltage	AC 120V
Rated Current	15A Resistive (Max)
AC Frequency	60Hz
Max Total Output Power	1800W
Working Temperature	-20°C - 45°C (-4°F - 113°F)
Wireless Standard	IEEE 802.11 b/g/n, 2.4GHz
App Support	iOS/Android

12

Customer Service

- Warranty: 12-Month Limited Warranty
- Support: Lifetime Technical Support
- Email: support@govee.com
- Official Website: www.govee.com
- @Govee @Govee
- @Govee @Goveeofficial

13

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC

FCC Exposure Statement

Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the

FCC Exposure Statement

equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

FCC Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



Indoor use only

Responsible party :

Name: GOVEE MOMENTS(US) TRADING LIMITED
Address: 2501 Chatham Rd Suite R Springfield IL 62704
Email: support@govee.com
Contact information:
<https://www.govee.com/support>

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Shenzhen Qianyan Technology LTD is under license.

The trademark Govee has been authorised to Shenzhen Qianyan Technology LTD. Copyright ©2021 Shenzhen Qianyan Technology LTD. All Rights Reserved.



User Manual


Model: H5086
Smart Plug Pro
(Energy Monitoring)

Safety Instructions

- This device is recommended for use indoors and in a dry location only.
- The device should only be used within its issued outlet rating stated in the instructions.
- Please contact the Govee team for a replacement if there is any damage caused from transport.
- Please correctly plug in the socket and keep away from children.
- For added safety, please make sure to plug in the socket fully before using.
- Please do not disassemble the device. Otherwise, the device may get damaged or become a safety hazard.

01

At a Glance



With Govee Smart Plug Pro, you can remotely turn on or off home appliances simply with a network-connected mobile phone. You can also press the button on the device to turn them on or off. Press and hold the button for 10s to restore to factory settings.

02

LED Indicator	Status
Solid blue	Power on. Wi-Fi connected.
No light	Power off. Wi-Fi connected.
Solid red	Disconnected from Wi-Fi.
Flashing blue	Connecting to Wi-Fi.

Installing Your Device


Plug the device into the socket.

Notice:

- Make sure the distance between the device and the router is less than 100ft.

03

- Keep as few obstructions (e.g. wall, windows) as possible between the device and the router.



04

Pairing Your Device with Govee Home App

What You Need:

- A Wi-Fi router supporting the 2.4GHz and 802.11 b/g/n bands. 5GHz is not supported.
- A smartphone or tablet running iOS 8.0 (or above) or Android 4.3 (or above).



05

- Download Govee Home App from the App Store (iOS devices) or Google Play (Android devices).
- Turn on your smartphone's Bluetooth.
- Open the app, tap the "+" icon in the top right corner and search "H5086".
- Tap the device icon and follow the on-screen instructions to complete pairing.

06

Using Your Device

1 App Control

Remote On/Off	Turn on/off the device remotely.
Timer Setting	Turn on/off the device at the preset time automatically.
Off Delay	Automatically turn off the device after the time period you preset.
Energy Monitoring	Monitor the power consumption of the devices plugged into the smart plug.
Lock Feature	The lock feature can be turned on or off in the app. When the lock is

07

	on, the On-Off Button on the device will not be effective.
Turn Off the LED Indicator	Turn off the LED indicator when the device is powered on.

2 Voice Control

The device supports voice control via Alexa and Google Assistant. Please refer to "User Guide" to activate. The "User Guide" can be found through the following methods:

- Open Govee Home App and select your Wi-Fi plug in the Devices page.
- Tap the settings icon in the top right corner.
- Tap "User Guide" to follow the on-screen instructions.

08

Troubleshooting

1 Failed to connect to Wi-Fi.

- Make sure the distance between the device and the router is less than 100ft.
- Keep as few obstructions (e.g. wall, windows) as possible between the device and the router.
- Make sure the Wi-Fi name and the password you entered is correct.
- Make sure the Wi-Fi you connect to is 2.4GHz. 5GHz is not supported.

09

2 Lost W-Fi connection./Cannot use the device with the app.

- Make sure your home Wi-Fi works well.
- Check whether the Wi-Fi password has been modified.
- Keep as few obstructions (e.g. wall, windows) as possible between the device and the router.
- Check whether the device has connected to Wi-Fi by the indicator. If the indicator is red, please reconnect the device to Wi-Fi as steps mentioned above.

10