



Design by our hearts,
bring your baby joy
and happiness

EDUCATIONAL REMOTE CONTROL CAR USE MANUAL

Instructions must be retained since
it contains important information.




NO.2405C/2405D
Applies to #2405C #2405D

- Music theory cognition
- Curiosity Exploration
- Training of direction sense
- Learning of common sense in daily life
- EQ cultivation

FUNCTION INTRODUCTION

- Four channel remote control
 - Simulated drivingcondition
 - Direction recognition
- Alarm recognition
 - Shifting Gear

PICTURE OF EACH PART



Remote sensitive control

Inspire wisdom and exercise coordination skills. Remote control helps babies develop hand eye coordination and spatial perception, experiencing the charm of technology.

FUNCTIONAL EXPLANATION



The cyclic rotary scene


Your baby can control the car in the picture by using the steer and let the car drive along the road.



The steer can control the car to move to the left or to the right. Press the horn key in the middle and it will send out the honking sound.



ON/OFF: High-simulated key for the car, rotate the knob and the car will send out engine sound. The volume in the 2nd gear can be adjusted as you may need.



Press the key with the icon of fire truck, ambulance, police car and it will send out the corresponding alarming sound while the police traffic light keep flashing.



Turn-right When toggling the handle toward upward, the right steering light will keep flashing. When toggling the handle toward downward, the left steering light will keep flashing.
Turn-left When toggling the handle in the middle, the direction light will not be"ON".


Simulated operating by shifting the gear



The rotating speed of the scene will slow down when shifting the gear and let your baby experience more realistic and interesting driving.
Gear 0: Neutral Gear, Stop driving
Gear 1: Slow Speed
Gear 2: Fast Speed

Remote control Battery installation diagram

Open the battery cover on the Remote control back. Load 2PCS DC1.5V AA batteries into the battery compartment ,well buckle the battery cover and then lock with screws.



Note: the positive and negative poles of the battery should not be misplaced!

Explanation of charging function



Charging port



Charging line

Low power will make the sound of the product small, need to connect the charging cable to the charging hole to charge. Note It cannot play normally during charging. It can be played normally only after the charging cable is removed from the power supply.

3.7V

3.7V lithium battery is used, red light shines through the small round hole when charging, and the light goes out when full (charging time is about 150 minutes)

The toy shall only be used with a power supply for toys; the USB power supply is not a toy.

- Replacement of a battery with an incorrect type that can defeat a safeguard (for examplein the case of some lithium battery types);
- Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of abattery, that can result in an explosion;
- Leaving a battery in an extremely high temperature surrounding environment that canresult in an explosion or the leakage of flammable liquid or gas;
- And a battery subjected to extremely low air pressure that may result in an explosion or theleakage of flammable liquid or gas.

This toy contains battery that is non-replaceable.

USB charger used with the electric toy shall be regularly examined for damage to the supply cord, plug, enclosure or other parts, and in the event of damage, it shall not be used until the damage has been repaired.

This toy is only to be connected to equipment bearing either of the following symbols:



Notes: After 90 seconds of inactivity, it will play music automatically, which means it switches to sleep mode. You can press any key to wake it up.

正面

背面