

## **A1**

How to switch the function

Short press the button to switch function.

Blue Light

Clear Bluetooth Pairing ID

Green Light

Vibration on / off

Reset to factory settings:

1. Hold button
2. insert into the charge cable and connect to a USB charge port.

## **A2**

Function Description

Function Introduction

Blue Light: Clear Bluetooth Pairing ID

Long press the button for 3 seconds

Execute clearing ID

Green and Red flashing (Please wait 11-20 seconds when clearing ID)

Clear successful:

Green Light flashes 3 times

Clear failed:

Red Light flashes 3 times

Clear Failed (Please re-operate)

## **A3**

Green Light: Vibration on / off

Long press the button for 3 seconds

Vibration on:

Green Light flashes 3 times

Vibration off:

Red Light flashes 3 times

## **A4**

Pairing Connection

- 1, Turn on Bluetooth in your mobile.
2. Tap the Main Menu.
3. Tap Settings.
4. Select Pokemon Go Plus in setting page. Pocket Auto Catch Lightning will start to pair automatically.

Unpaired ID Green Light flashes

Paired ID Blue Light flashes

## **A5**

Pokemon Go Plus

5. Waiting for pairing. When the Pokemon Go Plus icon turns on, it means pairing is successful.

Not connected

Successful connection

Connected to Pokemon Go Plus

## A6-A7

Others

Power / Connection / Other status

Situation	LED	Vibrtion
Low Power	Flashing	X
Waiting for connection	Flashing (unpaired) Flashing(paired)	<ul style="list-style-type: none"><li>● 0 ~3 minutes: Vibrate for 2 times for every 10 seconds.</li><li>● 3 ~ 10 minutes: Vibrate for 2 times for every 30 seconds.</li><li>● Stop warning after 10 minutes.</li><li>● If the situation is "Intermittent ", it vibrate 3 times instead 2.</li></ul>
Out of internet	Fntermittent	
Items are full	White	<ul style="list-style-type: none"><li>● Vibrate for 2 times for every 2 seconds.</li><li>● Stop after 3 cycles.</li></ul>
Out of Pokeball	Flashing 3 times	
Pokemon up to maximum / Far away from Pokestop	Permanently on	

When you are playing Pokemon Go, there will be no vibration.

## A8

Charge your Catch

- When charging, Pocket Auto Catch Lightning shows 3 colors repeat LED light.
- When the power is full, Pocket Auto Catch Lightning shows white LED light.

## A9

Can't charge smoothly?

When it is not used for a long time, the rechargeable battery may enter the protection mode and cannot be charged smoothly, you can activate the rechargeable battery by pressing and holding the button, then plugging and unplugging the USB several times until the white LED flashes, and then releasing the button.

## **FCC STATEMENT :**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## **RF warning statement:**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.