



Automatic Ice Maker & Shaver Machine 33lbs/day

Instruction Manual



**THIS INSTRUCTION BOOKLET CONTAINS IMPORTANT SAFETY INFORMATION.
PLEASE READ AND KEEP FOR FUTURE REFERENCE.**

DESCRIPTION



SPECIFICATIONS

Daily Ice Output: 15kg/24h

Ice Storage Capacity: 1kgs

Water Reservoir Capacity: 1.7L

Refrigerant: R290

Ice Shape: Bullet


Dimension: 310*400*420mml

BEFORE/FIRST USE OF YOUR ICE MAKER

1. During transportation, the incline angle of the cabinet should not be over 45°. Do not turn the Ice maker upside down. As this may damage the compressor and sealed system.
2. Remove all packing material and carefully check your ice maker to ensure it is in good condition and that there is no damage to the ice maker or power cord and plug.
3. The Ice maker should be placed horizontally on a level surface. To ensure proper ventilation for your Ice maker allow 150mm of space at the top, the back and on each side. Do not install the Ice maker near an oven, radiator, or any other heat source.

4. Before using the Ice maker for the first time, please wait 2 hours after positioning it, and keep the front lid open for at least 2hours
5. Ensure that the voltage indicated on the ice maker corresponds with the voltage in your home.
6. Pure water is not allowed to be used on this unit, spring water is recommended.
7. Please always keep the viewing window close during ice making.

CONTROL PANEL OPERATION




Button/Indicator	Explanation
	Press this button to shaved ice. Before the press of this button,please put enough ice into the bowl and covers the bowl cover well.
	Unit under ice making process if it lights up without flash
	It lights up when the ice in ice basket is full
	Plt lights up when the water in water tank is not enough
	Press it to start the ice making.


OPERATING INSTRUCTIONS

Step 1.

Shaved ice may melt,so it is strongly recommended that a drain hose at bottom of unit be connected. The steps are as follows.



Sketch for step 1



Water tank drain outlet at the bottom of machine






Step 2.




Open the lid,take out of the ice basket and fill the water reservoir with water.

Note: Make sure the water is not over the bottom of the ice collecting tray.


If you prefer to fill the water automatically,then insert the water pipe into the socket at back of the unit as below.

STEPS TO HOOK IT UP TO A TAP

Step 2.1	Insert the brackets at the back of the machine.	
Step 2.2	Remove the lids on both sides of the filter.	
Step 2.3	Install the filter connectors on both sides, which should be bound with raw tape, otherwise it will result in leakage.	
Step 2.4	Stick the filter between the buckles (the end of the filter with an arrow should be placed towards the left).	
Step 2.5	Insert the water pipes to both sides to the filter .But do not connect them to the machine in advance.	



Step 2.6	Unscrew the water tap and instead screw the tap interface(the metal) first,and then screw the water tap to the tap interface.	
Step 2.7	Connect the blue water tap with tap interface to the right pipe of the filter.(Note:it's not the time yet for the left pipe to be connected to the water inlet hole),and turn on the tap for at least 10seconds to drain water. Once the water becomes clear, turn off the tap. Then connect the left pipe to the water inlet hole and turn on the tap again.	
Step 2.7	If you want to take off the pipe connected to the water inlet hole, take off the blue ring named as A(if any)first, then press the white ring at the outer side named as B, and pull out the pipe simultaneously.	

Step 3.


Press  button to turn unit on. The ice maker begins to work.

Note: For the first three cycles,the ice may be small and irregular in size,or even no ice.

Step 4.

If indicator  lights up,please take out the basket,then add water as per step 1 , then press  to restart the ice maker.

Step 5.

If indicator  lights up,please take out the ice with the scoop.

Note: When the ice basket is full please remove the ice immediately, Do not allow the ice collecting tray overflow.

Step 6.

Press  button to shave ice.

Note: Before the press of this button,please put enough ice into the shaved ice bowl and cover the bowl cap well.

Step 7.


Press  button to stop the machine.

Step 8.

Put a tank in below the unit, then pull the unit a little forward, pull the drain plug at middle of the tank to drain water.

Step 9.

If you want to take off the pipe, sketch as above, firstly take off the blue ring named as A (if any), then press the white ring (lock) at the outer side named as B, At last take out the pipe.



CARING

1. Clean the inner liner, ice collecting tray, water box, ice shovel and evaporator frequently. When cleaning, unplug the unit and remove the ice cubes. Use a diluted solution of water and vinegar to clean the inside and the outside surface of the Ice maker. Do not spray Ice maker with chemicals or diluted agents such as acids, gasoline or oil. Rinse thoroughly before starting.
2. Keep ventilation openings in the appliance enclosure, or in the built-in structure, clear of obstruction. Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
3. To ensure the cleanliness of the ice cubes, water in the water reservoir is suggested to be replaced every 24 hours.
4. If the compressor stops for any reason such as water shortage, too much Ice, power off, etc... Do not start the system right away, wait 3 minutes, and then re-start the Ice maker.
5. Always use fresh water before starting ice production either at initial installation or after a long shut-off period.
6. This unit is for home use only, not for outdoor use, if it is necessary for use outside, please make sure the view window is closed.

SAFETY NOTICE


In order to avoid any accidents, please refer to following operation:

1. Disconnect power before servicing.
2. Do not pull directly on wire when plugging or unplugging the unit.
3. If ice is abnormal, please call the seller.
4. It is normal for the compressor and condenser surface to reach temperatures between 70°C and 90°C during operation and surrounding areas may be hot. Please don't touch it.

5. Due to fast freezing, ice cubes may appear "Cloudy". This is trapped air in the water and it will not affect quality or taste of ice.
6. When out of use, please open the drawer at least 2cm to allow for air circulation and avoid any metallic components becoming rusted.
7. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
8. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
9. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision
10. WARNING: fill with bottled or good quality tap water only. (Do not fill with fruit juices or other drink types).
11. WARNING – Keep the air vents on the sides of the machine unblocked at all times.
12. WARNING – Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
13. WARNING – Do not damage the refrigerant circuit.
14. WARNING – Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.

TROUBLESHOOTING

1. Please note, if a power failure occurs due to disconnection of the power cord, or the off power button has been pushed off during an ice making cycle, small ice chips may form and lodge in the automatic shovel causing it to jam. If this occurs, the ice chips may be removed by disconnecting the power cord and gently pushing the shovel to the rear of the cabinet and removing the ice chips, then restarting.
2. Please restart the ice maker by pressing Stop and then Start. If the Ice shovel does not push the Ice into the Ice collector after the formed Ice drops from the evaporator finger while at the same time the M light is on, check to see if the water tray is horizontal or balanced. If not then adjust by pressing the Ice shovel lightly with your finger. Then re-start the Ice maker.

The compressor works abnormally with a Buzzing noise	Reasons	The voltage is lower than recommended.
	Solutions	Stop the Ice maker and do not restart until the voltage is normal.
Conditions for Ice making. Cycle are right but no ice is made.	Reasons	Refrigerant leaks./ Sealed system is blocked.
	Solutions	call for service.
The lights of ice full and add water come at in the same time.	Water tray is blocked by ice cube.	Clear the ice cube under the ice shovel pull out the plug and insert It again then press  the button, 3 minutes later the machine will restart automatically.
Machine keeps running, but the water is warmer than the normal water.	The magnetic valve is broken.	Replace the magnetic valve.

NOTE:

To continuously improve its products, VIVOHOME reserves the right to modify this information without prior notification.

For any questions during assembly, please watch the video in the product page for reference. Or contact customer service via support@vivohome.com with any questions, comments, or concerns. Thank you for using VIVOHOME products in your home!

Thank You For Purchasing From
VIVOHOME
MADE IN CHINA