# How to reset your **Schlage Omnia**™ Smart Lock

Please follow these instructions if you are having trouble pairing your Schlage Omnia™ Smart Lock to your Schlage Breeze app on your mobile phone.

## 1.

Remove the Schlage Omnia™ from your door by removing the two screws located on the interior body.

## 2.

Ensure the batteries are installed and the lock has power.

## 3.

Hold down the reset button located on the inside of the exterior body, for 5 seconds until you hear "Input initialisation code."
**Note:** A long, pointed object will be required to reach the small button.
**Note:** If you hear "Please enter administrator code." then you have not held down the button for long enough, please try again.

Reset Button

## 4.

Enter 000000#
(six zeros then hash).

## 5.

You will hear "Deleting administrator successful." You can now reinstall the Schlage Omnia™ on the door.

## 6.

Your Schlage Omnia™ Smart Lock has now been reset back to factory settings and can be paired to the Schlage Breeze app.

## 7.

Open the Schlage Breeze mobile app and follow the instructions to pair your Schlage Omnia™ Smart Lock.