


I:Key Instruction



  **Speed+/-**

- Speed increases/decreases in Effect mode
- Speed increases/decreases In dynamic gallery mode
- Speed increases/decreases in left/right/up/down mode of static gallery
- Increased/decreased sensitivity in music mode

II.About Settings:


1) In the setting interface, you can set the color calibration, horizontal flip.



III:Detailed introduction of APP functions


1).Colorful

16 million colors can be picked up! You can edit the curtain light color in whole section or point paint, and adjust the brightness.




2) Effect function

There are built-in 17 lighting effects, and adjustable speed and brightness.



3) Font function

Click "□" to add text or built-in pattern. You can Change the color or base color of the text. It also achieves up and down, around, flicker, fixed and other effects.



4) Gallery function

built-in dynamic pattern and static pattern selection, curtain lamp according to the selected pattern display lighting effect.




5) DIY function

1.Click "+" to create multiple screens to generate dynamic lighting effects.




2. Click "+" to make DIY arbitrary patterns and texts. It can also achieves up and down, around, flicker, fixed and other effects. Create the perfect atmosphere for your favorite special occasion.



6). Music Mode


1. Synchronization function of lighting and music rhythm.

Click "Add Music" > Import a music file or import it from the built-in music library.




2.MIC

The lights color will change with the sound rhythm when your phone microphone catches the sound. The microphone sensitivity can be adjusted by the slider. There are two ways to input the audio signal on the controller, built in APP microphone and external microphone (For sound control version).




7) Light timer

Smart lights automatically come on and off at given times through the timer function, choose your favorite effect and color then save it.



8) Group Control

This mode allows you to create different groups to control more than one controllers at the same time.



Attentions

a) Please use the product in a dry environment. b) For input voltage, please use the DC voltage within the specified range as instructed in the manual, must not connect into 220V AC directly. c) The product is requested common anode connection. The wrong connection will cause a malfunction.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure Statement

To maintain compliance with FCC'S RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm between the radiator and your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.