


# Wireless Intercom System



## Note:

1. Every conversation must be started by an outdoor machine.
2. The indoor machine is turn off when you received it, so please press&hold ON/OFF button for 3 seconds to turn on it at first.

## Volume +/-:

Adjust the volume of the incoming voice from the outdoor machine(4 Levels of volume).

**Channel Setting:** Press the Channel + & Channel - to change the channel (1-16).

**Tips:** Must keep the intercom machine on the same channel so that they can chat with each other.

## Power ON/OFF:



Long press and hold the power button for 3 seconds until hear the beep voice to turn on/off the machine.(Click the Volume Button after turn on the machine. If you hear the BEEP tone, it means the device has power. If you do not hear the tone, it means the battery needs to be charged)

## Intercoms

- (1) The using time of the intercom about 48 hours. We suggest that keep the indoor intercom stay in the charge station after use or charge the indoor machine once every 2 days.
- (2) For systems that have multiple indoor machines, you can use them as walkie-talkies for indoor/outdoor activities.

**Note: Please charge the indoor machine at least 5 hours after receiving it to ensure that there is sufficient power to use. Then press & hold the ON/OFF button for 3 seconds to turn on it after charged.**

## Pairing and using

- (1) The machines should be on the same channel (a total of 16 channels). Press the  and  button to change the channel.
- (2) To test the communication between the devices, press and hold the TALK button to talk to another machine. After you have stopped speaking release the TALK button and wait for the other intercom response.

## Installing

- (1) Place it on the charging stand, then connect it to AC power.
- (2) Stating using the intercom system!

## Usage scenario

- (1)Set the same channel (1-16) for the intercom;
- (2)Hold the power button of the machine to turn it on;
- (3)Hold the talking button to speak with others.

## Notes

- (1)You must press and hold the TALK button when you want to speak to someone. Simply clicking the TALK button is invalid;
- (2)Two users cannot use the TALK button on both sides at the same time.
- (3)Only one user can use the TALK button to speak to the other. The other user must wait for the speaker to finish, then press and hold the TALK button on their side to respond. You will not be able to hear the other user while you are speaking.

**FCC Statement:**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

SAR tests are conducted using standard operating positions accepted by FCC/ISED with the device transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. Before a new model is available for sale to the public, it must be tested and certified to the FCC/ISED that it does not exceed the exposure limit established by the FCC/ISED. Tests for each product are performed in positions and locations as required by the FCC/ISED.

For body worn operation, this device has been tested and meets the FCC/ISED RF exposure guidelines when used with and accessory designated for this product or when used with and accessory that contains no metal.

To maintain compliance with FCC/ISED RF exposure guidelines hold the transmitter and antenna at least 1 inch (2.5 centimeters) from your face and speak in a normal voice, with the antenna pointed up and away from the face.

The equipment complies with FCC/ISED radiation exposure limits set forth for an uncontrolled environment. In order to comply with the FCC/ISED RF exposure requirement, the antenna installation must comply with following:

Users must be fully aware of the hazards of the exposure and able to exercise control over their RF exposure to qualify for the higher exposure limits.

Your wireless hand-held portable transceiver contains a low power transmitter. This product sends out radio frequency (RF) signals when the Push-to-Talk (PTT) button is pressed.

The device is authorized to operate at a duty factor not to exceed 50%.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.