

Reset button hole (use S/S pin to press) Battery Cover LED Indicator 3) Blink Slowly: You can also select "Blink Slowly", make sure the LED indicator is blinking slowly, if not, use the S/S

App interface, it will connect automatically,

configuration completed.

Product Presentation:



Specification

Size: 71*25*20mm

Wi-Fi Standard: 2.4GHz Wi-Fi Frequency: IEEE 802.11b/g/n

Standby Current: 22uA

Battery: LR03-1,5V/AAA*2 (Alkaline battery)

in the right direction of electrode, the indicator will blink, then push to close the cover. (Notes: when batteries are run out, please choose

Slide downwards to open back cover of batter

compartment, install 2pcs AAA Alkaline batterie

How to use:

Functions 1. Alarm alert

When the sensor detects someone is passing by you will receive alarm message on your mobile.

2. Alarm records

You can check all alarm records in the app. so you will not miss any important moments.

3. Low power alarm

When the battery power is low, the app will aler you to replace with new batteries.

4. Device sharing

Share your added sensors with family members

so they can also monitor the status on their App.

You can set scene linkage with other tuva smart

5. Scene linkage

devices such as light. When it detects someone

close to human body temperature, the detect, sensitivity will decrease obviously, making sensoi short-term failure sometimes.

Please contact us if you have any questions: Wiooni@outlook.com

How to set up:

1. Use your smartphone to scan QR code, or

APP Store to download and install.

Smart Life

and authentication code.

then pass by again.

the infrared.

search "Smart Life" app in Google Play Store or

2. Create an account with your mobile number

FAQ

human body is easy to be sheltered due to poor

penetration, so the detector is hard to receive

3. The motion sensor is vulnerable to interrupt by RF radiation. When environment temperature is

reception.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received.

FCC WARNING

1. If you use the motion sensor the first time, it will

alarm when the sensor detects body movement And there will be about 30s time interval to alarr including interference that may cause undesired after you leave the detect anale or detect range

operation. Any changes or modifications not expressly approved by 2. The motion sensor is vulnerable to interrupt by heat or light sources, the infrared radiation of

the party responsible for compliance could void the

user's authority to operate the equipment,

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device. pursuant to Part 15 of the FCC Rules. These limits are

designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in

-13-

accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not

occur in a particular installation. If this equipment does cause harmful interference to radio or television

motion sensor automatically.

4. 1) Bluetooth Mode:

Connect your mobile to the Wi-Fi router, click

and supply power to the gateway.

"Add Device" . Make your zigbee gateway ready

The app advises you to turn on the bluetooth in your mobile, enter wifi name and password, it

will search nearby device, and connect the

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the

interference by one or more of the following measures: Reorient or relocate the receiving antenna.

Increase the separation between the equipment and

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure

guidelines. This equipment should be installed and operated with minimum 20cm distance between the

radiator and your body: Use only the supplied antenna.