

Installation Information

MICROWAVE OVEN **WOLF**™

INSTALLATION INFORMATION

The Wolf microwave oven can be set up as a free-standing unit or set into a built-in wall installation.

This section of the manual covers some of the installation issues that a service technician may need to know when servicing a Wolf microwave oven. If additional installation information is needed after reviewing this section of the manual, please refer to the installation guide or contact the Wolf Appliance Customer Service Department.

Electrical Requirements

- 110 to 120 Volts AC, 60Hz, 15 ampere fused electrical supply
- Separate electrical circuit serving only this appliance
- A properly grounded 3-prong receptacle

⚠ WARNING

THE INSTALLATION SITE MUST BE EQUIPPED WITH A PROPERLY GROUNDED 3-SLOT RECEPTACLE TO MATCH THE 3-PRONG (GROUNDED) POWER SUPPLY CORD PROVIDED ON THE APPLIANCE. IF THE ELECTRIC RECEPTACLE OR POWER CORD ARE NOT PROPERLY GROUNDED, THIS COULD CAUSE A SHOCK HAZARD AND THE APPLIANCE MAY NOT FUNCTION.




Figure 2-1. Electrical Receptacle & Power Cord

⚠ WARNING

TO AVOID SHOCK HAZARD, NEVER REMOVE THE GROUND PRONG FROM THE PLUG OF THE POWER SUPPLY CORD.

⚠ WARNING

- **EXTENSION CORDS ARE NOT RECOMMENDED.**
- **IF AN EXTENSION CORD IS NECESSARY, USE ONLY A 3-WIRE CORD WITH A 3-PRONG PLUG AND A 3-SLOT RECEPTACLE, RATED FOR 115 - 120VOLTS, 15 AMP OR HIGHER.**
- **DO NOT DRAPE EXTENSION CORD OVER COUNTERTOP OR TABLE WHERE IT CAN BE PULLED ON OR TRIPPED OVER ACCIDENTALLY.**

Free-Standing Installation

With the microwave free-standing on the countertop, it is recommended to have counter space on at least one side of the appliance. At least 2 inches of clearance must be allowed on the sides, top and at the rear of the appliance for air circulation. (See Figure 2-2)




Figure 2-2. 2" Clearance on Sides, Top & at Rear

Built-In Wall Installation

The Wolf 24" microwave can be set into a built-in wall installation with the use of a 30" trim kit, available from a Wolf dealer or distributor.

The trim kit consists of a ductwork assembly, duct mounting screws, a decorative trim assembly and trim mounting screws. (See Figure 2-3)

The ductwork assembly is placed on the platform of the rough-in opening and secured with screws. The microwave oven is first plugged into the electrical receptacle, then set on top of the ductwork assembly with the feet of the oven sitting in detents on the rails. The decorative trim is then attached to the wall around the front of the microwave oven. (See Figure 2-4)

NOTE: Because of the decorative trim design, the ductwork assembly and microwave oven need to be positioned toward the right side of the rough-in opening. For complete built-in installation instructions, refer to the installation guide and the instructions that accompany the trim kit.




Figure 2-3. Trim Kit Components




Figure 2-4. Rough-in Opening Dimensions and Trim Kit Installation