



KOGAN ALEXA BUILT-IN SMART WATCH



(KALXWTCBLKA, KALXWTCGRYA, KALXWTCREDA, KALXWTCBLUA, KALXWTCGRNA & KALXWTCPNKA)

Safety & Warnings	3
Overview	4
Operation	5
Pairing with VeryFit app	7
Functions	8
Using with Amazon Alexa	15
Cleaning & Care	18
Specifications	19

SAFETY & WARNINGS

- To prevent device failure, fire and explosion, never place the smart watch or its accessories in any extremely high temperature or extremely low temperature areas.
- To prevent device damage, accessory damage and device failure, always protect the device against strong impact or shock.
- Do not disassemble or modify the device or its accessories without authorization. Any device failure should be referred to our after-sales service personnel.

OVERVIEW




OPERATION

Note:


- Ensure the smart watch is charged fully before first use.

Charging

Whilst the watch is off, it automatically turns on when you put it on charge. To charge, attached the supplied magnetic charging cable to the magnetic charging contacts on the back of the smart watch.



Attach the opposite end of the cable into a USB charging adapter (not supplied). Ensure the adapter meets the specified voltage and current (5V/500mA).



Wearing

- 1. Wear it correctly: make sure that the bottom sensor is properly attached to the skin and the strap shall be one finger away from the wrist.
- 2. Touch operation: the smart watch supports full-screen touch operations. Single click: select; long press: enter or confirm.
- 3. Touch button: the smart watch has a touch button. Short press: return or close a notification.



Getting started

Powering on and off	To power off, open Setup menu and select “Turning Off”.
	To power on, hold the physical button

Physical button operation

Short press	Return (back) Wake the screen when it is off.
Press and hold	Turn on the watch Hold for 5 seconds while charging to reset apps Hold for 5 seconds to activate Alexa on watch face.

Navigating and operation basics

Swipe the screen up/down	To toggle through menu / pages.
	To view long text or details.
Swipe the screen left/right	To toggle through menu / pages.
Tap the screen	To go to the sub-page.
	To complete the corresponding action, depending on which on-screen button is clicked.
Tap and hold the screen	To change the watch face wallpaper.

PAIRING WITH VERYFIT APP

For Android users, open Google Play Store on your smartphone.

For iOS users, open app Store on your iPhone.

Search for “VeryFit” and download the app.

Alternatively, scan this QR code on your device to open the appropriate store for your device and go straight to the app download page.



Once downloaded, open the app, fill in your info, then go to the “Home” page and select “Bind Device.”

Make sure Bluetooth on your smartphone is turned on. You will see a list of devices. Select the Kogan Smart Watch and continue with the binding process.

Light up the smart watch screen and bring it close to your phone.

Confirm the binding request on the smart watch. Fill in your information and set your step goal on the app to complete the binding. Make sure location/GPS permissions are granted to the app for full functionality.

FUNCTIONS

App

Swipe up or down to select an icon. The icons include: Message, Health Data, Workout, Heart Rate, Stress, SpO2, Sleep, Relax, Music, Time and Settings.



Dial

You can switch between different dials in the “Dial Settings”. And you can download and install more dials in the “Dial Market”.

Health Data



It supports viewing the daily accomplishment of the following info: Steps, Calories, Distance and Activity.

Sports

14 Sports modes are provided:



You can choose to show or hide any sports mode in VeryFit.

To start an exercise, start the Sports app, click the icon of sports type, set the goal, then start to exercise.

Heart Rate



It supports measuring your heart rate any time or viewing the daily monitoring data. Also, you can set the measurement frequency in the app settings.

After you start the heart rate measurement app, you should keep your arms and wrists still during the measurement.

Stress



After you start the stress measurement app, you should keep your arms and wrists still during the measurement.

SpO₂



After you start the SpO₂ measurement app, you should keep your arms and wrists still during the measurement.

Sleep



You can view the most recent sleep record and sleep status at each stage.

Relax



Enter the Relax app and choose the duration. Click to start, then follow the vibration frequency and animation instructions to adjust your breathing and it will help you relax.

Message



The watch supports multiple reminder modes, including message reminder, incoming call reminder, walking reminder, drinking reminder, exercise goal reminder, exercise centre rate warning reminder, etc.

Stopwatch



Stopwatch and a timer are provided.

Timer



You can set a timer with a preset duration on the watch and the timer will remind you when the timer expires; you can customize the timer time.

Alarm



1. The watch can be set to add, delete, turn on/off the alarm; you can also set the alarm to the watch through the app; you can also set the label you need in the alarm to identify the alarm
2. You can set the alarm delay time and times in the app to decide how long you want to delay and how many times to delay

Weather



Supports three-day weather viewing, you can view today's "current weather, highest and lowest weather values" and the "highest and lowest weather values" for the next two days

Music



When the watch is connected to the app, you can control the mobile music player to perform the functions of "next, previous", "play/pause" and "volume increase and decrease".

This function can be displayed/hidden in the app settings.

Exercise Record



You can view your recent exercise records on the watch, including detailed data about your exercise; you can also view the exercise records on the app

Find Phone



When the watch is connected to the app, you can make your phone ring. Tap the icon to end the ringing. This function can be displayed\hide in the app settings.

Settings



1. You can set your wrist-lifting screen, real-time heart rate and do not disturb switch on the watch This function can be displayed\hide in the app settings
2. You can switch the locally stored watch face on the watch
3. You can set the brightness of the watch and the length of time the screen is on the watch; you can set the switch to reduce the brightness at night
4. You can control the shutdown, restart and factory settings of the watch on the watch (after restoring the factory settings, all data in the watch will be cleared and the binding relationship with the phone will be released)

USING WITH AMAZON ALEXA

Syncing with Alexa

Ensure you have the Amazon Alexa app downloaded and have your Alexa account set up first. To pair the Smart Watch with Alexa, open the VeryFit app, go to the Device page, click on your device, then find the Amazon Alexa function among the settings.

Follow the prompts on the screen, log in with your Amazon account, authorise your Smart Watch by clicking Allow, and finish the pairing process. Finally, you can choose your preferred language setting for Alexa.



The watch supports Alexa Voice Services. After inputting a voice command in the listening interface, it will enter the thinking interface and return the result.

Timed out? When the request times out, the voice cannot be recognized, the account is not logged in, the network connection is unstable, or the Bluetooth is not connected, a corresponding prompt will be displayed.



Please note: The watch has to stay connected with the phone in order to use Alexa.

Time and Location Settings of Alexa

Please note that Alexa doesn’t know the location and time zone of your Smart Watch until you have the location and time zone updated in the Alexa app. Without doing this, Alexa cannot check your local weather or set the correct alarm.

To update your default location and time zone settings, first open your Alexa app, then go to the Devices page, click on All Devices, select your Smart Watch. Then click on Device Location, fill in your default location, then click on Save. Finally, under Time Zone settings, change the region by clicking on “Change” on the top right corner, select Australia, then specify which Australian time zone.



CLEANING & CARE

Below are three recommendations on wearing and maintenance:

- Keep the device clean
- Keep the device dry
- Do not wear the device too tight

For cleaning:

- Do not use household cleaners to clean the device. Use soap-free cleaners instead.
- For stains that are difficult to remove, it is recommended to scrub with alcohol.

Waterproof performance: the device is not suitable for diving, swimming in the sea or sauna, it is suitable for swimming pool, shower (cold water) and swimming in shallows.

SPECIFICATIONS

Battery capacity	300mAh
Charging time	about 2.5 hours
Waterproof level	5ATM
Operating temperature	0°C-60°C
Product frequency	2402-2480MHz
Screen type	1.69-inch colour screen
Charging voltage	5V±0.2v
Battery life	5 days
Weight of product	42g
Bluetooth version	BLE5.0
Max. transmission power consumption	4dBm
Minimum wristband size	145mm
Maximum wristband size	200mm

Need more information?

We hope that this user guide has given you the assistance needed for a simple set-up.

For the most up-to-date guide for your product, as well as any additional assistance you may require, head online to **help.kogan.com**

kogan.com