

|                                                                                            |                                                                                            |
|--------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------|
| <p>  </p> | <p>  </p> |
|--------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------|

|  |  |
|--|--|
|  |  |
|  |  |

[illegible]

### "ME"


On this page, you can click the water to customize your personal information and other settings.



### Unbinding equipment

Click "device" - click the water cup image - more settings - unbind the device.

Note: when the water cup is connected to other mobile phones, it is necessary to unbind the device on this mobile phone.



### Product introduction

#### Precise temperature regulation

Control the mobile app to apply to adjust the water temperature, which can be accurate to 0.02°C - 0.05°C per degree.



### Lighting temperature display

Temperature light display, different lights represent different temperature ranges.



### Diy colorful reminder light

App comes with a variety of colorful lights to choose from. App sets drinking water alarm clock, colorful light flash prompt.



### Charging instructions

Connect the charger to the coaster, plug in the power supply, place the cup on the coaster, and the metal ring at the bottom of the cup is in full contact with the electrode of the coaster.




### Power introduction description

During charging, the charging sign shows green light and flashes slowly.

Fully charged, the green light of charging sign is fixed, when the power is less than 10%, the red light of the cup is lit.

Note: at the charging indicator light red and green at the same time, it is in full state and flashes orange and yellow.



### Wireless constant temperature

After the water cup is full and the coaster is powered, the water temperature can be kept at the set temperature for 1-2 hours.



### Diy reminder light entrance

Enter the "equipment" page - click the reminder light - click to select the light.



### Charging safety design description

Automatic power-off protection  
No operation on the cup for 2 hours, automatic shutdown.



### Drum protection


When there is no drink in the cup, the cup will automatically identify and turn off the power.



### Technical parameter

Model: S05AH-01X  
Capacity: 250ml  
Battery: 3.7V 220mAh lithium battery  
Cup body: 65x65mm (excluding handle)  
Coaster: 130x100mm  
Waterproof: splash (up body)  
Display: color LED light  
Grade: top grade  
Scope of application: for food contact  
Adapter input: AC 100-240V 50/60Hz  
Adapter output: DC 12V 0.2A  
Base power input: DC 12V 0.25A  
Temperature control range: 40°C-62°C

\* This equipment contains radio transmission (works with mobile network code (respectively))  
CEM 10: 202103-17014





67mm

reminder

Product safety design description

⚠ Dry burning prevention

When there is no liquid in the cup, the cup will automatically identify and turn off automatically.

⚠ Electric shock protection

In the process of use, the tea, water and wine stains come out, and the coaster panel is free from electric leakage and electric shock. Please wipe it in time.

⚠ Anti scald design

During use, the temperature of the cup bottom end and cup base panel will not scald human skin

reminder

Safety precautions

① This product is household vessels.

② Do not store carbonated beverages.

③ It shall not be used to keep dairy products or baby food warm for a long time (there is a risk of bacterial production).

④ Please wipe the water stains in time when use, and keep the cup bottom and coaster dry to avoid damage.

⑤ Do not expose to high temperature sunlight.

⑥ Do not use microwave and other heating equipment to heat the product.

⑦ Do not use the dishwasher.

⑧ Do not collide violently to avoid deformation / damage of the product body.

⑨ Repairing products are not allowed to disassemble, repair or replace parts without authorization.

⑩ The cup body has passed high temperature grade and can be washed safely. The coaster can be wiped with paper towel and cloth, and cannot be washed.

Reminder

Warranty description

1. For relevant after-sales service matters, please contact the distribution unit or the after-sales center of the company. In case of quality problems in normal use, during the warranty period, the company will provide free maintenance services. There are no human faults in normal use, please keep the appearance and integrity of the product, accessories and packaging for repair or replacement (instead of warranty). After the repair or replacement, the company will provide a replacement or repair.

2. The purchase time of all will be subject to the invoice or receipt issued on the purchase date.

3. If the appearance is damaged artificially after purchase, the replacement will be free, and only warranty service will be provided.

4. Under the following circumstances, the replacement / warranty is invalid, and only limited maintenance services are provided:  
(1) The product is damaged due to non-normal use.  
(2) Customers repair, self-repair by units not authorized by the company.  
(3) Damage caused by poor transportation during purchase.  
(4) Damages caused by other factors require

sgslx

certificate

Name: intelligent temperature control Mug

Model: SLX

Manufacturer: Xiechouguang (Shenzhen) Intelligent Technology Co., Ltd.

Address: Floor 2, building 11, Zhilong Industrial Park, Guanhou Second Road, Nantou street, Nanshan District, Shenzhen, Guangdong

Tel: 0755-2301 6693

Executive standard: GB / 12980-2013

Scope of application: for food contact

examination date:

Date:

warranty card

Product name / model

Date of purchase

Sales unit

Customer name / telephone number

postal address

Warranty records

Warranty date | Faults and handling methods | Completion date

|  |  |  |
|--|--|--|
|  |  |  |
|  |  |  |
|  |  |  |

Warning

3) FCC 15.39

The device complies with part 15 of the FCC Rules. Operation is limited to the following conditions:  
(1) The device may not cause harmful interference, and (2) the device must accept any interference received, including interference that may cause undesired operation.

2) FCC 15.21

Warning: Changes or modifications to this unit not expressly approved by the responsible company could void the user's warranty to operate the equipment.

3) FCC 15.105

For a Class B digital device or peripheral, the instructions limit the permitted location in the text of the manual:  
The device must not be used in the following areas:  
— Areas with a high density of people, such as hospitals, schools, and public places.  
— Areas where the use of the device is prohibited, such as aircraft, ships, and vehicles.  
— Areas where the use of the device is restricted, such as airports, train stations, and public places.  
— Areas where the use of the device is prohibited, such as airports, train stations, and public places.  
— Areas where the use of the device is restricted, such as airports, train stations, and public places.  
— Areas where the use of the device is prohibited, such as airports, train stations, and public places.  
— Areas where the use of the device is restricted, such as airports, train stations, and public places.

Warning

1. The device has been evaluated for most general RF exposure requirement. The device complies with the following conditions:  
(1) The device may not cause harmful interference, and (2) the device must accept any interference received, including interference that may cause undesired operation.

2) FCC 15.21

Warning: Changes or modifications to this unit not expressly approved by the responsible company could void the user's warranty to operate the equipment.

3) FCC 15.105

For a Class B digital device or peripheral, the instructions limit the permitted location in the text of the manual:  
The device must not be used in the following areas:  
— Areas with a high density of people, such as hospitals, schools, and public places.  
— Areas where the use of the device is prohibited, such as aircraft, ships, and vehicles.  
— Areas where the use of the device is restricted, such as airports, train stations, and public places.  
— Areas where the use of the device is prohibited, such as airports, train stations, and public places.  
— Areas where the use of the device is restricted, such as airports, train stations, and public places.  
— Areas where the use of the device is prohibited, such as airports, train stations, and public places.  
— Areas where the use of the device is restricted, such as airports, train stations, and public places.

88mm