


CK24AT



ATOM™

USER GUIDE

 **WARNING:**
CHOKING HAZARD—Small Parts
Not for children under 3 yrs.

 **WARNING:**
CHOKING HAZARD—Small Parts.
Not suitable for children under 3 years

 **ATTENTION:**
RISQUE D'ÉTOUFFEMENT — Petites Pièces.
Ne convient pas aux enfants de moins de 3 ans.


 **ACHTUNG:**
ERSTICKUNGSGEFAHR—Kleinteile.
Dieses produkt ist nicht für kinder unter 3 jahren geeignet.

 **PRECAUCIÓN:**
PELIGRO DE AHOGAMIENTO CON Piezas Pequeñas.
Producto no adecuado para niños menores de 3 años.

 **VARNING:**
KVÄVNINGSRISK—Små Delar.
Produkten är inte lämplig för barn under 3 år.

 **ADVARSEL:**
KVÆLNINGSFARE—Små Dele.
Ikke egnet til børn under 3 år

 **AVISO:**
PERIGO DE ASFIXIA — Peças Pequenas.
Produto Não Adequado Para Crianças Com Menos De 3 Anos.


 **OSTRZEŻENIE:**
RYZYKO ZADŁAWIENIA—Drobne Części.
Produkt nie jest przeznaczony dla dzieci poniżej 3 roku życia.

 **WAARSCHUWING:**
VERSTIKKINGSGEVAAR—Kleine Onderdelen.
Niet geschikt voor kinderen jonger dan 3 jaar.

 **AVVISO:**
RISCHIO DI SOFFOCAMENTO—Parti Di Piccole Dimensioni.
Non adatto a bambini di età inferiore a 3 anni.


ATOM LAYOUT

FRONT




NOTE: Press (-) and (+) for screen capture function on Switch.

TOP



ATOM LAYOUT



SETUP

CONNECTION STATUS

The ATOM status LED has the following connection statuses: Search/Reconnection mode, Pairing Mode and Connected.

NOTE: When the status LED is SLOW blinking, ATOM is in search mode. The ATOM can NOT go into pairing mode while in search mode. ATOM must be powered OFF before going into pairing mode. Press and hold the HOME (CRKD) button for 10 seconds to power OFF the ATOM.

CONNECT TO NINTENDO SWITCH™



Option 1: Bluetooth® (Pro Controller)

1) In settings, select the “Controllers and Sensors” and then select Change Grip/Order. **2)** Press and Hold the Home (CRKD) Button for 3 seconds to enter pairing mode. The status LED will blink fast in white. The ATOM will then automatically connect to the Switch. **3)** After successful connection, you will see the controller highlighted in user 1/2/3/4 on the Switch and Status LED on the ATOM will either be RED (1st player), BLUE (2nd player), Yellow (3rd player), Green (4th player).

Option 2: Wired USB

1) Dock the Switch console into its base / stand and then the connect the controller via the USB cable. The controller will automatically connect to the Switch and the status LED will keep lit in white. **2)** After removing the controller from the Switch, the controller will revert to utilizing a *Bluetooth®* connection automatically.

Status LED	Description
Slow Blinking	Search / Reconnection Mode
Fast Blinking	Pairing Mode
Solid	Connected



SETUP

CONNECT TO PC

Option 1: Bluetooth® (Xinput Device). **RECOMMENDED**


1) Turn on the *Bluetooth®* function on the computer (or with a *Bluetooth®* adapter). **2)** Press and Hold ↑ Dpad + Home (CRKD) Button for 3 seconds to enter Xinput Device pairing mode. The status LED will blink fast in orange. **3)** Select “Add *Bluetooth®* device.” Select “*Bluetooth®*” from the available drop down. You will see “Xbox Wireless Controller” available in the options. Select this and wait for Windows to setup the device.

Option 2: Bluetooth® (Pro Controller).




1) Turn on the *Bluetooth®* function on the computer (or with a *Bluetooth®* adapter). **2)** Press and Hold the Home (CRKD) Button for 3 seconds to enter pairing mode. The status LED will blink fast in white. **3)** Select “Add Device.” Select “*Bluetooth®*” from the available drop down. Select “Pro Controller” on the available device list and wait for Windows to setup the device.

Option 3: Wired USB

1) Connect the controller via USB connection.



NOTE: When connecting ATOM as an Xinput Device, the button mappings for X/Y and A/B will be switched. Specifically, Y will function as X, and B will function as A, and vice versa. To switch the X/Y and A/B layout mappings, press and hold ↓ Dpad + “-” button for 5 seconds. The status LED will blink and then turn back to solid. To revert back, press and hold ↓ Dpad + “-” button for 5 seconds.



SETUP

CONNECT TO iOS / macOS

Option 1: Bluetooth® (Xinput Device). RECOMMENDED


1) Turn on the *Bluetooth®* function on iOS / macOS device. **2)** Press and Hold ↑ Dpad + Home (CRKD) Button for 3 seconds to enter Xinput Device pairing mode. The status LED will blink fast in orange. **3)** Select “Xbox Wireless Controller” on the available device list and ATOM will connect with the iOS device.

Option 2: Bluetooth® (Pro Controller).

1) Turn on the *Bluetooth®* function on iOS / macOS device. **2)** Press and Hold the Home (CRKD) Button for 3 seconds to enter pairing mode. The status LED will blink fast in white. **3)** Select “Pro Controller” on the available device list and ATOM will connect with the iOS device.

Option 3: Wired USB (macOS)






1) Connect the controller via USB connection.



CONNECT TO ANDROID

Option 1: Bluetooth®

1) Turn on the *Bluetooth®* function on Android device. **2)** Press and Hold ↓ Dpad + Home (CRKD) Button for 3 seconds to enter pairing mode. The status LED will blink CYAN. **3)** Select “Gamepad” on the available device list and press PAIR. ATOM will pair with the Android device.




CONNECTING TO MULTIPLE DEVICES

The ATOM can be connected to multiple devices.

1) Connect ATOM to an initial device (Refer to SETUP sections). **2)** Press and hold the HOME (CRKD) button for 10 seconds to power OFF the ATOM. **3)** Connect ATOM to another device using a different method.

NOTE: Refer to SETUP sections on how to connect the ATOM to compatible devices. Power OFF the ATOM before connecting it to another device. ATOM cannot be connected to multiple devices using the same method.



SWITCHING BETWEEN DEVICES

If the ATOM is paired to multiple devices, it can be switched between devices seamlessly using different button combinations.


Make sure the ATOM has already been connected to multiple devices. The ATOM has to be powered OFF before switching between devices.

Press dpad right and Home (CRKD) button to switch main device to Switch (Pro Controller)

Press dpad up and Home (CRKD) button to switch main device to Xinput device (PC / iOS / macOS)

Press dpad down and Home (CRKD) button to switch main device to Android.

NOTE: The device that the ATOM is switched to will make it the main device. Pressing the Home (CRKD) button will wake up the ATOM to the main device from OFF status.



SPECIAL FUNCTIONS

The ATOM has special functions that can be set.

CHANGE DPAD TO FUNCTION AS LEFT STICK

Press and hold ← Dpad and Minus Button (-) for 5 seconds. The status LED will blink and then turn back to solid.

CHANGE DPAD TO FUNCTION AS RIGHT STICK

Press and hold → Dpad and Minus Button (-) for 5 seconds. The status LED will blink and then turn back to solid.

RESET DPAD FUNCTION BACK TO DEFAULT

Press and hold ↑ Dpad and Minus Button (-) for 5 seconds. The status LED will blink and then turn back to solid.


SWITCHING X/Y AND A/B MAPPING

When connecting ATOM as an Xinput Device, the button mappings for X/Y and A/B will be switched. Specifically, Y will function as X, and B will function as A, and vice versa. To switch the X/Y and A/B layout mappings, press and hold ↓ Dpad + (-) button for 5 seconds. The status LED will blink and then turn back to solid. To revert back, press and hold ↓ Dpad + “-” button for 5 seconds.

SCREEN CAPTURE

Press (-) and (+) for screen capture function on Switch.

NOTE: Any special function settings will reset back to default after any power-cycle.



PLAY & CHARGE

The ATOM supports playing game software while also charging. Use the USB-C connector port to charge the ATOM. The Status LED will blink slowly when ATOM is charging.

NOTE: The status LED will blink fast in red when battery is low.

TAP AND COLLECT


The ATOM contains an RFID touchpoint. Use the CRKD app and an NFC-antenna enabled smartphone to add the ATOM to your collection. The CRKD app includes complete instructions and videos on how to tap your device. Scan the QR code to download the CRKD app.



SPECIFICATIONS

Design and specifications are subject to change without notice.

Design and specifications are subject to change without notice. USB Charging cable: 125mm (4.9inches), Wireless Connection: Bluetooth 5.0, Battery type: Li-ion, Battery capacity: 180mAh, Charging time: Approximately 2h, Play hours: 8-10h, Power rating: DC 3.7V/10mA, Input Voltage: 5.0V +/-0.2V, Operating temperature: -10°C---60°C, Radio frequency: 1SM 2.4G, Frequency band: 2402---2480MHz(1MHz), Maximum radio-frequency: 0dbm, Mass: Approximately 19g



CUSTOMER SUPPORT

If you have questions about setup or use, contact CRKD direct. The CRKD App includes informational support videos. Visit support on the web at crkd.gg/support. If you still need help, please contact our support team: support@crkd.gg

LIMITED WARRANTY

CRKD warrants to the original consumer purchaser that product will be free from defects in materials and/or workmanship for the length of time specified in the warranty period from the date of purchase, this being 2 Years, as set forth at www.crkd.gg/warranty.

AUSTRALIAN WARRANTY

These goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. If purchased in Australia or New Zealand, this product comes with one year (12 months) warranty from date of purchase. Defects in the product must have appeared within one year from date of purchase, in order to claim warranty. All warranty claims must be facilitated back through the retailer of purchase in accordance with the retailer's returns policy and procedures. Any expense incurred as a result of returning the product to the retailer of purchase is the full responsibility of the customer.

Bluemouth Interactive, Level 2, 2 Darling Street, South Yarra, VIC 3141. Phone: (03) 9867 2666
Email: Support@bluemouth.com.au. Visit: www.bluemouth.com.au

USE AND HANDLING

- Before use, check that there is plenty of space around you.
- When using the controller, grip it firmly and make sure it cannot slip out of your hand.
- If using a controller that is connected to the console with a cable, make sure that the cable will not hit a person or object. Also take care to avoid pulling out the cable from the console.

EXTERIOR PROTECTION

Follow the instructions below to help prevent the product exterior from deteriorating or becoming discolored. Do not place any rubber or vinyl materials on the product exterior for an extended period. Use a soft, dry cloth to clean the product. Do not use solvents or other chemicals.

SAFETY

- Do not handle damaged or leaking lithium-ion batteries.
- If you come into contact with material from a leaking battery, take the following actions: If the material gets into your eyes, do not rub, instead immediately flush your eyes with clean water and seek medical attention.
- If the material comes into contact with the skin or clothes, immediately rinse the affected area with clean water. Consult your physician if inflammation or soreness develops.
- Avoid prolonged use of this product. Take a break at about 30-minute intervals.
- Stop using this unit immediately if you begin to feel tired or if you experience discomfort or pain in your hands or arms during use. If the condition persists, consult a doctor.
- This product is intended for use with your hands only, do not bring it into close contact with your head, face or the bones of any other part of the body.
- Never disassemble or modify the product.
- Do not expose the product to high temperatures, high humidity or direct sunlight.
- Do not allow the product to come into contact with liquids.
- Do not put heavy objects on the product.
- Do not throw or drop the product or subject it to strong physical shock.
- Do not touch the ports or insert any foreign objects into them.

COMPLIANCE STATEMENTS

FCC STATEMENT: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help.

ISED STATEMENT: This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s).

Operation is subject to the following two conditions:

This device may not cause interference.

This device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil contient des émetteurs/récepteurs exemptés de licence qui sont conformes aux flux RSS exemptés de licence de Innovation, Science et développement économique Canada. L'exploitation est soumise aux deux conditions suivantes: Cet appareil ne doit pas causer d'interférences. Ce dispositif doit accepter toute interférence, y compris toute interférence pouvant causer un fonctionnement indésirable du dispositif.



Freemode Go LLC hereby declares that this product follows the essential requirements and other provisions of EMC Directive 2014/30/EU and RED directive 2014/53/EU. The full text of the EU Declaration of Conformity is available at the following internet address: www.crkd.gg/docs



The UKCA (UK Conformity Assessment) mark is a declaration from the manufacturer that the product meets applicable UK regulations for health, safety, and environment protection.



The crossed-out wheeled bin symbol marked on this product signifies that it must not be disposed of with regular household waste and needs to be taken instead to an appropriate collection point.



The Regulatory Compliance Mark is a visible indication of a product's compliance with all applicable ACMA (Australian Communications and Media Authority) regulatory arrangements, including all technical and record-keeping requirements regarding the electrical safety and/or electromagnetic compatibility (EMC).

© 2024 Freemode Go, LLC. All rights reserved. CRKD, ATOM and the CRKD logos are trademarks of Freemode Go, LLC. All other trademarks are owned by their respective owners. THIS PRODUCT IS NOT ENDORSED OR LICENSED BY NINTENDO.



MANUFACTURED BY
FREEMODE GO LLC
3142 Constitution Drive,
Livermore, CA 94551, USA

EU AUTHORIZED REPRESENTATIVE (2019R1020)
AR Service, 77 Camden Street Lower,
Dublin, D02 XE80, Ireland

UK AUTHORIZED REPRESENTATIVE
FREEMODE GO LTD
Unit 19 Hither Green Industrial Estate,
Clevedon, Somerset, BS21 6XU, UK