








Simple instructions in English						
						
Ensure the system version of your android device be above android 9.0, and the latest version of 'Google™ Find my device' App be installed.	Please check your android device to ensure the Bluetooth function and location function of it have been enabled and working well.	Press the power button once to turn on your loshall anti-lost device.	Place the activated loshall anti-lost device near your android device , tap on the 'connect'in the appeared pop-up.	Follow the on-screen instructions, tap on the "Agree and continue".	Tap on the "Done" to complete pairing and binding.	Or tap on the "Open the app" to turn on the "Find my device" app to apply finding.
Instructions faciles version française Assurez-vous que la version du système de votre appareil Android est supérieure à Android 9.0 et que la dernière version de l'application « Localiser mon appareil » est installée. Vérifiez que les fonctions Bluetooth et localisation de votre appareil Android sont activées et fonctionnent correctement. Appuyez une fois sur le bouton d'alimentation pour activer votre dispositif anti-perte Loshall. Presiona el botón de encendido una vez para activar tu dispositivo anti-pérdida Loshall. Coloque el dispositivo anti-pérdida loshall activado cerca de tu dispositivo Android y toca "Conectar" en la ventana emergente que aparece. Suivez les instructions à l'écran et appuyez sur « Accepter et continuer ». Appuyez sur « Terminé » pour finaliser la connexion et l'appairage. Ou appuyez sur « Ouvrir l'application » pour lancer l'application « Localiser mon appareil » et commencer à l'utiliser.						
Instrucciones de uso claras y concisas Asegúrate de que la versión del sistema de tu dispositivo Android sea superior a Android 9.0 y que la última versión de la aplicación "Encontrar mi dispositivo" esté instalada. Verifica que las funciones de Bluetooth y ubicación de tu dispositivo Android estén activadas y funcionando normalmente. Presiona el botón de encendido una vez para activar tu dispositivo anti-pérdida Loshall. Coloque o dispositivo anti-perda loshall ativado perto do seu dispositivo Android e toque em "Conectar" na janela pop-up que aparece. Siga as instrucciones en pantalla y toca "Aceptar y continuar". Toca "Listo" para completar el emparejamiento y la vinculación. O toca "Abrir la aplicación" para iniciar la aplicación "Encontrar mi dispositivo" y comenzar a usarla.						
Instruções de operação claras e concisas Certifique-se de que a versão do sistema do seu dispositivo Android seja superior ao Android 9.0 e que a versão mais recente do aplicativo "Encontrar meu dispositivo" esteja instalada. Verifique se as funções Bluetooth e de localização do seu dispositivo Android estão ativadas e funcionando normalmente. Pressione o botão de energia uma vez para ligar seu dispositivo anti-perda Loshall. Coloque o dispositivo anti-perda loshall ativado perto do seu dispositivo Android e toque em "Conectar" na janela pop-up que aparece. Siga as instruções na tela e toque em "Aceitar e continuar". Toque em "Concluído" para finalizar o pareamento e a vinculação. Ou toque em "Abrir o aplicativo" para abrir o aplicativo "Encontrar meu dispositivo" e começar a usá-lo.						
Четкие и краткие инструкции по эксплуатации Убедитесь, что версия системы вашего устройства Android выше Android 9.0 и установлена последняя версия приложения «Найти устройство». Проверьте, что функции Bluetooth и геолокации на вашем Android-устройстве включены и работают нормально. Однократно нажмите кнопку питания, чтобы включить ваш антипотерейку Loshall. Поместите активированное устройство loshall против потери рядом с вашим Android-устройством и нажмите «Подключить» во всплывающем окне. Следуйте инструкциям на экране и нажмите «Согласиться и продолжить». Нажмите «Готово», чтобы завершить сопряжение. Или нажмите «Открыть приложение», чтобы запустить приложение «Найти устройство» и начать его использовать.						
明確で簡潔な操作手順 AndroidデバイスのシステムバージョンがAndroid 9.0以上であることを確認し、「デバイスを探す」アプリの最新バージョンがインストールされていることを確認してください。 AndroidデバイスのBluetooth機能と位置情報機能が有効で正常に動作しているか確認してください。 ロスホール紛失防止デバイスの電源を入れるには、電源ボタンを一度押してください。 起動したloshall紛失防止デバイスをAndroidデバイスの近くに置き、表示されるポップアップで「接続」をタップします。 画面の指示に従い、「同意して続ける」をタップします。 「完了」をタップしてペアリングとバインディングを完了します。 または「アプリを開く」をタップして「デバイスを探す」アプリを起動し、使用を開始します。 FCC Statement 1.This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1)This device may not cause harmful interference. (2)This device must accept any interference received, including interference tha may cause undesired operation. 2.Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested ad found to comply with the limits for a class B digital Device,pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.						

قۇچۇچىمۇ ئۆزىنىڭ ئىشلىتىش ئورنىنى ئۆزگەرتىشكە بولىدۇ.	برقلىق قۇچۇچىمۇ ئۆزىنىڭ ئىشلىتىش ئورنىنى ئۆزگەرتىشكە بولىدۇ.	برقلىق قۇچۇچىمۇ ئۆزىنىڭ ئىشلىتىش ئورنىنى ئۆزگەرتىشكە بولىدۇ.	برقلىق قۇچۇچىمۇ ئۆزىنىڭ ئىشلىتىش ئورنىنى ئۆزگەرتىشكە بولىدۇ.	برقلىق قۇچۇچىمۇ ئۆزىنىڭ ئىشلىتىش ئورنىنى ئۆزگەرتىشكە بولىدۇ.	برقلىق قۇچۇچىمۇ ئۆزىنىڭ ئىشلىتىش ئورنىنى ئۆزگەرتىشكە بولىدۇ.	برقلىق قۇچۇچىمۇ ئۆزىنىڭ ئىشلىتىش ئورنىنى ئۆزگەرتىشكە بولىدۇ.
---	--	--	--	--	--	--

Loshall Anti-lost Device

(Google™ Android Version)

User Manual



04 To pair by manual

If you missed the fast pairing pop-up,you can set up it by manual.

1. Enable lost mode

In the "Google™ Find My Device" app,select this device and tap on "Mark as lost" to enable Lost Mode.

Then add your contact information and you will be notified once it is lost and located by the Google™ Find my device network.

2. Location Sharing
Lauching the "Google™ Find My Device" App, and select this product ,then tap on the "Share Device".

3. Pair and bind this device to other android devices
To remove this device from the bound android device firstly and reset it.

After complete this process,you can restart this product, and then pair and bind it other android devices.

4.7 Click on it and follow the on-screen instructions to complete the connection.

07 FCC Statement

FCC Statement

1.This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference.

(2)This device must accept any interference received, including interference tha may cause undesired operation.

2.Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested ad found to comply with the limits for a class B digital Device,pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

01	Before you start
----	------------------

1. Before you start.

2. Getting started.

3. Fast pairing way.

4. To pair by manual.

5. Verify position and trajectory.

6. About Google™ Find My Device.

7. FCC Statement.

8. About Battery Usage and Disposal.

01	Before you start
----	------------------

This device is a smart finder that uses Google's Find My Device service,paired with the "Google™ Find My Device" app on your android devices to quickly and securely locate your personal items on Google™ Maps.All location information remains private,even Google™ cannot access it.

1.1 This device only supports the "Google™ Find My Device" app .Please ensure to download and install the latest version of "Find my device"App from the Google™ Play store.

1.2 This device is compatible only with android devices running android 9 or higher.

1.3 Please check your android device and ensure the bluetooth function and location function of it have been enabled.

05 Verify position and trajectory

5.1 Once this device is left behind and it is no longer in the range of your android device,you will receive a pop-up notification on the screen of your android.

5.2 When this device is left out of your sight but it is nearby.

Launch the "Find my device" app,find the bound device from the list,and tap on the "Play Sound" on the present page to make it beep.

Look for this device following the sound and tap on the "Stop Sound" to stop the beeps once you find it .

02	Getting started
----	-----------------

2.1 Power on
Press the power button for once to turn on this device.

2.2 Power off
Press the power button twice rapidly, and on the third press, hold it down continuously until you hear the power off sound.

2.3 Check the device's working states
Double-click the power button of the device.

When you hear a confirmation sound, this indicates that the device has been successfully activated and is now in its normal operating state.

2.4 Factory resetting
Press the power button four times rapidly, and on the fifth press, hold it down continuously until you hear the reset sound.

5.3 Locate far away

To launch the "Find my device" app,navigate to the list and select this device byscrolling or tapping.

Upon selection, the screen presents a map interface that indicates either this device's live location (if online) or its last known position (if offline). The map automatically adjusts its scale to focus on the area where this device is situated and displays a corresponding marker.

Location updates occur in real time if this device is within the coverage of the Find My Device network (i.e., there are nearby Android devices assisting with location updates). Should the location not be updated, the screen will indicate "Last updated X minutes ago".

Select the "Navigation" or "Directions" icon on the map, and the application will redirect you to Google™ Maps, providing detailed directions to the location of your belongings

08 About Battery Usage and Disposal

About Battery Usage and Disposal

Our products feature various battery types and models (e.g., coin cells or rechargeable batteries) tailored to design, usage, and needs; please verify specifications before use.

Some products contain coin batteries—store them securely to prevent children from accessing, dismantling, or swallowing them; seek immediate medical help if ingested.

For replaceable batteries, use proper tools for careful removal, ensure correct polarity, and retain the manual for reference.

We prioritizes environmental protection and circular economy principles. Dispose of used batteries and packaging responsibly per local regulations (e.g., EU WEEE Directive), avoiding waste to reduce carbon emissions and pollution. Utilize certified recycling facilities to support sustainability.

Contact us support for assistance. We are not liable for issues from improper disposal.



Warning: Don't ingest battery; Chemical burn hazard.

Choking hazard

This device may contain a coin cell battery. Keep batteries away from children.

Do not ingest battery if ingested or placed inside body, seek medical attention immediately. Ingesting can cause severe chemical burns in just two hours and result in serious injury or death.If the battery compartment does close securely,stop using the device and keep away from children.

This device,the battery compartmentdoor,the battery and case may present a choking hazard or cause other injury to kids.Keep these items away from kids.

03	Fast pairing way
----	------------------

3.1 Press the power button for about 3s to activate this device.

3.2 Put the activated device close to your android device.

3.3 One pop-up will appear on your screen,tap the "connect" in it.

3.4 Follow the on-screen instructions, tap on the "Agree and continue".

3.5 And then ,tap on the "Done" to complete pairing and binding.

3.6 In the "Google™ Find My Device" app,select this device to customize the device name and category.

About Google™ Find My Device

This product leverages the Google™ Find My Device network and Android ecosystem to locate items, utilizing crowdsourced data from nearby Android devices to provide real-time or last-known locations.

Google™ and Find My Device are registered trademarks of Google™ LLC, protected under intellectual property laws, and may not be used without authorization.

Adhering to Google's privacy policies, user location data is encrypted and used solely for locating purposes, not shared with third parties. We explicitly warn: this product is intended solely for lawful item tracking; using it to track individuals is strictly prohibited and may violate applicable laws, with users bearing full responsibility. For privacy, regularly review device status and settings. Visit findmydevice.google.com for details. We are not liable for issues arising from misuse or non-compliance with Google's terms.