

深圳市三米智能有限公司

物料名称

## 妙控板-说明书

## 材质工艺

105克金东太空梭哑粉纸

专色印刷

PANTONE Cool Gray 11C 

版本号	修改时间	修改内容
V1.0	2024.04.16	创建文档
V1.1	2024.05.21	修改内容
V1.2	2024.05.21	缩小尺寸 修改内容

## 修改记录

# Multi-Function Gesture Trackpad Operating Manual

## 多功能手势触控板操作说明书

Please read instructions carefully before use

使用前请仔细阅读说明书

### 欢迎使用多功能手势触控板

多功能手势触控板，本产品配备USB2.4G接收器/Type-c数据线，请使用USB接收器或数据线连接您的电脑。

### 系统版本要求

若您使用多功能手势触控板及其完整功能，请将Mac更新至最新版本的Mac OS(最低要求OSX10.11)。若要更新至最新版本的Mac OS，请选取苹果菜单>App Store来查看是否有更新。按照屏幕指示更新Mac OS。

### 多功能手势触控板与MAC连接方式：

若要将多功能手势触控板与Mac连接，请使用随附的USB接收器插入Mac主机中(开关往左边拨)/或者将TypeC线插入触控板的Type-c端口，同时将另一端插入Mac主机的Type-C端口上。然后触控板的绿色指示灯内亮，触控板将自动与Mac连接。

### MAC手势设置步骤：

- ① 打开“系统设置”。
- ② 点击“触控板”。
- ③ 点击设置“光标与点按”。
- ④ 点击设置“滚动缩放”。
- ⑤ 点击设置“更多手势”。

### 设置“启用拖移”步骤：

- ① 打开>“系统设置”>点击“辅助功能”。
- ② 指针控制>触控板选项>启动使用触控板拖移。
- ③ 拖移样式中选择“使用三指拖移”，点击“确认”。

### Windows手势设置步骤

Windows系统可以通过USB接收器/数据线任一方式连接。

- ① USB连接：开关往右边拨动，请将接收器插入电脑中。
- ② 有线连接：请将开关往右拨，插入数据线即可。

待机超过10分钟后，需要按压唤醒使用本产品。

### 使用多功能手势触控板

多功能手势触控板有一个Force Touch表面，用于移动鼠标指针及执行手势。若要设置手势及设定其他选项，请选取苹果菜单>“系统设置”然后点按“触控板”。将多功能手势触控板放在平稳的水平面上。移动鼠标指针或执行手势时，您可以将手舒适地搭在五指触控板上并在其表面上轻轻地滑动手指。

### 单指操作

**打开文件**  
单指双点

**桌面切换**  
五指左右滑动

**打开启动台**  
五指合握

**显示桌面**  
五指向外张开

### 双指操作

**翻动页面**  
双指上下轻扫

**切换页面**  
双指从边缘左右

**显示通知中心**  
双指左右轻扫

**放大**  
双指轻拉

**缩放**  
双指合握

**智能缩放**  
双指双指轻拉轻转

**旋转图片**  
双指旋转

### 多指操作

**选中文本**  
五指滑动

**拖动页面**  
五指拖拽

**显示特定窗口**  
四指下滑

**打开调度中心**  
四指上滑

### 清洁多功能手势触控板

请使用不起绒的布清洁触控板的外部。请勿使用化学物品擦拭产品。

### 人体工程学

使用多功能手势触控板时，请注意找到舒适的坐姿，不时变换身体姿势，时常休息一下，这样可避免。

### 更多信息

有关使用触控板的更多信息，请打开“Mac帮助”并搜索“触控板”。

### Windows触控板手势说明

**点按**  
单指轻点

**拖动文件**  
双指不放

**辅助点按（右键点按）**  
双指点按或轻点

**滚动**  
两指上下左右滑动

**缩放**  
双指捏合

### 三指或四指手势可在系统重新设置，路径如下：设置>蓝牙和其他设备>触控板

**选中文本**  
三指滑动

**显示桌面**  
三指下滑

**切换应用**  
三指左滑

**切换应用**  
三指右滑

### 产品保修卡

感谢您购买使用本产品,为了您能享受更好的服务,请您仔细阅读以下内容并妥善保管好此保修卡。本公司出品的产品在正常使用情况下如发生非人为故障,客户可凭此保修卡及有效购买凭证向原经销商申请维修服务,但不包含以下情况:

- 1.人为因素造成的损坏,包括不按说明书操作引起的故障,或因保管不善造成产品撞击、跌落、折弯等引起的损坏(产品表面有明显磨损痕迹除外);
- 2.在保修期外行维修或造成或因非官方维修站点维修所引起的故障;
- 3.用户无法提供产品保修卡及有效购买凭证;
- 4.对购买已完成或产品信息等人为涂改的;
- 5.超出产品保修期限;

### 产品清单

多功能手势触控板

Type-C数据线

USB接收器

转接头 (Type-C转USB)

说明书

使用指南

产品型号	用户姓名	联系电话	购买时间	商家盖章
用户地址:				

(注:用户未能提供购买日期凭证者以产品出厂日期为准)

### 产品合格证

本产品经质量检验合格

产品合格证

质检员: 01

Made in China

# Multi-Function Gesture Trackpad Operating Manual

## 多功能手势触控板操作说明书

### Welcome to Multi-Function Gesture Trackpad

Multi-function gesture trackpad is equipped with USB2.4G receiver / type-c data cable. Please use USB receiver or data cable to connect your Computer.

### System Version Requirement

To use trackpad and its full functionality, please update your Mac to the latest version of mac OS (minimum OSX 10.11 required).

To update to the latest version of mac OS, select Apple menu -> App Store to check for updates - follow the instructions to update mac OS.

### How to connect the trackpad to MAC.

To connect the trackpad to a Mac, use the included USB receiver to plug into the Mac (flip the switch to the left) or plug the type-c cable into the trackpad's type-c port, and plug the other end into the Mac port. The green light flashes, indicating the trackpad is connecting to the Mac automatically.

### MAC Trackpad Gesture Description

#### One Finger Operation

- Open file**  
One-finger double-tap
- Two Finger Operation**
  - Flip the page**  
Slide up and down with two fingers
  - Switch page**  
Slide left and right with two fingers
  - Display notification center**  
Double finger slide from left edge
  - Zoom in**  
Two finger spread
  - Zoom out**  
Two Finger Double Tap and rotate
  - Smart Zoom**  
Two Finger Double Tap and rotate
  - Rotating pictures**  
Three-finger side up

### Windows trackpad gestures explained

- Tap**  
Tap with one finger
- Drag and drop files**  
Two-finger tapping
- Auxiliary tap (right-click)**  
Two-finger tapping
- Scrolling**  
Slide two fingers up and down, left and right
- Zoom**  
Two finger spread or pinch
- Three- or four-finger gestures can be reset in the system by going to System Settings > Devices > Trackpad**
- Selected text**  
Three-finger side up
- Show Desktop**  
Three-finger side down
- Switching Applications**  
Three-finger side left
- Switching Applications**  
Three-finger side right

### Multi-Finger Operation

- Select text**  
Three-finger slide
- Drag the page**  
Four-finger tap slide
- Show specific windows**  
Four-finger slide down
- Open Dispatch Center**  
Four-finger slide up
- Desktop switching**  
Four-finger left/right side
- Open the launchpad**  
Gather your fingers.
- Show desktop**  
Spread your fingers outwards.

### MAC gesture setting steps:

- Open "System Settings"
- Click "Trackpad"
- Click to set "Point & Click"
- Click to set "Scroll & Zoom"
- Click to set "More Gesture"

### Windows gesture setup steps

Windows system can be connected by USB receiver and data cable.

- USB receiver connection: Please flip the switch to the right and plug the receiver into the computer.
- USB cable connection: please flip the switch to the right and insert the usb cable to both side.

### After more than 10 minutes of standby, you need to press to wake up the trackpad.

Please read instructions carefully before use

使用前请仔细阅读说明书

### Product Warranty Card

Thank you for purchasing this product, in order to provide you with better service, please read the following content and keep this warranty card. If a non-human fault occurs during the daily use of the product, you can show this warranty card and a valid proof of purchase to the original dealer to apply for warranty service. However, the following are not included.

- Damage caused by human factors, including failure caused by not operating in accordance with the manual, or due to poor storage of the product caused by impact, falling, bending and other damage (product surface has obvious wear marks, etc.).
- Failure caused by private disassembly, repair or modification, or maintenance by non-special maintenance sites.
- The user is unable to provide product warranty card and valid proof of purchase
- Artificially altered purchase records or product information.
- Beyond the product warranty period.

### Product List

Multi-Function Gesture Trackpad

Type-C Data Cable

USB Receiver

Adaptor (Type-C to USB)

User Manual

### Certificate of Conformity

Product Model	User Name	Contact Number	Time of Purchase	Merchant Stamp
User Address				

### EC Declaration

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
 (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference by or not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

### Certificate of Conformity

This product has passed the quality inspection

Quality Inspector: 01

Made in China