



Smart Switch Gen3



THIRDREALITY

Accessories



Screw*2



Fixator*2



Thin rubber ring*2



Thick rubber ring*2




Battery*2

Setting up your Smart Switch

Third Reality Smart Switch Gen3 can work with both toggle and rocker style switches.


Step 1:

Remove screws from faceplate.



Step2:

Insert with new screws and attachment assembly as follows.





In most case, you need to combine fixator with thin rubber ring. However, you can also use fixator only or combine fixator with thick rubber ring to adjust the thickness of attachment assembly.

Step 3:


Place two AA batteries inside the Smart Switch. Check the Smart switch clip position with your switch panel. If your toggle switch lever or rocker switch board is up/down, you need to match the Smart Switch clip position as up/down.

For example:



When switch lever or switch board is up, make sure the Smart Switch clip position is up, you can manually quick press the switch button to adjust the clip position if necessary.

Step 4: Place the Smart Switch on the top of your existing switch, follow by the “Up” direction marked on the back of the Smart Switch.



Using your Smart Switch

1. Follow instructions in the Amazon Alexa App to set up your Amazon smart speaker
2. Configure Third Reality Smart Switch Gen3 with Amazon smart speaker, by saying “Alexa, find my device.”



3. Go to devices page of Amazon Alexa App to rename the smart switch and create routines.

LED Light Status Indication

Rapid blinking – Smart Switch is under pairing mode.

Slow blinking – Smart Switch is reconnecting the internet.

Double Blinking – Smart Switch is low battery, please replace the batteries.

Troubleshooting

1. Inverted On/Off status

If you find that the switch on/off status is inverted, press the Smart Switch button for around 10 to 15 seconds. The status will be corrected once the blue LED lights up, then release the hold.

2. Factory reset

If you need to factory reset the Smart Switch, long press the button more than 30 seconds until the blue LED blinks rapidly.

Limited Warranty

For limited warranty, please visit <https://www.3reality.com/devicesupport>

For customer support, please contact us at info@3reality or visit www.3reality.com

For help and troubleshooting related to Amazon Alexa, visit the Alexa app.