

快速入门指南  
使用前请阅读使用说明书  
HTC NE21

蓝牙  
范围：≈ 10m  
版本：6.0

喇叭  
直径：14.2mm  
阻抗：16Ω

耳机功率  
输入：5V≈30mA  
电池容量：30mAh  
使用时间：≈ 4小时  
充电时间：≈ 1.5小时

充电仓功率  
输入：5V≈300mA  
输出：5V≈60mA  
电池容量：300mAh  
充电时间：≈ 1.5小时  
充电仓充满电时，能给耳机充电约4次

产品规格

型号：HTC NE21

物品清单

充电仓

2 耳机

快速入门指南

USB-C充电线

挂绳

部件

耳机指示灯

多功能触摸键

充电触点

耳机喇叭

充电仓数显屏

Type-C 充电口

取出耳机并配对

如果您第一次使用耳机，请将两个耳机从充电仓中取出，其中一个耳机的LED灯将会交替闪烁白灯和青灯，表示它们处于配对模式。

注：

- 如果耳机未与任何设备配对，打开后会自动进入配对模式。配对成功后，您会听到两声滴响声。
- 如果耳机之前已配对，打开后会自动重新连接。连接时您会听到嘟嘟声。

如何佩戴耳机

1

2

3

4

开机和关机

开机

自动开机：将耳机从充电仓中取出，耳机开机。  
手动开机：长按3秒，耳机开机。

关机

自动关机：耳机放入充电仓中，耳机关机。  
手动关机：长按5秒，耳机关机。

注：当耳机开机后，3分钟未与蓝牙耳机设备配对，便会自动关机；当配对的蓝牙耳机发出信号有效连接而离，且未重新连接时，3分钟后，耳机自动关机。

连接到蓝牙耳机

在您的设备上，打开蓝牙并选择连接“HTC NE21”。

基本操作

L

R

开机/关机

播放/暂停 3s/Ss

上一曲 x2

下一曲 x2

通话模式

接听/挂断电话 x1

退出语音助手 x2s

音乐模式

音量+ x2

音量- x2

上一曲 x3

下一曲 x3

播放/暂停 x1

快进 2s

倒退 2s

清除蓝牙配对历史记录

长按 x5 x5

功能操作

- 暂停/播放：轻触任一耳机一次
- 音量加：轻触右耳机二次
- 音量减：轻触左耳机二次
- 上一曲：轻触左耳机三次
- 下一曲：轻触右耳机三次
- 接听/挂断电话：轻触任一耳机一次
- 通话拒接：按住任一耳机2秒
- 启动语音助手：按住左耳机2秒

注：单耳使用时：按住已开机的耳机2秒，均可激活语音助手

• 游戏模式与音乐模式切换：按住右耳机3秒切换

• 单耳使用时，无法切换游戏模式和音乐模式

注：出厂设置默认为音乐模式

注：通知声音较大的是游戏模式

指示灯显示

耳机指示灯

状态

白灯和白灯交替闪烁

两个耳机：开机  
单耳机：未配对

白灯常亮

充电中

灭灯

配对成功或充满电

充电仓指示灯

状态

常亮

耳机充电中

闪烁

充电仓充电

显示100%

充电仓充满电

如何清除蓝牙配对历史记录

双手同时以下情况：

A：双耳无法配对时，单边音时，双击对号。

B：使用单耳机分别连接不同蓝牙耳机时。

C：清除所有的蓝牙耳机设备。

特别提示：

当单边耳机出现无声，或者无法配对时，请按以下恢复重置操作。

产品中有有害物质名称及含量

产品中有有害物质的名称及含量

部件名称	有害物质						
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬 Cr(VI)	多溴联苯	多溴二苯醚	(PBB)
印刷电路组件	○	○	○	○	○	○	○
外壳等小结构件	○	○	○	○	○	○	○

本表格依据SJ/T 11364的规定编制。  
○：表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。  
×：表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。  
表中标记“×”的部件，皆因全球技术发展水平限制而无法实现有害物质的替代。

印刷电路板组件：包括印刷电路板及其零部件、电子元器件等，根据产品类型不同，您所购买的产品可能不会含有以上所有部件

重要安全说明

在使用本产品之前，请仔细阅读本说明书中的所有安全说明。

常规安全说明

- 小心使用本产品，并将其存放在没有极端温度、高温高压和潮湿的清洁环境中。确保产品存放在不易弯曲或挤压的地方。
- 维修和更换只能由授权的售后服务人员进行。

请勿自行拆卸或更换产品的任何部件，以防受伤或损坏设备。

对产品的任何未经授权的修改都将使保修无效。

- 仅允许蓝牙传输的环境中使本产品。

个人安全说明

- 如果产品有明显缺陷或出现膨胀或温度过高等异常，请勿使用。
- 执行需要全神贯注的高风险任务时，请勿使用本产品。
- 为了保护您的听力，请勿长时间高音量收听
- 请将产品及其它包装放在儿童和宠物接触不到的地方，以防发生吞嚼和窒息等事故

电池安全说明

该产品内置可充电电池，请参阅以下说明，确保安全使用和处置。

- 请勿将产品长时间暴露在热源下，如明火或阳光直射。
- 仅将产品存放在环境温度约为 0 至 35°C（32 至 95°F）的环境中。
- 请勿在产品产生灰尘、烟雾、高温、高压或高温度的环境中使用或存放本产品。
- 保持产品干燥，远离液体或湿气。
- 只能使用经 FCC 或 CCC 认证、输出电压为DC 5V/1A的充电器。
- 充电时不要使用产品。
- 产品充电时间不要超过 8 小时。
- 按照当地的废物管理规定负责责任地处理产品。

法律声明

商标和许可：

HTC和HTC标志为HTC公司的商标。

授权给深圳市卜兰沃德科技有限公司使用。

2025版权©深圳都市卜兰沃德科技有限公司。

本文件仅供参考，不构成任何形式的保证，本公司保留所有权利。

10

11

12

13

14

15

16

<div data-bbox="131 1181 299 1224"> <h1>HTC</h1> <h2>Wireless Earphones 21</h2> </div> <div data-bbox="174 1274 346 1485"> </div> <div data-bbox="192 1545 326 1580"> <h3>Quick Start Guide</h3> <h4>HTC NE21</h4> </div>	<div data-bbox="430 1181 599 1198"> <h3>Product Specifications</h3> </div> <div data-bbox="430 1207 500 1218"> <p>Model: HTC NE21</p> </div> <div data-bbox="430 1233 486 1244"> <h4>Bluetooth</h4> </div> <div data-bbox="430 1252 529 1276"> <p>Range: ≈10 m Version: 6.0</p> </div> <div data-bbox="430 1293 474 1304"> <h4>Speaker</h4> </div> <div data-bbox="430 1310 509 1336"> <p>Diameter: 14.2 mm Impedance: 16 Ω</p> </div> <div data-bbox="430 1351 521 1362"> <h4>Earphone power</h4> </div> <div data-bbox="430 1371 535 1418"> <p>Input: 5 V≈30 mA Battery capacity: 30mAh Battery life: ≈ 4 hrs Charging time: ≈ 1.5 hrs</p> </div> <div data-bbox="430 1433 544 1444"> <h4>Charging case power</h4> </div> <div data-bbox="430 1450 681 1513"> <p>Input: 5 V=300 mA Output: 5 V=60 mA Battery capacity: 300mAh Charging time: ≈ 1.5 hrs Earphone recharges: 4 charges (when case is fully charged)</p> </div> <div data-bbox="422 1586 442 1597"> <p>12</p> </div>	<div data-bbox="797 1181 928 1198"> <h3>What's in the box</h3> </div> <div data-bbox="797 1224 978 1567"> </div> <div data-bbox="722 1586 742 1597"> <p>13</p> </div>	<div data-bbox="1115 1181 1211 1198"> <h3>Components</h3> </div> <div data-bbox="1042 1224 1275 1580"> </div> <div data-bbox="1022 1586 1042 1597"> <p>14</p> </div>	<div data-bbox="1351 1181 1578 1198"> <h3>Take out and pair the earphones</h3> </div> <div data-bbox="1327 1224 1604 1567"> </div> <div data-bbox="1327 1586 1345 1597"> <p>15</p> </div>	<div data-bbox="1654 1181 1875 1198"> <h3>How to put on the earphones</h3> </div> <div data-bbox="1662 1224 1875 1580"> </div> <div data-bbox="1627 1586 1645 1597"> <p>16</p> </div>	<div data-bbox="1951 1224 2175 1580"> </div> <div data-bbox="1927 1586 1945 1597"> <p>17</p> </div>	<div data-bbox="2300 1181 2431 1198"> <h3>Power on and off</h3> </div> <div data-bbox="2250 1224 2483 1580"> </div> <div data-bbox="2227 1586 2248 1597"> <p>18</p> </div>	<div data-bbox="2562 1181 2778 1198"> <h3>Connect to Bluetooth device</h3> </div> <div data-bbox="2562 1224 2778 1580"> </div> <div data-bbox="2533 1586 2553 1597"> <p>19</p> </div>														
<div data-bbox="192 1632 320 1649"> <h3>Basic operations</h3> </div> <div data-bbox="160 1666 358 2030"> </div> <div data-bbox="116 2033 136 2043"> <p>20</p> </div>	<div data-bbox="422 1627 492 1638"> <h3>Key functions</h3> </div> <div data-bbox="422 1645 704 1832"> <ul style="list-style-type: none"> <li>• Play/Pause: Tap either earphone once.</li> <li>• Volume up: Tap the right earphone twice.</li> <li>• Volume down: Tap the left earphone twice.</li> <li>• Play previous track: Tap the left earphone three times.</li> <li>• Play next track: Tap the right earphone three times.</li> <li>• Answer/End call: Tap either earphone once.</li> <li>• Reject call: Press and hold either earphone for two seconds</li> <li>• Activate voice assistant: Press and hold the left earphone for two seconds.</li> </ul> <p>Note: When using a single earphone only, press and hold the active earphone for two seconds.</p> <ul style="list-style-type: none"> <li>• Switch between Game and Music modes: Music mode is the default mode. Press and hold the right earphone for two seconds to switch between modes. (The louder notification sound indicates Game mode.)</li> </ul> <p>Note: Mode switching is disabled when you're using a single earphone only.</p> </div> <div data-bbox="422 1852 704 2030"> <table border="1"> <thead> <tr> <th>Earphone LED</th><th>Status</th></tr> </thead> <tbody> <tr> <td>Blinking white and cyan</td><td>Both earphones: Powered on Single earphone: Unpaired</td></tr> <tr> <td>Solid white</td><td>Charging</td></tr> <tr> <td>Off</td><td>Paired or fully charged</td></tr> </tbody> </table>   <table border="1"> <thead> <tr> <th>Charging case Power display</th><th>Status</th></tr> </thead> <tbody> <tr> <td>Solid</td><td>Earphones charging</td></tr> <tr> <td>Flashing</td><td>Case charging</td></tr> <tr> <td>Shows 100%</td><td>Case fully charged</td></tr> </tbody> </table> </div> <div data-bbox="422 2033 442 2043"> <p>21</p> </div>	Earphone LED	Status	Blinking white and cyan	Both earphones: Powered on Single earphone: Unpaired	Solid white	Charging	Off	Paired or fully charged	Charging case Power display	Status	Solid	Earphones charging	Flashing	Case charging	Shows 100%	Case fully charged	<div data-bbox="722 1627 963 1645"> <h3>How to reset the earphones</h3> </div> <div data-bbox="722 1645 998 1692"> <p>If the earphones fail to pair or reconnect to each other, reset them by tapping both earphones five times simultaneously. Note: Resetting the earphones will clear the Bluetooth pairing history.</p> </div> <div data-bbox="733 1709 984 2015"> </div> <div data-bbox="722 2033 742 2043"> <p>22</p> </div>	<div data-bbox="1022 1627 1243 1645"> <h3>Important Safety Instructions</h3> </div> <div data-bbox="1022 1645 1292 1670"> <p>Carefully read all the safety instructions in this document before using the product.</p> </div> <div data-bbox="1022 1670 1167 1681"> <h4>General safety instructions</h4> </div> <div data-bbox="1022 1688 1292 1830"> <ul style="list-style-type: none"> <li>• Use the product with care and store it in a clean environment that is free from extreme temperature, pressure, and humidity. Make sure that the product is stored in a location where it cannot be bent or squeezed.</li> <li>• Repairs and replacements should only be performed by authorized after-sales service staff. Do not attempt to disassemble or replace any part of the product yourself to prevent injuries or damage to the device. Any unauthorized modification to the product voids the warranty.</li> <li>• Only use the product in environments where Bluetooth transmission is permitted.</li> </ul> </div> <div data-bbox="1022 1830 1170 1841"> <h4>Personal safety instructions</h4> </div> <div data-bbox="1022 1847 1292 1961"> <ul style="list-style-type: none"> <li>• Do not use the product if it is obviously defective or exhibits abnormalities such as bulging or excessive heating.</li> <li>• Do not use the product when performing high-risk tasks that require your full attention.</li> <li>• For your hearing protection, do not listen at high volume for long periods.</li> <li>• Keep the product and its packaging out of reach of children and pets to prevent accidents such as swallowing and choking.</li> </ul> </div> <div data-bbox="1022 2033 1042 2043"> <p>23</p> </div>	<div data-bbox="1327 1627 1467 1638"> <h3>Battery safety instructions</h3> </div> <div data-bbox="1327 1645 1566 1670"> <p>The product has a built-in rechargeable battery. Read the following instructions to ensure safe use and disposal.</p> </div> <div data-bbox="1327 1670 1604 1862"> <ul style="list-style-type: none"> <li>• Keep the product away from prolonged exposure to heat sources such as open fires or direct sunlight.</li> <li>• Only store the product in environments with ambient temperatures of 0 to 35°C (32 to 95°F).</li> <li>• Do not use or store the product in dust-prone, smoke-prone, high-temperature, high-pressure, or highly humid environments.</li> <li>• Keep the product dry and away from liquids or moisture.</li> <li>• Only use an FCC or CCC-certified charger with an output voltage of 5 V/1 A DC.</li> <li>• Do not use the product while charging.</li> <li>• Do not leave the product charging for longer than 8 hours.</li> <li>• Dispose of the product responsibly according to your local waste management guidelines.</li> </ul> </div> <div data-bbox="1327 2033 1345 2043"> <p>24</p> </div>	<div data-bbox="1627 1627 1805 1645"> <h3>FCC ID: 2BHJR-NE21</h3> </div> <div data-bbox="1627 1645 1683 1655"> <h4>FCC Caution</h4> </div> <div data-bbox="1627 1664 1916 1731"> <p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> </div> <div data-bbox="1627 1731 1916 1778"> <p>Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> </div> <div data-bbox="1627 1778 1916 1966"> <p>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> <li>-Reorient or relocate the receiving antenna.</li> <li>-Increase the separation between the equipment and receiver.</li> <li>-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</li> </ul> </div> <div data-bbox="1627 2033 1645 2043"> <p>25</p> </div>	
Earphone LED	Status																					
Blinking white and cyan	Both earphones: Powered on Single earphone: Unpaired																					
Solid white	Charging																					
Off	Paired or fully charged																					
Charging case Power display	Status																					
Solid	Earphones charging																					
Flashing	Case charging																					
Shows 100%	Case fully charged																					