

# SHARPER IMAGE®

## Heat Therapy Wraps and Rechargeable Battery


### User Guide

Thank you for purchasing a Sharper Image Heat Therapy Wrap.  
Please take a moment to read this guide and store it for future reference.


#### BACK WRAP




Place heating area over your back with logo facing out.



Bring the straps around your sides.




Lay the strap with the logo over the other end to close it with the velcro.




Our Back Wrap may also be used in the front to relieve pain from menstrual cramps.

#### SHOULDER WRAP



Place the wrap, logo facing out, so that the cupping of the wrap fits over your shoulder.



Bring the longer strap around your back and under the opposite arm to the front of your chest. Put the longer strap through the loop.



Tighten the strap and bring the velcro back over the strap so the logo is now facing out.




Bring the smaller velcro strap beneath your arm and place it over the wrap as shown. It should fit securely over your bicep.

#### NECK WRAP



Place wrap over back of neck.




Place straps around the neck and over one another to secure the velcro.

#### WRIST WRAP



Place thumb through the slit, with the wrap's logo side facing out.



Wrap the strap around your wrist, making sure to support any area with slight compression.



Lock the strap in place with the velcro at the end of the strap by placing it over the wrap surface.

## KNEE WRAP



Place wrap over knee, making sure the cupping of the wrap goes over the knee cap. Wrap the upper strap around your thigh and close the velcro over the wrap.




Wrap the lower strap around your upper calf and secure the velcro over the top of the wrap.



You may use the wrap over either knee. To do so repeat the same directions on your other knee.


## BATTERY GUIDE

### CONNECT THE CHARGER




### FULLY CHARGE THE BATTERY

Four Blue lights = Full Charge




### REMOVE BATTERY CHARGER PLUG/ CHECK THE BATTERY



#### Click "Power":


Four lights = 100% battery  
Three lights = 75% battery  
Two lights = 50% battery  
One light = 25% battery  
One light [blinking] = Less than 25% battery

### INSTALL POWER PACK



Locate the connector. Plug Power Pack into the connector. Put Power Pack into pocket.

### POWER ON & MAX TEMP SETTING




**To Turn Power On:**  
Press and hold "Power" for 2 seconds until the controller light shows BLUE (100%).

#### ATTENTION


\*Do not turn the power on when brace/glove is folded.

### SELECT HIGH TEMP SETTING




**High Temperature Setting:**  
Click "Power" until the light changes to 75%.

### SELECT MED TEMPERATURE SETTING




**Med Temperature Setting:**  
Click "Power" until the light  
changes to 50%.

### SELECT LOW TEMPERATURE SETTING




**Low Temperature Setting:**  
Click "Power" until the light  
changes to 25%.

### POWER OFF



**To Turn Power Off:**  
Press and hold "Power" for  
2 seconds until all lights are OFF.


### FULLY CHARGE THE BATTERY BEFORE STORING



#### ATTENTION

\*Battery must be fully charged before use.  
\*Battery must be fully charged before it's  
stored, and at least once every 6 months  
of storage thereafter.

### WASH & CARE



**Warning:** *Power Pack must be  
removed from device prior to  
washing.*

#### Spot Cleaning Recommended

- Hang dry
- Do not iron
- Do not use bleach or cleaning  
solvents
- Do not twist or wring

### SPECIFICATIONS

**Charge time:** 2.3 hours

**Output charger:** 8.4V/1A

**PLEASE NOTE:** *This is a personal  
care item and is returnable if in its  
original unopened packaging and  
unused condition.*

### WARRANTY/CUSTOMER SERVICE

Sharper Image branded items purchased from SharperImage.com include a 1-year limited replacement warranty. If you have any questions not covered in this guide, please call our Customer Service department at 1 (877) 210-3449. Customer Service agents are available Monday through Friday, 9:00 a.m. to 6:00 p.m. ET.

**SHARPER IMAGE®**

The SHARPER IMAGE® name and logo are registered trademarks.  
©Sharper Image. All Rights Reserved.