



-
- Battery: 74Wh Lithium ion
 - USB C PD Output: 5V/3A, 9V/3A, 12V/3A, 15V/3A, 20V/3A 60W Max
 - USB C PD Input: 5V/3A, 9V/3A, 12V/3A, 15V/3A, 20V/3A 60W Max
 - USB A Output 1: 9V/2A 18W Max
 - USB A Output 2: 5V/2.4A 12W Max
 - Start Current: 1500A.
 - Peak Current: 3000A

-
- Fully charge the unit before first use or if the unit has not been used for a long time.
 - To maximize battery life, it is highly recommended that you fully charge your battery every three months.
 - Do not attempt to disassemble or replace the battery or batteries.
 - This unit is not intended to be used by people with reduced physical, sensory, or mental capabilities or those who lack experience and knowledge.
 - Children must always be supervised around this unit.
 - When charging the unit, DO NOT expose it to open flames or cigarettes.
 - DO NOT insert foreign objects into the input and output ports.
 - DO NOT move the unit if it is being charged or while it is in use.



DANGER

ELECTRICAL SHOCK

- This product is an electrical device and can cause electric shock or serious injury.
- Do not cut power cords.
- Do not expose the unit to rain or excessive moisture or submerge in water.

EXPLOSION

- Do not attempt to jump start a damaged or frozen battery.
- Use the product only with batteries of the recommended voltage.
- Use the product only in well-ventilated areas.

FIRE

- This product is an electrical device. It emits heat and can cause burns.
- Do not cover the product.
- Do not smoke or allow any source of electrical spark or fire during operation.
- Keep the product away from combustible materials.

EYE INJURY

- Wear eye protection when operating the product.
- Battery acid can cause eye and skin irritation.
- In the case of contamination of eyes or skin, flush affected areas with running clean water and contact poison control immediately.

EXPLOSIVE GASES

- Batteries generate explosive gases during normal battery operation.
- To reduce the risk of battery explosion, follow all safety information instructions and those published by the battery manufacturer.
- Review the warning labels on these products and your engine.



The Powerboost 1500 Lithium Jump Starter contains a 74Wh lithium battery pack. Charge the product with the included 60W silicone cable and a PD 60W wall adapter (not included) or a PD car charger (not included).

Note: Fully charge the battery at least once every three months. Overloading the battery or storing it for too long without charging it may cause permanent damage.



Step 1: Charge the Powerboost 1500 Lithium Jump Starter.


- The Powerboost 1500 lithium jump starter comes partially charged out of the box and needs to be fully charged prior to first use.
- We recommend not charging and discharging the unit at the same time.
- The time to recharge the unit will depend on the power supply used.
- As a guideline, a PD 60W wall adapter takes approximately 50 minutes to charge from 0 to 80%.


Step 2: Connect to the battery.

- Connect the battery clamps to the unit by connecting to the 12V out port.
- Connect the positive (red) battery clamp to the positive (+) battery terminal.
- Connect the negative (black) battery clamp to the negative (-) battery terminal or vehicle chassis.
- When disconnecting, disconnect in the reverse sequence, removing the negative first.

Step 3: Jump starting

- Before beginning, make sure all the vehicle's power loads are turned off before attempting to jump start the vehicle.
- Turn on the power button.
- Try starting the vehicle. Most vehicles will immediately start. Some vehicles may take up to 30 seconds before starting.
- If the vehicle does not start right away, wait 30 seconds and try again.
- Do not attempt more than three jump starts within a 15 minute period.
- Allow the Powerboost 1500 to rest for 15 minutes before attempting to jump start the vehicle again.
- Once you have started your vehicle, disconnect the cable clamps and remove the Powerboost 1500.

- 
- Before cleaning, ensure the unit is switched off and disconnected from the power supply.
 - Clean with a damp cloth only.
 - Do not use any abrasive cleaners or harsh chemicals.
 - Ensure all components are completely dry before storing the unit.

- 
- If the Powerboost 1500 temperature climbs higher than 55 degrees or lower than -10 degrees, the unit will immediately stop and a warning icon will flash at 1 second intervals.
 - The Powerboost 1500 is designed with 100% maximum safety protection. Manual override (removing all protections) to force jump start engines is not possible.
 - The Powerboost 1500 is designed to jump start 12V lead acid batteries down to 2V only.

