



Rabbit Alarm Clock

User's Manual

Please remove the protective film from the mirror surface when using the clock.

We value every customer and commit to providing **a lifetime warranty** service to each and every one of them. To activate lifetime warranty, please visit: www.jall-us.com

Missing accessories or any other problems, please contact us:

ThreeDucksDirect@outlook.com

Objects the package contains

This product is packed in a color box, which contains:

1x Rabbit alarm clock


1x power adapter

1x Type-C data line

1x instruction manual



Product appearance & button introduction



① Time button


② Alarm button

③ Volume up button

④ Volume down button

⑤ Reset button

Product appearance & button introduction



⑥ Type-C power input

⑦ Temperature sensor


⑧ Alarm Horn

⑨ Snooze / Night light

Pre-use setting

Power on for the first time

- Remove the protective film from mirror surface. Connect Type-c power plug to the input port of alarm clock. And then connect the USB plug to the adapter. At last plug the adapter into 100V-240V home socket. As shown in the following figure:



Note:

- Rabbit alarm clock is transported in the off state. It will be turned on when powered on for the first time.
- Rabbit alarm clock has a built-in lithium battery, which can work by connecting to the power adapter, or it can work independently after being fully charged.

Time setting

When powered on for the first time, the time shows AM 12:00

1. Long press TIME button for 2s to enter time setting


- In time setting mode, the number will blink. Click **VOLUME UP** and **VOLUME DOWN** button to set current value. Then click **TIME** button to confirm.
- The setting sequence: year - month - day - hour - minute - temperature display mode(°C/°F).

2. Click TIME button to switch 12/24-hour display

- Click **TIME** button to switch 12/24-hour display after time setting is over.

Note:

- The day of week will be automatically adjusted according to the year, month and day. Do not need to set it yourself.
- Temperature display mode switching can only be set in time setting mode, which can be set in Celsius or Fahrenheit




Alarm setting

Long Press **ALARM** button for 2s to enter alarm setting

- In alarm setting mode, the number will blink. Click **VOLUME UP** and **VOLUME DOWN** button to set the value you need. Then press **ALARM** button to confirm.
- The setting sequence: hour - minute - working mode(weekday/all 7 day).

Note:

- Alarm will turn on automatically after alarm setting is over. When alarm is turned on, alarm icon will be displayed on the screen.
- Alarm function can only be turned on or off by clicking the alarm button.




Volume setting

Click VOLUME UP and VOLUME DOWN button to set an appropriate Key-press volume and alarm volume

- In time display state, click **VOLUME UP** and **VOLUME DOWN** button to set an appropriate Key-press volume and alarm volume.

Note:

- There is total 4 level volume that you can adjust.
- Alarm volume is consistent with Key-press volume and cannot be set separately.



How to SNOOZE or TURN OFF alarm

After the alarm clock is turned on, the alarm clock will ring at the preset time: when it comes to the setting time of the alarm, it will start to ring and wake you up. When the alarm goes off, you can do the following:

1. Snooze

- Click **SNOOZE** button for one time when the alarm goes off, which will enter “Snooze Mode”. And the alarm icon will blink. Alarm will go off again after 9 minutes.

Note: It's 3 times that you can enter snooze mode in one alarm.

2. Stop today's alarm.

- When alarm goes off, click any button at the bottom of the alarm clock to stop today's alarm and it will go off on the next setting day.
- When alarm goes off, double click **SNOOZE** button to stop today's alarm and it will go off on the next setting day.
- When in “Snooze Mode”, click **SNOOZE** button for one time to stop today's alarm and it will go off on the next setting day.



Night light mode

1. Night light mode

- In time display state, press **SNOOZE** button to turn on the night light.

Night light brightness adjustment

2. Night light brightness adjustment

- In night light mode, long press **SNOOZE** button for 3s, and the night light brightness will change from bright to dark / dark to bright(total two level).


Note: Night light will be stay on when you turn it on. And it will never be turn off automatically until you turn it off or it's out of power.



Trouble Shooting

1. what should I do when rabbit alarm clock's system crashes?

- If you encounter a system crash or an unsolvable problem, first try clicking the reset button at the bottom of the alarm clock with a small stick. After clicking, the alarm clock will return to a initial state(screen displays 12 am). And you need to reset the time, alarm and other functions.



2. What if the reset button can't solve the problem?

- Missing accessories or any other problems, please contact us:
ThreeDucksDirect@outlook.com
- To activate lifetime warranty, please visit: www.jall-us.com