

Smart Sound Machine User Guide

Cocoon Pro 2

Relax More, Sleep Better

Start Your New Sleep

Step 1: Download and Register the APP


Download the Hotmoon app from the Apple App Store or Google Play, then create or log in to your account.

NOTE:

- For Android versions below 12, geographic location permission is required to connect via Bluetooth. This will not be used to record personal data.
- The Hotmoon app is regularly updated; follow in-app instructions for any changes.




APP download



Step 2: Plug it in

Connect the device to a power adapter with an output voltage of 5V1A using the USB - C cable.



Step 3: Connect Your Cocoon Pro 2

Tap the device's power button to turn it on. Open the Hotmoon APP and follow the in-app steps to connect your Cocoon Pro 2.

NOTE:

- Enable the Bluetooth on your phone.



Things to Try

1. Customize 3 Sound Buttons

Tap "Edit" on the "My Sounds" page, select a sound to replace, choose your preferred sound from the Library to add, and save — your device will sync automatically.

2. Customize a Routine

Create your routine by modifying defaults or customizing with library sounds. Once set up, tap routine button "⌚" to start your routine—No Phone Required.

3. Adjust Clock Brightness

Tap the settings icon "⚙️" in the upper right corner of the "My Plan" page to adjust.


4. Bluetooth Speaker Mode

Press the mode switch button underneath. After "Bluetooth speaker mode" plays, connect to "Cocoon Pro 2" in Bluetooth settings.

5. Adjust the Voice Prompt Volume

After pairing, tap the settings icon "⚙️" on the "My Plan" page → "Prompt Tone Volume" and adjust the slider.

Buttons



1. Routine

- Tap when you're ready to rest. (It will seamlessly transition through each step of your Routine as programmed in the app.)
- Once your Routine is playing, tap this button to skip to the next step.
- Sound, light, and duration can be customized in the app, and up to 8 combos can be set.

2. Noise Sounds

Tap to switch between up to 9 sounds customized in the app.

4. Music

Tap to switch between up to 9 sounds customized in the app.

6. Timer

Tap: 45m/90m/8h/Timer off

3. Nature Sounds

Tap to switch between up to 9 sounds customized in the app.

5. Power

Tap: turn on, or switch to standby mode if already active.

7. Volume -


Tap: Volume down.
Tap over 2s: Volume down continuously.



10

8. Volume +

Tap: Volume up
Tap over 2s: Volume up continuously



11

9. Light

Tap: Cycle through 7 colors and off.
Hold 2s: Turn off the light.

10. Clock

After pairing it with your phone, the clock will automatically set its time. You can adjust the brightness and clock display period in the app.

11. Mode Switch

Press to switch between the Sound Machine Mode and Bluetooth Speaker Mode. The default is Sound Machine Mode. Long press 3s to enter the pairing status.

NOTE:

- Sound Machine Mode: The device defaults to this mode. You can customize the Routine and three sound buttons in the app. Additionally, the device can be controlled through the app.
- Bluetooth Speaker Mode: The device can also function as a Bluetooth speaker. In this mode, you can play all audio from the 'Cloud' column through the device.

⚠️ Safety Warning

- Please always keep the device at least one meter away from children as the cord can pose a strangulation hazard.
- This product is not waterproof. Do not use it near or place in water.
- Do not place this device aloft. When placing it on the table, please avoid the edges to prevent it from falling down, which might damage the device and also get potential hurt.

FCC Warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and

2. This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Need help? Hotmoon support is here.
Contact us at support@hotmoon.com

Model: HMNL-07 Contain FCC ID: 2A3V3HMNL-03
Manufacturer: Shenzhen ZhiLong Electronic Technology Co., Ltd (ShenZhen Shi ZhiLong DianZi KeJi YouXian GongSi) Address: No.105, Fourth Lane, Yongxiang Rd., Wuhe Community, Bantian St. Longgang Dist., Shenzhen, CHINA 518000



Cocoon Pro 2 User Guide