Instruction Manual
Configuration of Smart Fan Controller in 'RR signature smart' APP

Notes:

1. Make sure 'RR Signature Smart' App is downloaded on the mobile phone.
2. QR code is available on the packaging box to download the RR Signature Smart' App from the Android Playstore & iOS Appstore.
3. Location and other relevant permissions must be granted to the 'RR Signature Smart' app
4. Only 2.4GHz Wi-Fi supported. Password for Wi-Fi network should be same.
   After the Fan is powered ON, the Buzzer on the Fan will beep 5 times & LED will blink GREEN continuously for 3 minutes to indicate user that the Fan is in pairing mode and ready to connect with Wi-Fi.
5. After the Fan is powered ON, if the Buzzer on the Fan doesn't beep 5 times & LED doesn't blink GREEN, this indicates FAN is not in pairing mode. In that case USER can RESET (Pairing mode) the Fan by long pressing (for at least 5-6 seconds) the connectivity icon (Blue color Button) on the remote. If even this doesn't work, Switch ON-OFF the Main fan switch 5 times. This will bring the device into pairing mode. After this, Buzzer will beep 5 times & LED on the Smart-Fan Intelligent Controller will start Blinking continuously for 3 minutes.

   REGISTRATION ON MOBILE APP

1. Register & sign up yourself in the 'RR Signature Smart' app using Mobile No. OR Email ID

Steps for configuration via Default mode (Quick connect Mode):

1. Make Sure the Local Wi-Fi is in ON condition and the Mobile phone is connected to the Local Wi-Fi.

2. Click on + icon in the top right of the home screen, it will move to next screen of "Add Device"

3. On the next screen, select the device type 'Fan' option

4. It will search the device using 'Wi-Fi' and display the Smart Fans (For example Audie Fan) available in the vicinity and User will select the Fan to initiate the pairing mode.

5. Make sure the Fan is ON.

6. After being powered ON, Buzzer will quickly beep 5 times & LED will blink continuously GREEN to indicate user that it is in connection seeking mode and

ready to connect with Wi-Fi. Fan will be in connection seeking mode for 3 minutes.

Note : If NO Buzzer beep OR NO Green LED Blinks, in that case, USER to Switch ON-OFF the fan 5 times OR Long Press of Blue Button on the remote. This will produce 5 times Buzzer Beeps and Green LED will glow for 3 minutes.

7. Read the instructions on the next screen and confirm the buzzer beeps fast 5 times.

8. Now, make sure your smartphone is connected to a 2.4 Ghz Wi-Fi and provide the Wi-Fi credentials here. Next, click the 'Connect" button.

9. Now wait for some time as the Wi-Fi router is discovering the Smart Fan.

10. Once discovered, the app will take you to the next screen where you can add the Smart Fan to a room. In case no room is created, or you want to add Smart Fan to a new room, you can do so here.

11. That's all! You've successfully added the Smart Fan to your devices list.

Steps for configuration via 'Detailed connect Mode':

1. If USER not able to pair the Fan and gets Error – Unable to perform scan for nearby devices .

2. User gets 2 options –

3. <mark>Try again with Default 'Quick Connect mode' and Try Detailed Connect mode'</mark>

4. If using Default 'Quick Connect mode' same steps from 2 to 5 will be followed.

5. If User selects <mark>Try Detailed Connect mode' → It will go to Add Device screen →Click the Fan → Move to next Screen and then Either Switch ON-OFF the mains 3 times OR Long Press Blue Button of Remote ,</mark> Buzzer beeps 3 times & LED will blink continuously GREEN for 3 minutes to indicate user that it is in connection seeking mode and ready to connect with Wi-Fi.

6. Now, make sure your smartphone is connected to a 2.4 Ghz Wi-Fi and provide the Wi-Fi credentials here. Next, click the 'Connect" button.

7. Wi-Fi router will discover the Smart Fan and display it .Click on the Fan , it will start the process of configuration.

8. Pairing Process will be initiated.

9. Select the Room for the Fan and Submit

10. Next, click the 'Connect" button.

11. Wi-Fi checking & configuration of devices will be in process

12. Fan Control Screen/Dashboard will appear once the device gets configured

13. That's all! You've successfully added the Smart Fan to your devices list.

Re-configuration

Note:

» Need for reconfiguration of Smart Fan will arise in the following cases:

a) If you have changed the Wi-Fi credentials — Wi-Fi name or Wi-Fi password or both

b) If you have installed a new Wi-Fi router

c) If your existing Wi-Fi router isn't working

Steps for re-configuration

1. Home Screen -- >Click on the device tile in My Devices--» in Fan Control Screen, Click on the Settings -—» Click on Connected to ---- > It will search the available Network and Select the Network USER wants to switch

2. Fan will pair with the New WiFi network.

CONNECT TO ALEXA:

1. Download and install the 'Amazon Alexa' App from Appstore / Playstore
2. Go to Mobile app 'Home Screen'
3. Select Profile → Select Connect with Alexa
4. It will open the Alexa app and ask to fill the Alexa credentials
5. Message will come to 'Link RR Signature Smart' with Alexa. Press Link
6. It will 'Successfully linked with Alexa' – Press OK
7. USER can see the devices on Alexa app which are onboarded on the app.

OR Method 2

1. Open Alexa app
2. Search the skill "RR Signature Smart" on Alexa app .
3. Enable the skill
4. Enter user credentials of RR Signature smart in the Skill
5. It will display "Waiting for RR Kabel to link the app"
6. Finally it will display " Successfully App is linked with Alexa"
7. Explore your devices on the Alexa app.
8. Now can control the operation of the devices using Alexa app.

Connect to Google Home

1. Download and install the 'Google Home' App from Appstore / Playstore
2. Go to Mobile app 'Home Screen'
3. Select Profile → Select Connect with Google Home
4. It will open the Google Home app and ask to fill the credentials
5. Message will come to 'Link RR Signature Smart' with Google Home. Press Link
6. It will 'Successfully linked with Google Home' – Press OK
7. USER can see the devices on Alexa app which are onboarded on the app.