


INSTALLATION INSTRUCTION

YZ2320_US1.0



If you have any questions, please feel free to contact Customer Service via Amazon before returning.


Safety Caution

Please read this instruction carefully before installation. If you do not understand these instructions or have doubts about the safety of the installation, assembly or use of this product, please contact us.


- This product is designed for use in wood stud or solid concrete wall.
- **DO NOT install into drywall alone.**
- The wall must be capable of supporting five times the weight of the TV and mount combined.
- Incorrect installation may result in product damage / property damage or body injury.
We shall bear no responsibility for any damage or injury resulted from incorrect installation, incorrect assembly or misuse.

WARNING: This product contains small items that could be a choking hazard if swallowed. Before starting assembly, verify all parts are included and undamaged. If any parts are missing or damaged, do not return the damaged item to your dealer; please contact our customer service team. Never use damaged parts!

Must Check Before Getting Started




Minimum VESA Pattern (W × H):
100mm × 100mm / 4 in × 4 in
Maximum VESA Pattern (W × H):
600mm × 400mm / 24 in × 16 in




WARNING

DO NOT exceed the maximum weight indicated. This mounting system is intended for use only within the maximum weights indicated. Use with products heavier than the maximum weights indicated may result in failure of the mount and its accessories, causing possible damage or injury.

Verify Your Wall Construction




CAUTION: Avoid potential personal injuries and property damage! Drywall covering the wall must not exceed 5/8 in. (16 mm). Minimum wood stud size: nominal 2 x 4 in. (51 x 102 mm) actual 1 1/2 x 3 1/2 in. (38 x 89 mm).





CAUTION: Avoid potential personal injuries and property damage! Mount the wall plate assembly directly onto the concrete surface (no surface covering).







CAUTION: DO NOT install into drywall alone.



Product Dimensions



Supplied Parts and Hardware




TV					
Philips Screws	Philips Screws	Philips Screws	Spacers	Washers	Spacers
M4 x 12mm M4 x 30mm	M6 x 15mm M6 x 30mm	M8 x 25mm M8 x 45mm	H10mm	Φ6mm M4-5-6	H5mm
 x4	 x4	 x4	 x8	 x4	 x8
MA	MB	MC	MD	ME	MF




NOTE: Not all parts and hardware included will be used.

Extra Tools You Need (Not Supplied)




1 Attach Brackets to TV

1-1 Select TV Screws




1-2 Need Spacer?



I Yes, choose the appropriate screws, washers, and spacers for your TV.



II No, just choose the screws, washers.




1-3




2 Assemble the Mount

2-1 Tilt Adjustment



2-2 Assemble Wall Plate



3-A Attach Wall Plate to Wall

OPTION A: Wood Stud Installation

A-1

Min. 2" (51mm)
Min. 4" (102mm)
Center line
Wall in front of the wood studs < 16mm (5/8")
Bubble Level

Locate your studs. Verify and mark the center of the stud by finding the stud edges using awl and stud finder.

Line up the holes with your stud center line. Level the wall plate and mark the pilot hole locations.

A-2

Material	Bit	2 3/4 in (70mm)	Deep
Wood Stud	Ø7/32 in (Ø5.5 mm)		

Drill pilot holes using a Ø7/32 in (Ø5.5mm) diameter drill bit.

IMPORTANT: Do not drill holes into where water pipes or electrical wires are located. Be sure to drill into the center of the stud.

STOP Do not drill into water pipes or electrical wires.

DANGER Do not drill into drywall or wood studs.

A-3

CAUTION: Do not use in drywall or wood stud!

Install wall plate using lag bolts **A** with Socket Wrench, NO Electrodrill. No anchors when installed onto the wood studs.

CAUTION: To avoid potential personal injury or property damage: All 4 lag bolts **A** **MUST BE** firmly tightened to prevent unwanted movement of the wall plate assembly. Ensure the wall plate assembly is securely fastened to the wall before continuing on to the next step.

3-B Attach Wall Plate to Wall

OPTION B: Solid Concrete Wall Installation

B-1

Min. 8" (203mm)
Bubble Level

Level the wall plate and mark the pilot hole locations.

B-2

Material	Bit	2 3/4 in (70mm)	Deep
Concrete Wall	Ø3/8 in (Ø10 mm)		

Drill pilot holes using a Ø3/8 in (Ø10mm) diameter drill bit.

IMPORTANT: Do not drill holes into where water pipes or electrical wires are located, or mortar between blocks.

STOP Do not drill into water pipes or electrical wires.

DANGER Do not drill into drywall or wood studs.

B-3

Use the hammer to knock anchors (not included) into the concrete wall. Be sure the anchors are seated flush with the concrete surface.

Install wall plate using lag bolts **A** and anchors (not included) with Socket Wrench, NO Electrodrill.

CAUTION: To avoid potential personal injury or property damage: All 4 lag bolts **A** **MUST BE** firmly tightened to prevent unwanted movement of the wall plate assembly. Ensure the wall plate assembly is securely fastened to the wall before continuing on to the next step.

4 Hang and Secure TV to Wall Plate

4-1

Before hanging TV, please conduct "wall plate installation integrity test" first.

120 LBS (54.5 KG)

4-2

Hang and secure TV assembly onto the wall plate.

TV must be hung up by two person

CAUTION: Avoid potential personal injury or property damage! Always make sure your TV brackets are in the locked position so the TV is securely attached to the wall plate assembly.

If necessary

Take down the TV from the Mount

To prevent breaking the locking latch: always pull and hold the release straps down while pulling the TV away from the wall.

TV must be taken down by two person

5 Cable Management (If necessary)

Velcro Cable Ties

Adjust the length of the straps.