SRitDo

Ultimate 3-mode Xbox - Rare

English

猎户座三模手柄(Xbox - Rare)

中文

- . Press the Xbox button to turn on the controller
- Hold the Xbox button for 6 seconds to turn off the controller.
- Hold the Xbox button for 12 seconds to force the controller off.

Xbox Series/One console

- System Requirement: ensure your Xbox console is updated to the latest system version.

eless Connection

- 1. Connect the 2.4G adapter to your Xbox console
- 2. Turn the **Mode switch** to **2.4G** position.
- 3. Press the **Xbox button** to turn on the controller and wait till the controller is recognized by the device, the Status LED will stay solid when the connection is successful.

- 1. Turn the Mode switch to USB position.
- 2. Connect the controller to your Xbox console via a USB cable.
 3. Press the Xbox button to turn on the controller and wait till the controller is recognized by the console, the Status LED will stay solid when the connection is successful.

Windows 10/11

· System requirement: Windows 10(1903) or above

Wireless Connection

- 1. Connect the 2.4G adapter to your Windows device.
- 2. Turn the Mode switch to 2.4G position.
- Press the Xbox button to turn on the controller and wait till the controller is recognized by the device, the Status LED will stay solid when the connection is successful.

Wired Connection

- 1. Turn the Mode switch to USB position.
- 2. Connect the controller to your Windows device via a USB cable.
- 3. Press the Xbox button to turn on the controller and wait till the controller is recognized by the device, the Status LED will stay solid when the connection is successful.

Android

· System requirement: Android 9.0 or above.

Bluetooth Connection

- 1. Turn the Mode switch to BT position.
- 2. Press the Xbox button to turn on the controller.
- Press and hold the Pair button for 3 seconds to enter the pairing mode, the Status LED will blink rapidly. (This is required for the very first time only)
- 4. Go to your Android device's Bluetooth Setting and pair with "8BitDo Ultimate 3mode Xbox", the Status LED will stay solid when the connection is successful.

Apple®

• System requirement: iOS 18.2, iPadOS 18.2, tvOS 18.2, macOS 15.2, visionOS 2.2 or above

Bluetooth Connection

- 1. Turn the Mode switch to BT position.
- 2. Press the Xbox button to turn on the controller
- 3. Press and hold the Pair button for 3 seconds to enter its pairing mode, the Status LED will blink rapidly. (This is required for the very first time only)

 4. Go to your Apple device's Bluetooth Setting and pair with "8BitDo Ultimate 3mode Xbox", the Status LED
- will remain solid to indicate a successful connection.

Xbox Series 系列 / One 系列主机

*要求 Xbox 主机系统版本已更新到最新版本。

无线连接

开机:按下 Xbox 键。

关机:按住 Xbox 键 6 秒。

强制关机:按住 Xbox 键 12 秒。

- 1. 将配备的 2.4G 接收器 连接到 Xbox 主机的 USB 端口。
- 2. 将 **模式开关** 移动到 **2.4G** 位置。
- 3. 按下 Xbox 键 开启手柄,等待系统识别完成后,状态指示灯 常亮。

有线连接

- 1. 将 模式开关 移动到 有线 位置。
- 2 使用 USB 线将手柄连接到 Xhox 主机的 USB 端口。
- 3. 按下 Xbox 键 开启手柄,等待系统识别完成后,状态指示灯 常亮。

Windows 10 / 11

* 要求 Windows 设备系统版本为 Windows 10 (1903) 或更高版本。

无线连接

- 1. 将配备的 2.4G 接收器 连接到 Windows 设备的 USB 端口。
- 2. 将模式开关移动到 2.4G 位置。 3. 按下 Xbox 键 开启手柄,等待系统识别完成后,状态指示灯 常亮。

有线连接

- 1. 将 模式开关 移动到 有线 位置。
- 2. 使用 USB 线将手柄连接到 Windows 设备的 USB 端口。

3. 按下 Xbox 键 开启手柄,等待系统识别完成后,状态指示灯 常亮。

Android

*要求 Android 设备系统版本为 Android 9.0 或更高版本。

蓝牙连接

- 1. 将 模式开关 移动到 蓝牙 位置。
- 2. 按下 Xbox 键 开启手柄。
- 状态指示灯 常亮。

Apple

电源 手柄电源状态

电量不足

充电完成

正在充电

* 要求 iOS 18.2、iPadOS 18.2、tvOS 18.2、macOS 15.2、visionOS 2.2 或更高版本。

蓝牙连接

- 1. 将 模式开关 移动到 蓝牙 位置。
- 2. 按下 Xbox 键 开启手柄,

电源指示灯状态

底座电源指示灯状态

红灯闪烁


绿灯闪烁

绿灯常亮

琥珀色常亮

A

白色常亮 *配备 1000mAh 可充电式锂电池, 2.4G 连接可持续使用约 20 小时, 蓝牙连接可持续使用约 25 小时, 充



- Built-in 1000mAh battery pack, 20 hours of usage time via wireless 2.4G connection and 25 hours via Bluetooth connection, rechargeable with 4 hours charging time.

 The controller will automatically shut down if it fails to connect within 1 minute of startup, or if there are no
- operations within 15 minutes after establishing a connection.

 The controller will not automatically power off when connected to 3.5mm headphones for audio playback.

 The controller will not shut down during wired connection.

Safety Warnings

- Please always use batteries, chargers, and accessories provided by the manufacturer.
 The manufacturer is not liable for any safety issues arising from the use of non-manufacturer-approved
- accessories. • Do not attempt to disassemble, modify, or repair the device yourself. Unauthorized actions may result in
- serious injury. · Avoid crushing, disassembling, puncturing, or attempting to modify the device or its battery, as these actions
- can be dangerous.

 Any unauthorized changes or modifications to the device will void the manufacturer's warranty.
- This product contains small parts that may cause choking. Not suitable for children under three years old.
 This product features flashing lights. Individuals with epilepsy or photosensitivity should disable the lighting
- effects before use. Cables may cause tripping or entanglement hazards. Keen them away from walkways, children, and nets. - Stop using this product immediately and seek medical attention if you experience dizziness, visual

安全警示

- 请使用制造商的电池、充电器、配件。 在用户使用第三方的配件时,制造商不能对用户的安全负责。 请勿自行拆卸、改装或修理设备。

连接 3.5mm 耳机播放音频时不会自动关机。

* 有线连接时不会自动关机。

请勿自行所即以表现修理设备。 请勿挤压、拆解、刺穿或尝试改装设备及电池。 对设备的任意变动或改装,将导致制造商对设备不予保修。

电时间约 4 小时。
* 开机后 1 分钟内未连接,或连接后 15 分钟内无操作会自动关机。

- 产品包含小部件,可能造成窒息危险,不适合3岁以下儿童使用。
- 本产品使用时包含闪烁灯光效果,若有癫痫病史或光敏性反应者使用时请关闭灯光。 产品线缆可能造成绊倒或缠绕危险,请勿放置在行走区域,并远离儿童及宠物。
- 如产品使用过程中出现头晕、视力异常、肌肉抽搐等症状、请立即停止使用并就医。

Re-pair the Controller and Adapter

If the connection is lost or the receiver needs to be re-paired, you can follow the steps below to re-pair the controller with the adapte

1. Turn the **Mode switch** to **2.4G** position.

disturbances, or muscle spasms.

- 2. Connect the 2.4G adapter to your Windows device or Xbox console.
- 3. Press the **Xbox button** to turn on the controller.

 4. Press and hold the **Pair button** for 3 seconds to enter the pairing mode, the **Status LED** will blink rapidly 5. Both the Status LEDs on the controller and adapter will become solid when the connection is successful.

重新配对接收器

如果连接丢失或需要重新配对接收器,可使用以下方法重新将手柄与接收器配对: 1. 将 **模式开关** 移动到 **2.4G** 位置。 2. 将 **2.4G** 接收器 连接到 Windows 设备或 Xbox 主机的 USB 端口。

- 按下 Xbox 键 开启手柄。

Ultimate Software X

- After configuration, press the **Profile button** to enable, switch, or disable the custom configuration
- The default profile has no configuration. - Please visit app.8bitdo.com to download the Ultimate Software X to get the customize button mapping function, joysticks/triggers sensitivity, vibration intensity ,and additional support.

自定义配置

技术支持

- 配置后按下配置键可开启 / 切换 / 关闭自定义配置,默认无配置。 请访问 app.8bitdo.cn 获取 精英软件 X,可对手柄按键映射、摇杆灵敏度、扳机键灵敏度、振动强度
- 等功能讲行自定义配置。

Support



• Please visit support.8bitdo.com for further information and additional support.









