

APPLICATION

- SHAKE THE PRODUCT GENTLY BEFORE USE. LINE A SUEDE CLOTH ON THE APPLICATOR BLOCK'S SPONGE SURFACE.
 - POUR THE PRODUCT ONTO THE SUEDE CLOTH. 4-5ML COVERS 1M² AREA.
 - SPREAD THE PRODUCT GENTLY OVER THE SURFACE IN A 'CRISSCROSS' MOTION. ONCE BEADING OCCURS (IT TAKES 30 SECONDS IN NORMAL CONDITIONS), WIPE THE EXCESS PRODUCT OFF IN LINEAR MOTIONS.
 - AFTER WIPING THE SURFACE, COMPLETE THE FINAL BUFFING PROCESS BY GENTLY USING A SEPARATE MICROFIBER CLOTH IN CIRCULAR MOTIONS.
 - KEEP THE COATED SURFACES AWAY FROM DIRECT SUNLIGHT, ELEMENTS, VARIOUS TYPES OF CONTAMINATION, AND WATER EXPOSURE FOR MINIMUM OF 24 HOURS.
- **UP TO 48 HOURS RECOMMENDED TO CURE BEFORE ANY DETERGENT-BASED WASHING.**

TO ENSURE THE LONGEVITY OF THE PRODUCT;

- PREP VEHICLE THOROUGHLY
- PREPARE SURFACE WITH ISOPROPYL ALCOHOL OR SIMILAR TO IMPROVE THE BONDING PERFORMANCE OF THE NANO COATING.

****PROTECTIVE NITRILE GLOVES ARE HIGHLY RECOMMENDED DURING APPLICATION**



info@ryzecarcare.com.au
+617 5558 3880
www.ryzecarcare.com.au
@ryzecarcare