

# USER MANUAL


## Remote Controller

### Manufacturer:

Foshan Alpicool Holding Group Co., Ltd.

No.3, ZhenZhu Road, Yang'e, Lunjiao , Shunde, Foshan, Guangdong, China

### REMOTE CONTROL OPERATION



- ① TEMPERATURE UP
- ② FAN SPEED
- ③ TEMPERATURE DOWN
- ④ AUTOMATIC DRAINAGE
- ⑤ SLEEP MODE
- ⑥ SWITCH MODE BUTTON
- ⑦ TIMING
- ⑧ ON/OFF

\*Note: Please pair the remote control with the air conditioner before operating.

- **Pairing the remote control with the air conditioner:** Within 10 seconds of powering on the air conditioner, long press the power button ⑧ for three seconds, the buzzer will make a long beep, pairing finished.
- **Air conditioner ON/OFF:** press the ON/OFF button ⑧ to switch ON/OFF.
- **Timing:** under the running state, press ⑦ to timing, then press ① or ③ to adjust the specified time, press ⑦ again to complete the timing. After 10s, the display changes to temperature. Press ⑦ to cancel the timing. (\*The time interval ranges from 1 to 24 hours)
- **Mode conversion:** press ⑥ to switch between 3 modes: cool, dry and fan. Short press the sleep mode button ⑤ to activate sleep mode.
- **Temperature Setting:** under the cool and sleep mode, press ① to increase the temperature, and press ③ to decrease the temperature. (\* under the fan and dry mode, the temperature cannot be adjusted.)
- **Fan Speed Setting:** press ② to switch between 3 modes: H/M/L.
- **Automatic Drainage Function:** press ④ to switch ON/OFF the drainage function.

-This remote control requires two AAA batteries (not included).

#### -Battery Installation and Replacement

- Removing Old Batteries

1. Locate the Battery Compartment:

On the back of the remote, find the "OPEN" or "⇨" symbol, then slide/press the cover in the direction of the arrow.

2. Open the Cover:

Gently push or pry open the battery cover until it is fully released.

3. Remove the Batteries:

Use your fingers or a non-metallic tool (e.g., a toothpick) to push the old batteries out of the slots. Avoid pulling forcefully.

- Installing New Batteries

1. Check Battery Type: Use 2 AAA batteries (\*\*Note: Do not mix old and new batteries\*\*).

2. Align Polarity: Insert the batteries according to the "+/-" markings inside the compartment (usually positive side up).

3. Secure the Batteries: Press down gently to ensure they are fully seated and making proper contact.

4. Close the Cover: Align the cover with the locking tabs and press firmly until it clicks into place.

- 

-Non-rechargeable batteries are not to be recharged;

-Different types of batteries or new and used batteries are not to be mixed;

-Batteries are to be inserted with the correct polarity;

-Exhausted batteries are to be removed from the appliance and safely disposed of;

-If the appliance is to be stored unused for a long period, the batteries should be removed;

-The supply terminals are not to be short-circuited.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.


-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.


-- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## SMART CONTROL - AIR CONDITIONER APP INSTRUCTIONS

**First Step:** Turn on the Bluetooth on your smart device; start the APP and click "Search" to find nearby air conditioners. A location authorization pop-up will appear. Click "Authorize" to grant permission.

**Second Step:** Click air conditioner icon for Bluetooth pairing (the APP will prompt you to pair the air conditioner by pressing the mode button  on the air conditioner's control panel when connecting the air conditioner for the first time). After pairing, the APP will switch to the main interface allowing you to control the air conditioner.



- ① SET (Celsius and Fahrenheit conversion can be adjusted in the SET)
- ② ⑨ Temperature control
- ③ Current temperature (Ambient temperature)
- ④ Mode: COOL/DRY/SLEEP/FAN
- ⑤ Autodrain ON/OFF
- ⑥ Back button (Tap to disconnect Bluetooth and return to the search page)
- ⑦ ON/OFF
- ⑧ Fault Indicator (Displays only when errors occur)
- ⑩ Round temperature vector (Displays target temperature)
- ⑪ Target temperature
- ⑫ Fan speed: Low/Medium/High
- ⑬ Timing

\*Image for reference only, please refer to the actual display page.

## Downloading the "Portable air conditioner" Application



iOS



Android

Scan the QR code on the left or search for the "Portable air conditioner" APP in the APP Store (for Apple devices) or Google Play (for Android devices).

- **Fan Speed Setting:** press ② to switch between 3 modes: H/M/L.
- **Automatic Drainage Function:** press ④ to switch ON/OFF the drainage function.

## 7.CARE AND MAINTENANCE

### **Cleaning:**

- Wipe the air conditioner with warm and wet cloth.
- If it is too dirty, wipe it with neutral detergent, and then dry the water stain with dishcloth.

### **Plastic parts maintenance:**

- To properly protect the air conditioner, it must always be kept clean, and try to avoid oil stain and deformation when using.
- If the oil is attached to the plastic parts for a long time, the plastic is prone to aging or cracking, and gives off odor. Therefore, we should form the habit of regular cleaning.

### **⚠ WARNING!**

- It is strictly forbidden to clean the air conditioner in the water directly, so as to prevent the electrical insulation from reducing and rusting.
- The following things will damage the coating, plastic parts and cannot be used for cleaning: alkaline detergent, soap, grinding powder, hot water, brush, Tiana water, gasoline, alcohol.