ATUMAN TH3 Intelligent Thermo-Hygrometer Clock Instruction Manual

Products 100 A B Average outdoor -Kev/12/24h system 3 Day of the 7 Indoor humidity 4 Clock 8 Minimum and maximum 2 + kev/network distribution/ outdoor temperature temperature unit °C/°F switching

- 1 clock function
- Calendar function
- Temperature and humidity detection function
- 4. Battery level display
- WiFi networking
- Networking status WiFi blinking

Networking status WiFi is always on

After WiFi connection, it can display the minimum and maximum outdoor temperature and average humidity,

Setup Operations

- Power on: In the off state, short press or long press the [SET] key, the screen lights up. Shutdown: Under the power on state, press and hold the ISETI key for 3 seconds, the screen will turn off
- •SET key: Short press [SET] key to enter setting mode, short press [SET] key to set Short press [SET] key to set year/month/day/hour/minute; short press [+ / -] key to set the specific value, after setting "minute", press [SET] key again to set "minute", then press [SET] key again to set "minute", After setting "minute", press [SET] key again to exit the setting, no operation for 15 seconds will exit the setting automatically.
- •+ key: In normal mode, press [+] key to switch the temperature unit °C/°F.
- In setting mode, short press [+] key to increase the number; long press [+] key for more than 2 seconds to increase the number quickly.
- kev: In normal mode, press [-] briefly to switch between 12h/24h system. In setting mode, short press [-] key to decrease the number; long press [-] key for more
- than 2 seconds to decrease the number quickly.

- Automatic network distribution: when the device is turned on for the first time, it will enter the network distribution mode automatically, the network distribution cycle is 5 minutes, more than 5 minutes need to distribute the network manually.
- Manual network distribution; when the device is turned on, long press the "+" key for 3 seconds to enter the network distribution mode, the network distribution cycle is 120 seconds, more than 120 seconds will exit the network distribution state.

Please check that the device has power status and nearby WiFi is available before distribution:

1. Open the cell phone settings - wireless LAN selection"TH3", and the cell phone connects to the device's WiFi hotspot:



TH3 WiFiManager;



2. After successful connection, the phone will automatically open the browser and jump to the interface to

重点



5. After the success of the first network, the device will connect to the weather server to get the weather data, and need to wait for 1 minute.

Within 1 minute, the device will automatically display the weather, temperature and humidity data of the day; (The data will be updated at 6 o'clock every day,

(The weather data is updated at 6 o'clock every day, the weather data is from the website https://www.seniverse.com)

If the outdoor weather data is not acquired; it indicates that the synchronization of the weather data has failed, and the step 1234 is repeated;

3. Select the configuration option, it will 4. After connecting WiFi successfully, display the nearby WiFi, select your the interface will be displayed as follows available WiFi, enter the WiFi password.



Temperature and humidity measurement

1)Temperature Measurement

10/28 week5 ⊋ IIII)

Measuring range: -9,9~60°C (14~140°F)

2)Humidity Measurement Measuring range: 10%~99%RH

Main parameters

roduct Name	TH3 Intelligent Temperature and Humidity Clock		
Size	86×86×13.3mm	Net weight	86g
Resolution	0.1°C/1%RH	Renewal Rate	60 seconds/trip
Battery	3.7V/450mAh	Continuous Endurance	≈4 months

special note

Please keep the screen surface clean.

The Company shall not be liable for any results derived from the use of this product.

The Company reserves the right to make changes to the design of the product and the

Due to the improvement of the product, the product you purchased may not be exactly

the same as the introduction of the instruction manual, this instruction manual

This manual is for reference only. If you have any doubts, please contact us.

- 2. Please prevent the product from falling.

contents of the manual without prior notice.

- Please use this product within the specified measurement range.
- 4. This product is intended for healthy living use only and is not recommended for use as a measuring tool in professional settings.

The device has been evaluated to meet general RF exposure requirement. The device can be used in

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible

portable exposure condition without restriction.

- Increase the separation between the equipment and receiver.

-Consult the dealer or an experienced radio/TV technician for help.

for compliance could void the user's authority to operate the equipment.

Manufanturer: Shenzhen ATuMan Precision Machine Technology Co. Ltd

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two

received, including interference that may cause undesired operation.

(1) This device may not cause harmful interference, and (2) this device must accept any interference

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital

can radiate radio frequency energy and, if not installed and used in accordance with the instructions.

interference to radio or television reception, which can be determined by turning the equipment off

protection against harmful interference in a residential installation. This equipment generates, uses and

device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable

may cause harmful interference to radio communications. However, there is no guarantee that

and on, the user is encouraged to try to correct the interference by one or more of the following

-Connect the equipment into an outlet on a circuit different from that to which the receiver is

interference will not occur in a particular installation. If this equipment does cause harmful

Room 1012, Dongming Building, Minkang Road, Minzhi Street, Longhua District, Shenzhen, Web: www.atuman.com

Business e-mail: business@atuman.com

- Recrient or relocate the receiving antenna.

Commissioned producers: Henan ATuMan Precision MachineryTechnology Co., Ltd.

Manufacturer's address: Building D, standard workshop, southeast corner, intersection of

Xingye Avenue and Ruhe Avenue, Yicheng District, Zhumadian City, Henan Province, China

