Instruction for live Smartphone live streaming Sound Device

Dear users,

Thank you for buying the live broadcast sound card. In order for you to better use this product,

Please read this product manual carefully and keep it for future reference

Use.

Live broadcast sound card is a very popular application for network broadcast, karaoke

Professional recording equipment, equipped with professional DSP digital processing chip,

Bring you quality reverberation effect and voice processing. Support for multiple current masters

Live streaming, k-song apps, such as Chanba, full name K-song, Ai-sing, Mei-pai,

Huya, Douyu, Tencent and other K songs or live broadcast software, in the live,

Chat, host shout mai, personal recording and so on all have very outstanding

Live broadcast port: mobile phone live broadcast, recording interface.
Monitor socket: 3.5mm three or four earphones can be used, audio output plug
My mouth.
Microphone jack: Anchor microphone jack.
Accompaniment socket: external accompaniment socket, mobile phone, MP3, etc., to play external accompaniment
Play, also can insert Musical Instruments as an accompaniment.

PC/OTG/ USB port:
Rechargeable, OTG, USB connected computer

charge/OTG

3 4

1 2
M1 M6
M2 M7
M3 M8
M4 M9
M5 M10

ZOIN

1 Bluetooth indicator light: the indicator light will blink when pairing the device, and it will be steady on when pairing successfully.
2 power lamp: the green light flashes when charging, the green light is steady on when fully charged, and the green light stops flashing, and the battery capacity will be automatically detected to indicate the power. When fully charged, the power will be green, and about 50% of the power will be orange, and the weak current will be red.
3. Accompaniment lamp: the accompaniment lamp will jump according to the accompaniment sound. From bottom to top, the accompaniment lamp will increase or decrease when the monitoring size is adjusted.
Microphone light: it will light up gradually from green to red according to input sound size and reverb level adjustment.

Model lamp

M1 KTV mode: With long reverberation effect, it is suitable for karaoke scenes

M2 chat mode: the microphone is the original sound effect, suitable for chatting, miaoke and other scenes

M3 popular mode: short reverberation time, low reverberation volume, suitable for singing scenes
M4 mixing mode: it can be used to connect the microphone to the broadcast process. If this function is enabled, the audience will only hear the output of the microphone, and the accompaniment music will be blocked and the computer terminal will be closed.
M5 Electric mode: press the electric key to adjust the tone of 12 files, suitable for electric songs
M6 mic Shouting mode: MIC Shouting effect
The voice is low and magnetic, suitable for direct broadcast mic Shouting scenes
M7 female voice mode: voice output into female voice, suitable for funny scenes, you can press the tone change key for female voice fine tuning, a total of 6 female voice fine tuning
M8 male voice mode: human voice output into male voice, suitable for funny scenes, can press the tone change key for male voice fine-tuning, a total of 6 male voice fine-tuning
M9 children's voice mode: the voice output becomes children's voice, which is suitable for funny scenes. You can fine-tune children's voice by pressing the tone change key. There are 6 fine-tuning children's voice
M10 Dodge mode: when the microphone voice is input, the accompaniment will fade out, and when the speaker voice ends, the accompaniment will return to normal

---

蓝口混响⟳闪避
话筒
监听
+
+

Side key introduction
Microphone adjustment: adjust the volume of the microphone, "+" button to increase the volume of the microphone, "-" button to decrease the volume of the microphone, a total of 9 levels of volume switch. Monitor adjustment: adjust the volume of the monitor, "+" button to increase the volume of the monitor, "-" button to decrease the volume of the monitor.
Bluetooth/reverberation button: long press to enable or disable the Bluetooth function, the paired Bluetooth indicator light will flash, and the Bluetooth indicator light will be steady on when the connection is successful. Short press to start reverb adjustment, a total of 9 reverb can be adjusted cycle.
Power button: long press the switch on and off, and short press the switch on to start dodging
function
The primary key to introduce
Mode key: short press mode switch, switch order for KTV, chat, pop, remix, shout mai, female voice, male voice, children's voice; Long press back to original mode electric key: short press for electric tone adjustment, a total of 12 electric tone.

1. Press the power button to power on Connect the "DC5V" interface of the product to the USB interface of the computer with the data cable equipped with this machine。
2. (PS: Right click on the speaker in the lower right corner of the menu bar → click on the recording device → Check whether MV-AP82X Audio Effect debug is the only recording device available. If multiple recording devices are enabled during computer use, please disable other recording devices and keep only MV-AP82X as the only recording device available.)
3. If an accompaniment is required, connect other accompaniment devices in the accompaniment hole with the audio cable as an accompaniment. Please adjust the accompaniment size in the accompaniment device according to your personal needs. (Only in the use of computer live broadcast can directly use the music in the computer as an accompaniment, in other cases must access to accompaniment equipment can be accompaniment

Broadcast interface (3.5mm) Microphone interface (3.5mm)

Accompaniment interface (3.5mm) Speaker interface (3.5mm)

Headset port (3.5mm) Sound card charging (USB bidirectional female)
Battery capacity: 1200mAh/ 3.7V
Power: 3.7WH Sound card charging: DC5V/1A

1. When you hear the voice prompt of low power or low sound, the sound quality is not true, it means that the sound card is running out of power. Low power will affect the sound quality. 2, the use of the interface should be fully inserted, mobile phone equipped with mobile phone case, please remove the mobile phone case, avoid the case against the plug, after connecting to turn two round plug
3, headset or microphone sensitive too high, sound card microphone, monitor and mobile phone volume do not adjust to the maximum, otherwise there will be a loud phenomenon, please adjust the volume according to the actual situation until there is no loud so far. 4. It is not recommended to use speakers for computer broadcast, but to use monitoring earphones, as speakers will cause stress and affect the quality of sound heard by the audience. If want to sing a song to the person beside listen, when using sound box, microphone and sound box maintain certain distance, avoid avoid sound box to microphone generation shout or disturb sound.