

# HD Dash Cam

Smartphone wireless WIFI version

Model: Q3

User Manual

V22.12

## **1. Install the mobile APP application**

Select a commonly used mobile phone and scan the QR code as below “Viidure”, or search for “Viidure” installation on Google Play or APP Store.




## **2, WIFI-APP Connection**

Please first find the WIFI name of the recorder starting with “CarDV\*\*\*”, and enter the password as prompted, if you need to connect your phone to the recorder, please go back to the APP and click to enter.

Note: Because the camera does not reset the function, so please do not change the password, if you change the camera password, for the normal use of the camera, please be sure to remember the new password.

My Camera ▾



CarDV-TL0888e1

\* Camera offline

Connect



Camera



Album




More

WIFI Name: \*\*\*\*\* Password: 12345678

- 1, Insert a Micro SD card to the dash cam SD card slot.
- 2, Start the car to power on the dash cam. Find the wifi named with “CarDV...”, that’s the dash cam, connect with the default password 12345678.
- 3, Enter the APP Viidure, press the camera icon in the lower right corner “into camera” to connect the dash cam.
- 4, Pree the lower right corner icon of the app to enter setting options, select “format SD card” to enable the SD card.

5, Congrats that you have completed the connection settings, you are all set to discover on the Viidure App NOW! You can use the official 6zhentan App to start watching the live streaming view, replaying or downloading your recorded footage on your handheld big screen.

### 3, Main Operation Interface



### 4, Frequently Asked Questions

#### Q: How to download mobile APP?

A: Select a commonly used mobile phone and scan the QR code in the user manual, or search for “Viidure” installation on Google Play or APP Store.

#### Q: Cannot turn on the car DVR?

A: Firstly, check that the LED indicator light is on properly,

secondly, check whether the power cable is properly connected.

**Q: Can't recording/taping?**

A: Please use genuine Class 10 or above high speed card, suggest using 16GB-128GB SD card, and check that the memory card is installed correctly, or the memory card is not formatted, please format SD card in APP.

Note: When the memory card is inserted into the camera for the first time, it requires to be formatted on APP.

**Q: Can't connect WiFi or connect failed?**

A: Please remember to authorize the App with the album, location, WLAN & cellulardata and turn off the VPN, security software and anti-virus APP of your mobile phone, otherwise you will not be able to connect to wifi.

**Q: Why doesn't WiFi connected automatically?**

A: Let me explain to you why we set the wifi to need to be connected manually instead of automatically connect the wifi as soon as it is turned on. Since many mobile phones on the market are single-channel mobile phones, the SIM card cannot be used after connecting to WiFi. We are worried that the automatic opening and connection of WiFi will cause some mobile phones to be unable to use 4/5G and miss important information.

**Q: Is it possible to watch live video when the app is not connected to WiFi?**

A: When the app is not connected to the recorder wifi, it

isn't possible to watch live video, you can only view the downloaded and saved video files in the app.

**Q: How to activate this dash cam's parking monitoring function?**

A: Q3 dash cam support 24 hours recording only when it is connected to a mini USB hardwire kit (NOTE: HARDWIRE KIT NOT INCLUDED), please connect the hardwire kit to you fuse box. (If you don't know how to install the hardwire kit, please ask a professional for help)

**Q: The pictures is not clear?**

A: Please remove the protective film, wipe the lens clean with a clean cloth. Make sure the front windshield is clean.

**Q: Does the device shut down when the SD card is hot plugged?**

A: The device does not support the hot swap function of the SD card, The device will automatically shut down when you inserts or removes the SD card during the device is powered on for protect the devices ensure longer life time.

**Q: Black screen when you previewing the video on mobile screen?**

A: As the output of this device is 1080P high resolution video picture, and sends it wirelessly to a smartphone, make sure your phone is configured to decode 1080P

video files, Android phones in general are prone to this kind of problem, the reason is that Android phones accumulate a large cache of files during use, it occupies a certain proportion of memory space, users can properly clear redundant background files to free up more memory card space for APP.

## Device status indicator:

Working Condition		LED Indicator Light Condition
No Wifi connection status	Normal recording	Blue light flashing slowly
	Stop recording	Red light flashing slowly
Wifi connection status	Normal recording	Blue light flashing slowly
	Stop recording	Red light flashing slowly



Viidure APP

WiFi name: Car\*\*\*\* Password:12345678

Thank you for your support and purchased our product.  
Hope you enjoy our HD dash cam with your happy&safe  
journey!

**Matters Need Attention**

1.This product is the record of image and sound information and other related information in the process of vehicle driving. The data saved by the instrument is only for reference. The company shall not be jointly and severally liable for any loss caused by any bad file and data loss caused by any abnormal use of this product.

2. We recommend the use of Class10 or above memory cards, and in order to avoid misunderstanding by users, we make the following instructions: The machine must be in normal working state to record, but the image will be damaged or lost under the following circumstances:

1) Any abnormal operation, such as unlawfully pulling out the memory card during recording, may cause damage or loss of the last recording file.

2) Damage or loss of the recording file caused by a destructive collision of the machine during recording.

3. Pls be sure to remember and do as below during you use the dash cam:

Please use the dash cam to the extent permitted by law.

Please keep the dash cam manual properly, which contains the initial connection information of the dash cam.

If the dash cam is directly connected to the car power supply system, do not use the dash cam for a long time when the engine is not started, otherwise the car cannot start.


4.The normal temperature range of this product is -20℃-70℃, please do not use the dash cam in high temperature, low temperature or high humidity environment; Avoid dousing the product or exposing it to rain or dust density, so as not to affect the use of the dash cam.

5.The product will be updated from time to time. Some functions may be slightly different from those in this manual. For details, please refer to the actual functions of the product.This product is only for the use of auxiliary driving, can not replace real-time manual operation or specific human environment to seek!

# Dash Cam Use and Daily Maintenance

1. The dash cam does not record continuously, but in segments. You can also copy a video for retention if necessary. The dash cam mode is a cyclic recording mode, after recording full, it will automatically cover the earliest recorded content and re-record the new content.
2. In case of emergency, it is necessary to choose to save and download the content in the dashcam or app to prevent the video from being overwritten.
3. As time goes by, there are too many video clips protected, and it may be impossible to record new videos, so we need to format the memory card once a month.
4. If the machine chirps or the blue light is on during use, please poke the RESET jack with a toothpick or needle, and you also can contact the customer service.

DVR wiring diagram 1  
5V power supply



# Schematic Diagram for Installing ACC Hardwire Kit

Note: Must be USB type C hard cable kit, 12V-24V to DC 5V 3A car charger power cord. Most of the ACC hardwired covers sold on the market are universal and compatible with the equipment.

