

1200W 2 BAR CERAMIC HEATER



Please refer to the warranty section for terms of your extended guarantee





READING AND STORING THE USER MANUAL



Before using this product, please read through this manual carefully paying particular attention to the safety instructions. Failure to do so may result in personal injury or damage to the product.

Carefully save this instruction manual for future reference. Ensure the user manual is included when passing the product on to any third parties.

IMPORTANT SAFETY INSTRUCTIONS FOR PROPER USE

When using electrical appliances, basic safety precautions should always be followed.

Only use the product as described in this user manual. Any other use is considered improper and may result in damage to property or persons. The manufacturer or vendor cannot be held liable for damages or injury incurred through improper or incorrect use.

- Read and familiarise yourself with all operating instructions before using this Heater.
- Before plugging your unit into the mains, visually check that the unit is intact and has not suffered any transit damage.
- Check that the voltage indicated on the data plate corresponds with that of the local network before connecting the appliance to the mains power supply.
- AWARNING! In order to avoid overheating, <u>DO NOT</u>
 COVER the heater.
- DO NOT install the appliance directly below an electrical socket.
- DO NOT use this heater with a programmer, timer, separate remote-control system or any other device that switches the heater on automatically, since a fire risk exists if the heater is covered or positioned incorrectly.
- **DO NOT** use this heater in the immediate surroundings of a bath, shower or a swimming pool.
- DO NOT use this heater with an extension cable.
- Ensure appliance is situated in an open area, do not allow it to come in contact with Cupboards, Curtains, wall



coverings, clothing or other flammable materials.

- **AWARNING!** This heater is not equipped with a device to control the room temperature. Do not use this heater in small rooms when they are occupied by persons not capable of leaving the room on their own, unless constant supervision is provided.
- Children of less than 3 years should be kept away unless continuously supervised.
- Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.
- CAUTION some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.
- **DO NOT** immerse the appliance or its cord in water or any other liquids.
- **DO NOT** leave the appliance unattended during use.
- **DO NOT** leave the appliance unattended whilst connected to the mains supply.
- Always use this appliance on a solid, level, non-flammable surface.
- **DO NOT** use this appliance outdoors.
- It is imperative to unplug the power cord after the appliance has been used, before it is cleaned and whilst being repaired.
- Repairs to electrical appliances should only be performed by qualified personnel. Improper repairs may place user at serious risk.
- DO NOT operate this appliance with a damaged plug or



cord, after a malfunction or after being dropped or damaged in any way.

- Regular, periodic checks should be carried out on the mains cable to ensure no damage is evident. Should there be any signs of damage the appliance should not be used.
- If the supply cord is damaged it must be replaced by the manufacturer or service agent.
- **DO NOT** allow the mains cable to hang over sharp edges or come in contact with hot surfaces.
- DO NOT run the mains cable under carpets, rugs, etc.
- Allow the unit to cool before storage.
- Before cleaning, disconnect the appliance from the mains supply and allow to cool.
- Unplug after each use. Grasp the plug, not the cord.
- **DO NOT** place the appliance near to flammable material or high pressure containers. (E.g. Paper, wood, petrol, solvents, spray canisters etc.)
- This appliance is intended for household use only and should not be used for industrial purposes.
- DO NOT use any accessories or attachments with this appliance other than those supplied or recommended by supplier.
- **DO NOT** use this appliance for anything other than its intended use.
- DO NOT push objects into any openings as damage to the appliance and/or electric shock may occur.
- The appliance should not be installed in areas which have a fire-risk, such as garages, stables or wooden sheds; this is applicable also for rooms in which highly inflammable gasses or dust can develop. Danger of fire!!



CAUTION

THIS HEATER MUST ONLY BE OPERATED IN THE UPRIGHT POSITION.

The heater must stand on a solid, level nonflammable surface such as stone, slate, ceramic or concrete.

DO NOT Stand the heater on a carpet, rug or other soft floor covering.

THIS APPLIANCE MUST BE EARTHED

This appliance has been ERP classified as a portable space heater and should only be used for supplementary, secondary or temporary heating. It should not be considered for primary permanent heating in a room or dwelling.

During the first few minutes of initial use, you may notice a slight odour and a little smoke. This is normal and will quickly disappear, It is the coating applied to the heating elements to prevent any corrosion during transit.



Explanation of Symbols

The following warning symbols or words are used in this instruction manual:

UK CA

Products labelled with UK Conformity Assessment identifies products conforming to UK statutory requirements.



Products labelled with this symbol conform to applicable provisions of the European Economic Area.



You should now recycle your waste electrical goods and in doing so help the environment. This symbol means waste electrical products at the end of their useful life should not be disposed of with normal household waste and not sent to landfill. Please ensure it is taken to a suitable facility for disposal. Check with your Local Authority or retailer for recycling advice or visit www.recycle-more.co.uk enter your postcode to find out your nearest recycling site.



This symbol provides useful additional information on the use of this product.



This symbol indicates that the supply uses an alternating current mains supply.



This designates a hazard with moderate risk, which may result in severe injury if not adhered to.

Safety Tip-Over Switch

This heater is fitted with built in **Safety Tip-Over Switch** (4). If the heater is knocked over or placed on an uneven or soft/fluffy surface the appliance will automatically switch off.

Should the Safety Tip-Over Switch activate, remove the plug from the mains socket and check for any damage before reuse.

If no damage has occurred, plug the heater back into the mains socket.



Description of Controls



- 1. Heating Elements
- 2. Power Indicator
- 3. Control Switch
- 4. Safety Tip-Over Switch

Before the first time you use your Heater

Remove all packing materials and discard responsibly.

Safety Tip-Over Switch

This heater is fitted with built in **Safety Tip-Over Switch** (4). If the heater is knocked over or placed on an uneven or soft/fluffy surface the appliance will automatically switch off.

Should the Safety Tip-Over Switch activate, remove the plug from the mains socket and check for any damage before reuse.

If no damage has occurred, plug the heater back into the mains socket.

Operating Instructions – heat setting

- Place the heater on a solid, level non-flammable surface.
- Ensure that the **Control Switch** (3) is in the 0 (OFF) position.
- Insert the mains plug into the mains socket.
- Rotate the **Control Switch** (3) to select from:
 - 0 OFF
 - 1 Low Heat Setting (600W)
 - 2 High Heat Setting (1200W)



- 1 The Power Indicator (2) illuminates when the heater is switched on.
- Return the Control Switch (3) to the 0 (OFF) position to switch off the heater.



Care and Use of your Heater

- Always disconnect the heater from the mains power supply and allow it to cool before cleaning.
- Clean the outside of the heater with a clean damp cloth. Never clean with harsh or abrasive cleaners.
- **DO NOT** submerge any part of the heater, its mains cable or plug in water or any other liquids.
- DO NOT WRAP THE MAINS CABLE AROUND THE APPLIANCE.

<u>Safety Cut – Out</u>

MARNING! This appliance is fitted with a built-in safety cut-out, if the cut-out is activated the unit stops working, unplug the heater from the mains and check that the air intake area is not blocked or covered.

Leave for an hour to cool and reset before plugging back into the mains.

Technical Specification

Rated Voltage	220-240V~ 50-60Hz
Rated Power	1200W
Model Number	HEA1893
Protection Class	I (this appliance must be earthed)

Non-Rewireable Mains Plug

If your appliance is supplied with a non-rewireable plug fitted to the mains lead and should the fuse need replacing, you must use an ASTA approved one (conforming to BS 1362 of the same rating). If in doubt, consult a qualified electrician. Never use a plug with the fuse cover missing.

If you need to remove the plug – **DISCONNECT FROM THE MAINS** – and then cut it off the mains lead and immediately dispose of it safely. Never attempt to reuse the plug or insert it into a socket outlet as there is a danger of electric shock.

Disposal of the Packaging

Dispose of paper and cardboard in appropriate paper re-cycling facilities. Dispose of recyclable plastics in appropriate plastic re-cycling facilities. Dispose of non-recyclable plastics in the appropriate plastics collection service.

Disposal of the Product



You should now recycle your waste electrical goods and in doing so help the environment. This symbol means waste electrical products at the end of their useful life should not be disposed of with normal household waste and not sent to landfill. Please ensure it is taken to a suitable facility for disposal. Check with your Local Authority or retailer for recycling advice or visit www.recycle-more.co.uk enter your postcode to find out your nearest recycling site.



Customer Support

Should you require any product information, replacement parts or accessories, please contact our customer care team at help@daewooelectricals.com or call 0161 831 7879.

- Replacement parts and accessories are guaranteed for 1 year from the date of purchase.
- It is important to note that your warranty becomes invalid should non Daewoo parts or accessories be used with this appliance





ErP Data

Model identifier(s): HEA1893						
Item	Symbol	Value	unit	ltem	unit	
Heat output			Type of heat input, for electric storage local space heaters only (select one)			
Nominal heat output	P _{nom}	1,2	kW	manual heat charge control, with integrated thermostat	[no]	
Minimum heat output (indicative)	P _{min}	0,6	kW	manual heat charge control with room and/or outdoor temperature feedback	[no]	
Maximum continuous heat output	P _{max,c}	1,2	kW	electronic heat charge control with room and/or outdoor temperature feedback	[no]	
Auxiliary electricity consumption				fan assisted heat output	[no]	
At nominal heat output	el _{max}	0.000	kW	Type of heat output/room temperature control (select one)		
At minimum heat output	el _{min}	0.000	kW	single stage heat output and no room temperature control	[no]	
In standby mode	el _{sb}	0.000	kW	Two or more manual stages, no room temperature control	[no]	
				with mechanic thermostat room temperature control	[yes]	
				with electronic room temperature control	[no]	
				electronic room temperature control plus day timer	[no]	
				electronic room temperature control plus week timer	[no]	
				Other control options (multiple selections possible)		
				room temperature control, with presence detection	[no]	
				room temperature control, with open window detection	[no]	
				with distance control option	[no]	
				with adaptive start control	[no]	
				with working time limitation	[no]	
				with black bulb sensor		



Notes



WARRANTY

Thank you for purchasing your Daewoo product.

As part of our commitment to quality, we are offering you an extra 2 years warranty in addition to your 1 year quarantee

Your Daewoo product is guaranteed for 1 year from the date of original purchase, with proof of purchase or receipt. If any defect should occur due to faulty workmanship or material, your faulty product should be returned to the place of purchase, replacement or refund is at the discretion of the retailer.

The guarantee is subject to the following provisions:

- The product must be correctly installed and operated in accordance with the requirements contained in the instruction manual.
- The product must be used solely for domestic purposes.
- It does not cover general wear and tear, damage, misuse or any consumable parts.
 The guarantee will be rendered invalid if the product is re-sold or has been damaged through inexpert repair.
- The guarantee is only valid within the UK and Eire.

Your standard 1 year guarantee will only be extended to the maximum available for your individual product upon registration. (Note: products must be registered individually and covers the main body and housing). If you do not register your product within 28 days of the original purchase date, your product will only be guaranteed for 1 year.

To validate your extended 2 year warranty*please register your purchase online within 28 days of the original purchase date by registering at:

https://help.daewooelectricals.com Contact Us (daewooelectricals.com)

*Your extended warranty is only valid with proof of purchase receipt and subject to the conditions outlined above.

> Daewoo is a registered trademark. Produced and imported under licence by **Eurosonic Group Limited** Brightgate House 1 Brightgate Way Manchester M32 0TB UK EU Rep: EuroSonic Magppie (ESM) Ltd. Ireland D05 X006

www.esgltd.com