






Accessories may vary depending on the model.




The cables mentioned in this manual are not supplied with your unit.



Batteries not included*



The remote control may vary depending on the model: The buttons on remote control may have a different name or location than the remote control shown in this manual.




Note: The image shown here is for illustrative purposes only and may be subject to change.
The actual number of ports and their locations may vary depending on the model.

A, B, C, D, E : mm (inches)

F, G : kg (lbs)

MODELS	A		B		C		D		E		F		F - G		Power consumption
OLED83C2AUA OLED83C2PUA	1,851 (72.9)	1,851 (72.9)	1,092 (42.9)	1,092 (42.9)	275 (10.9)	279 (10.9)	1,092 (41.8)	1,092 (41.8)	55.3 (2.1)	55.3 (2.1)	41.6 (91.7)	41.6 (91.7)	32.3 (71.2)	32.3 (71.2)	802 W
Power requirement										AC 120 V~ 50/60 Hz					



C, D : mm (inches)

A	B	C × D (mm)	E
15W440B	OLED83C2*	400 (15.7) × 400 (15.7)	M6
		400 (15.7) × 400 (15.7)	



Read Safety and Reference

Easy Setup Guide

Please read this manual carefully before operating your set and retain it for future reference.



Depending upon model

A	B	C × D (mm)
WR71FR	OLED83C2*	180 (7.0) × 55 (2.1)
		180 (7.0) × 55 (2.1)



804006903A

PRINTED IN MEXICO / SC:02-06-2022 / 2P / Elbrd:J.E.
OBPN: N/A / SHNMDL:OLED83C2AUA_B