

Model No.: MH22242

MONSTER™

BLUETOOTH HEADPHONE

QUICK START GUIDE

Please read this Quick Start Guide carefully and keep it for future use.

Product Overview

Open earphones x2 (L & R)

Charging case x1

USB-C cable x1

Quick start guide and Warning card

Charging

Before using the "Monster Open Ear AC220", please connect the USB-C cable to a power adapter to begin charging. Fully charge the earphones and the charging case before the first use.

Power On/Off

Open the cover of the charging case, take out the earphones, the earphones will turn on automatically. If you want to turn off the earphones, please put the earphones into the charging case and close the cover, the earphones will power off and charge at the same time.

Pairing

Open the cover of the charging case, take out the earphones, the earphones will turn on automatically. For new device connection, turn on the Bluetooth

in your device and choose "Monster Open Ear AC220" from the Bluetooth list to connect. You will hear system prompts after the earphones are connected to the device. If the earphones have been paired before, they will automatically reconnect to the previous device when turned on.

Wearing

Put the "Monster Open Ear AC220" onto your ears and rotate to fit comfortably to get the best wearing and sound quality experience.

MFB Operation

Answer call

Press L or R twice

End call

Press L or R twice

Reject call

Press MFB on the left or right earphone for 2 seconds

LED indicator (earphone)

Power on

White flashes

Power off

The red light on 2s and then turn off

Pairing is successful

The white light on 1s and then turn off

Pairing timed out

The red light on 2s and then turn off

Connection is over distance

White flashes

Disconnect the phone

White flashes

Low battery

Red light flashes slowly

Low power off

The red light on 2s and then turn off

LED indicator (charging case)

Charging

The red light continues to flash slowly, and the red light is full and on

Discharge

When the charging case charges the earphones, the white light stays on and turns off when it is full

Low battery

Place the earphones in the charging case, the white flashes

Reset

In the power on state, touch the MFB of the earphones 5 times (two earphones at the same time), the earphones will automatically shut down and Place the earbuds back into the charging case to recharge. When you take them out again, they will power on automatically and enter pairing mode.

Additional Operation

Answer call

Press L or R twice

End call

Press L or R twice

Reject call

Press MFB on the left or right earphone for 2 seconds

LED indicator (earphone)

Power on

White flashes

Power off

The red light on 2s and then turn off

Pairing is successful

The white light on 1s and then turn off

Pairing timed out

The red light on 2s and then turn off

Connection is over distance

White flashes

Disconnect the phone

White flashes

Low battery

Red light flashes slowly

Low power off

The red light on 2s and then turn off

LED indicator (charging case)

Charging

The red light continues to flash slowly, and the red light is full and on

Discharge

When the charging case charges the earphones, the white light stays on and turns off when it is full

Low battery

Place the earphones in the charging case, the white flashes

Attention

*Private replacement of batteries without permission is not recommended.

*Batteries [battery packs or battery combinations] should not be exposed to lighting, baking or similar overheating environments.

*The input voltage and current standard ≤ 5V/1A when charging the headset charging compartment from an external power source;

FCC STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. FCC ID: 2AVD2-MH22242

IC CAUTION

Radio Standards Specification RSS-Gen, Issue 5
- English:
This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
This device may not cause interference.
This device must accept any interference, including interference that may cause undesired operation of the device.

RF exposure statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

- French:
Cet appareil contient des émetteurs / récepteurs exempts de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:
Cet appareil ne doit pas causer d'interférences.
Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

Déclaration d'exposition RF:
L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. L'appareil peut être utilisé dans des conditions d'exposition portable sans restriction.
IC: 28087-MH22242

Model No.: MH22242

MONSTER™

BLUETOOTH HEADPHONE

快速指南

请仔细阅读本快速指南并妥善保存以备将来使用。
本产品由中国平安保险公司承保

产品概述

耳机x2 (左&右耳)

充电盒x1

USB-C充电线 x1

快速指南/合格证

充电

请在使用此设备前先给耳机和充电盒充满电，此设备可以通过USB-C接口进行充电。

电源开、关

打开充电盒盖，拿出耳机，耳机将自动开机。想要关闭耳机，请将耳机放入充电盒，耳机关机同时进行充电。

配对

打开充电盒盖，拿出耳机，耳机将自动开机。对于新设备连接，请打开蓝牙设备并搜索 " Monster Open Ear AC220 " 进行连接，配对成功后，您会听到系统提示音。
如果耳机之前已配对过，开机就会尝试连接上一次的设备。

佩戴

拿出耳机，将 " Monster Open Ear AC220 " 顺着耳后佩戴，并轻轻旋转至舒适位置，以确保获得最佳的佩戴效果和音质体验。

按键操作

接听

双击左或右耳

挂断

双击左或右耳

拒接

长按左或右耳MFB键2秒

LED 指示灯（耳机）

开机

白灯快闪

关机

红灯长亮2S熄灭

配对成功

白灯长亮1S熄灭

配对超时

红灯长亮2S熄灭

连接超距

白灯快闪

断开手机连接

白灯快闪

低电提醒

红灯慢闪

低电关机

红灯长亮2S熄灭

LED 指示灯（充电盒）

充电

红灯持续慢闪，充满红灯长亮

放电

仓给耳机充电时白灯长亮，充满熄灭

低电提醒

耳机入仓，白灯闪烁

恢复出厂设置

开机状态下连续5击耳机触控键（双耳同时），耳机将自动关机，恢复出厂设置。耳机放入充电盒充电，再取出重新开机，进入配对模式。

更多操作

接听

双击左或右耳

挂断

双击左或右耳

拒接

长按左或右耳MFB键2秒

LED 指示灯（耳机）

开机

白灯快闪

关机

红灯长亮2S熄灭

配对成功

白灯长亮1S熄灭

配对超时

红灯长亮2S熄灭

连接超距

白灯快闪

断开手机连接

白灯快闪

低电提醒

红灯慢闪

低电关机

红灯长亮2S熄灭

LED 指示灯（充电盒）

充电

红灯持续慢闪，充满红灯长亮

放电

仓给耳机充电时白灯长亮，充满熄灭

低电提醒

耳机入仓，白灯闪烁

注意

*不建议未经许可私下更换电池。
*电池[电池组或电池组合]不得暴露在照明，烘烤或类似过热的环境中。
*耳机充电盒在外接电源充电时，输入电压电流标准 ≤ 5V/1A；

产品有毒有害物质或元素表

本表格依据SJ/T11364-2014的规定来编制

有害物质

多溴二苯醚 (PBDEs)

多溴联苯 (PBBs)

六价铬 (Cr(VI))

锑 (Sb)

汞 (Hg)

铅 (Pb)

部件名称

外壳

线材

喇叭

主板

电池

0:表示该有害物质在该部件所有均质材料中的含量均在GB/T26572规定的限量要求以下。
X:表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T26572规定的限量要求。

保修信息卡

信息填写

产品名称:

产品型号:

产品SN号:

购机日期:

用户信息

用户名:

联系电话:

地 址:

封面

75X95MM 105G双胶+1k+186C印刷+风琴折