



OPEN BLUETOOTH HEADSET



INTRODUCTION

Dear users, thank you for purchasing our products. In order to better understand the product, please read this manual carefully before use. Have a good experience.

PRODUCT INTRODUCTION



PRODUCT PARAMETER

Product model	X3	Transmission distance	≥10M
Chip version	V5.3	Charging time	1-2 hours
Horn size	φ16	Endurance time	6-7hours
Frequency response	50Hz-20kHz	Standby time	100 days
Charging bay battery capacity	400mah	Headphone battery capacity	50mah

FUNCTIONAL OPERATION

Music playback

Play/Pause music: Double click

Previous: Three blows to the left ear

Next: Three strikes on the right ear

Volume minus: Click left ear

Sound Plus: Click the right ear

Call management

Call Double-click: Answer the call or hang up the call

Reject a call: Hold down a call for 2 seconds

Auxiliary function

Game/Music: Press and hold right ear for 2 seconds

Voice Assistant: Press and hold the left ear for 2 seconds to access the voice assistant

Language switch: After starting up, click 4 times to switch between Chinese and English, and you need to have an English and Chinese prompt tone

LED INDICATOR

Charging status: headset charging indicator white light is steady on, full light is off.

Pairing status: The white indicator is blinking.

Disconnected phone status: The main ear indicator is blinking, and the secondary ear indicator is off.

Music status: The phone is connected successfully, and the indicator is off.

Call status: The indicator is off.

Game mode: White light breathing light effect

Low battery mode: The white indicator blinks and the voice prompts.

FIRST USE

Before using for the first time, please confirm that the power of the two earphones and the charging compartment is full. If the power is insufficient, please use the data cable equipped with this product to charge, and choose the charging equipment produced by the regular manufacturer through the national CCC certification. If the product has not been used for more than 2 weeks, it is recommended to charge the product before use.

ON/OFF

Automatic power on: After opening the cover of the charging compartment, take out the headset and turn on automatically.

Automatic shutdown: Put the earphones back in the charging compartment, and the earphones will disconnect the Bluetooth connection and automatically shut down.

BLUETOOTH PAIRING CONNECTION

Bluetooth pairing: The headset starts to enter the pairing state, and the Bluetooth device searches for the headset pairing name "X3" and clicks the connection pairing completion.

(If you can't find Bluetooth, turn it off and turn it on to reconnect)If the connection is successful, an announcement is played.

Automatic connect back: After the first connection is successful, the last device is connected by default.

EARPHONE POWER AND CHARGING

Earphone battery display

Mobile phone status bar can display headset device battery information (the mobile phone version needs to support this function)

Earphone charging state

During the charging process of the headset, the indicator light will have a charging reminder, and the indicator light will be turned off after it is full.

Headset low battery reminder

When the earphone is in the low battery state, the earphone will have an announcement indicating that the battery is low. Please put the earphone into the charging bay to charge it in time.

CHARGING BIN POWER AND CHARGING

Charging bin power display

Turn on the digital display inside the charging bin to display real-time power

Bin charging

It is recommended to use a standard charger and the included charging cable to charge the charging bay.

Charging bin low power reminder

When the charging bin digital display shows that the power is too low, please charge the charging bin in time

MATTERS NEEDING ATTENTION

1. Do not disassemble, repair or modify the headset for any reason, otherwise it may cause fire, electronic breakdown or even complete damage to the product.
2. Do not place the product in an environment where the temperature is too low or too high (below 0°C or above 45°C).
3. Do not use the device during thunderstorms. This may cause device failure or electric shock.
4. Do not use strong chemicals, cleaning agents or strong detergents to clean the equipment or its accessories.
5. Do not place the device near heat sources or exposed fire sources, such as electric heaters, microwaves, ovens, water heaters, candles, or other places that may produce high temperatures.
6. Do not listen to music at a high volume for a long time to cause hearing damage. Please adjust the volume when using the device.
7. Do not replace the battery by yourself. This device is equipped with a non-removable built-in battery to avoid damage to the battery or device. Private replacement is not recommended.
8. Before cleaning and maintenance, stop using the device, close all applications, and disconnect all connections or cables from other devices.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the

equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID : 2BEO2-X3