

ELLAS EARS

PRODUCT OVERVIEW WIRELESS EARBUDS

TWS Earbuds

Swarovski Crystal

LED Indicator (White)

Charging Case

Type-C charging port

Touchpad (Answer / End call / Play / Pause / Previous song / Next song)

Microphone

Charging Pins

WIRELESS EARBUDS E400

USER MANUAL

Please read this manual carefully before use and keep it for future reference

PACKING LIST

Charging Case * 1

Wireless Earbud * 2

Type-C Cable * 1

User Manual * 1

POWER ON

Option 1: Take out the earbuds and put them in the charging case. Fully charge both the earbuds and the charging case before the first-time using. It takes approximately 30 minutes to fully recharge the earbuds.

Option 2: Open the charging case and take the earbud(s) out. Or when the earbud is in power-off status, please touch and hold the touchpad on the left/right earbud for 3 seconds to turn on. (The earbuds will turn on automatically, the earbuds will enter the connection mode.) You will hear a voice prompt of "Power On/turn on the earbud."

WEAR

Insert the earbud into your ear and rotate to fit comfortably. Ensure the microphone is pointing towards your mouth.

ANSWER A CALL

Tap the Touchpad of either earbud once

Short press once

Reject a call

Tap and hold the Touchpad for either earbud two seconds

Long press 2 seconds

Note: Switching between the earbud and the phone, please also keep the earbud in contact during the call



FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.