



47986706

7827

VON DUPRIN®

Surface Vertical Rod Exit Device

Installation Instructions

Devices covered by these instructions:


7827 Surface Vertical Rod Exit Device

7827-F (Fire) Surface Vertical Rod Exit Device

CD7827 (Cylinder Dogging) Surface Vertical Rod Exit Device

QEL7827/27-F (Electric Latch Retraction) Surface Vertical Rod Exit Device

HH/HW7827/27-F (Hurricane Rated) Surface Vertical Rod Exit Device




Dogging Key

(use with non-fire devices
to lock down pushbar)

Index:

- Screw chart 2
- Preparation chart 3
- Device installation 4-6
- Cut top rod 7
- Install rod extension 7
- Optional equipment 8
- Cut device 8



Special tools needed:

5/64" hex wrench
#10-24 tap
Drill bits: #25, 1/8", 1/4", 5/16", 13/32"

Hurricane rated exit device requirements (when used with approved Allegion door applications)

Sexbolts		When installing a Wind and Impact-rated hurricane device (HH), sex bolts must be used. Sex bolts are noted throughout the instructions where applicable. If through-bolting trims are used, these trims are equivalent in function and are used in place of sex bolts.		
Application		Single door standard strike	Mullion	Double door standard strike
HH (Wind and Impact rated)	7827	Top: 299F Bottom: 304L	—	Top: 299F Bottom: 304L
	7827-F	—	—	
HW (Wind Only)	7827	Top: 299 Bottom: 304L	—	Top: 299 Bottom: 304L
	7827-F	—	—	



Customer Service



1-877-671-7011 www.allegion.com/us

© Allegion 2024
Printed in U.S.A.
47986706 Rev. 07/24-b




SCREW CHART

A




#10-24 X 1"

Surface mount or
Sex bolts (1-3/4" door)



#10-24 X 1-1/2"


Sex bolts (2-1/4" door)



#10 x 1-1/4" Wood screw


Surface mount (wood)

-Packaged with trim-



#10-24 X 3/4"



785 trims (1-3/4" door)



#10-24 X 1"


785 trims (2-1/4" door)

B




#10-24 X 3/4"

Surface mount or
Sex bolts (1-3/4" door)



#10-24 X 1-1/8"

Sex bolts 2-1/4" door



#10 x 1-1/4" Wood screw

Surface mount (wood)



C



#10-16 x 3/8" Thread cutting


End cap

D



1/4-20 X 3/4"



1-3/4" door



1/4-20 X 1-1/4"


2-1/4" door

E



#10-24 X 3/4"



Metal frame



#10 x 1-1/2" Wood screw

Wood frame


F



#10-12 x 10-24 x 1-1/4" Combination

Metal or wood frame

G



#10-12 x 10-24 x 1-1/4" Combination

Variable floor surfaces


H



#8-32 X 1/4"

Latch covers

I



#10-12 x 10-24 x 1" Combination

Metal or wood door

J




#8-18 x 3/8" Thread cutting


Center case cover

PREPARATION CHART


Go to instructions on next page before using Preparation Chart



1 Draw Horizontal Center Line (☿) and Assemble Device Template




2 Position Template as Shown and Mark Vertical ☿



3 Align Top and Bottom Templates Along ☿ and Prepare Door


See "Preparation Chart" on page 3 for drill, tap, and cut-out information

See trim instructions for pull side door preparation. Line X-X in trim instructions is same as vertical device ☿.




4 Adjust Tailpiece if Needed

Make sure tailpiece is installed at correct length for 1-3/4" thick or 2-1/4" thick door. If necessary, remove pine tree clip, rotate tailpiece, and reinstall pine tree clip.





5 If Using a Cylinder, Remove Cam and Rotate 180°

Cam must be in position shown **with key removed**. If necessary, remove cam screws, place cam in correct position, and reinstall cam screws.




Standard Orientation with key removed.

Rotate cam if necessary as shown here.




For NL and E-trims, use this orientation.

6 If Necessary, Install Cylinder




7 If Using a Cylinder with a Tailpiece, Prepare Device and Cylinder


- a. Install tailpiece guide.




8 Install Trim (if using) and Secure Device Center Case to Door




9 Mark and Prepare 2 Holes for End Cap Bracket




10 Install End Cap Bracket and End Cap




11 Install Top Latch and Rod




12 Install Top Strike



13 Adjust Top Rod (Screw Rod Into or Out of Latch) Until Adjusted as Shown




15 Adjust Bottom Rod with Door Open (Top Latch Retracted)




Open and close door a few times and check for deadlatching when door is closed. Readjust rods if needed.


14 Install Bottom Strike, Latch, and Rod



Hurricane applications use threshold with 304L bottom strike




16 Install Rod Guides and Covers



CUT TOP ROD


1. Measure amount to cut off rod as shown below.

Note: Rod cutting is required for doors shorter than 7'.




*Rods are factory sized for 7' (84") door. Measure actual door opening height and subtract that number from 84" to get amount to cut off top rod.


2. Cut rod.



3. Drill new hole.




4. Reinstall rod end and roll pin.



INSTALL ROD EXTENSION

1. Measure door opening to determine amount to cut off rod extension.




*Standard door heights:


With no extension	7' (84")
With 1' extension	8' (96")
With 3' extension	10' (120")

*Rods are factory sized for door heights shown above. Measure actual door opening height and subtract that number from 96" (for 1' extension) or 120" (for 3' extension) to get amount to cut off extension.


2. Cut rod extension.




3. Drill new hole.



4. Reinstall rod end and roll pin.



5. Connect top rod and rod extension.



OPTIONAL EQUIPMENT - CONTINUED

CD (CYLINDER DOGGING)

1. Remove mortise cylinder cam and reinstall in reverse (Figure 1).
2. Insert key and rotate cam to install the cylinder to the cover plate (Figure 2).
3. Remove key to slide cover plate in position in the mechanism case.




Figure 1

Dogging procedure







Figure 2

CUT DEVICE


1 Measure amount to cut off device.



2 Tape and mark area being cut.



3 Cut device square.



4 Slide anti-rattle clip into device.

