
## dicio

## LEVER WIRE CONNECTORS

## **MODEL 928**



## Instructions:

- 1. Turn off the power before installing or removing connectors.
- 2. You may use solid and/or stranded copper conductors.
- 3. Strip the wires to approx. 10 mm/0.39 inches.
- 4.Lift the lever to 90° and insert stripped conductor fully. Only one wire can be used in each hole.
- 5. Put another stripped wire into the opposite side of the wire entry hole.
- 6.Lower the lever to close the clamp and complete your connection.
- 7. Test through the test slot beneath the housing with a voltage tester.
- 8.To remove, lift the lever and pull out the wire.

Material Data	PC 94V-2 Grade (Housing) PA66 94V-0 Grade (Lever)
Insert	Brass / Tin-Plated Stainless Steel
Voltage / Ampere	450V / 32A(IEC),600V(UL)
Working Temperature	-40°C to 90°C
Cross Section	0.20 - 4mm², AWG 24- 12

928-2 & 928-3 have received both UL and ENEC while 928-1 has received ENEC and is applying for UL approvals

